u-blox M8

Receiver Description Including Protocol Specification

Abstract

The Receiver Description Including Protocol Specification describes the firmware features, specifications and configuration for u-blox M8 high performance positioning modules. The Receiver Description provides an overview and conceptual details of the supported features.

The Protocol Specification describes the NMEA and RTCM protocols as well as the UBX protocol (version 15.00 up to and including version 17.00) and serves as a reference manual. It includes the FTS, Raw Data and Timing product variants.

www.u-blox.com UBX-13003221 - R08





Document InformationTitleu-blox M8 Receiver DescriptionSubtitleIncluding Protocol Specification v15.00-17.00Document typeManualDocument numberUBX-13003221Revision and dateR08 (88183)A December 2014Document statusEarly Production Information

Document status explanation

Objective Specification	Document contains target values. Revised and supplementary data will be published later.
Advance Information	Document contains data based on early testing. Revised and supplementary data will be published later.
Early Production Information	Document contains data from product verification. Revised and supplementary data may be published later.
Production Information	Document contains the final product specification.

This document applies to the following products:

Product name	Type number	ROM/FLASH version	PCN reference
MAX-M8C	MAX-M8C-0-01	ROM 2.01	N/A
MAX-M8Q	MAX-M8Q-0-00	ROM 2.01	N/A
MAX-M8W	MAX-M8W-0-00	ROM 2.01	N/A
NEO-M8N	NEO-M8N-0-01	ROM 2.01 / FLASH 2.01	N/A
NEO-M8M	NEO-M8M-0-00	ROM 2.01	N/A
NEO-M8Q	NEO-M8Q-0-00	ROM 2.01	N/A
NEO-M8T	NEO-M8T-0-00	ROM 2.01 / FLASH 2.30 TIM RAW 1.01	N/A
LEA-M8F	LEA-M8F-0-00	ROM 2.01 / FLASH 2.20 FTS 1.01	N/A
LEA-M8S	LEA-M8S-0-00	ROM 2.01	N/A
LEA-M8T	LEA-M8T-0-00	ROM 2.01 / FLASH 2.30 TIM RAW 1.01	N/A
CAM-M8Q	CAM-M8Q-0-00	ROM 2.01	N/A



u-blox reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. Reproduction, use, modification or disclosure to third parties of this document or any part thereof without the express permission of u-blox is strictly prohibited.

The information contained herein is provided "as is" and u-blox assumes no liability for the use of the information. No warranty, either express or implied, is given, including but not limited, with respect to the accuracy, correctness, reliability and fitness for a particular purpose of the information. This document may be revised by u-blox at any time. For most recent documents, please visit www.u-blox.com.

Copyright © 2014, u-blox AG.

u-blox® is a registered trademark of u-blox Holding AG in the EU and other countries. ARM® is the registered trademark of ARM Limited in the EU and other countries.



Table of Contents

Pref	ace	1
1	Document Overview	1
Rece	eiver Description	2
2	Receiver Configuration	2
	2.1 Configuration Concept	2
	2.2 Organization of the Configuration Sections	3
	2.3 Permanent Configuration Storage Media	4
	2.4 Receiver Default Configuration	4
3	Concurrent GNSS	4
	3.1 Navigation Systems	4
	3.1.1 GPS	4
	3.1.2 GLONASS	4
	3.1.3 BeiDou	5
	3.1.4 SBAS	5
	3.1.5 QZSS	5
	3.1.6 IMES	5
	3.2 Configuration	5
	3.2.1 Configuring QZSS L1SAIF	
4	SBAS Configuration Settings Description	6
	4.1 SBAS (Satellite Based Augmentation Systems)	6
	4.2 SBAS Features	7
	4.3 SBAS Configuration	8
5	IMES Description	
	5.1 IMES Features	9
6	Navigation Configuration Settings Description	9
	6.1 Platform settings	9
	6.2 Navigation Input Filters	10
	6.3 Navigation Output Filters	
	6.3.1 Speed (3-D) Low-pass Filter	11
	6.3.2 Course over Ground Low-pass Filter	11
	6.3.3 Low-speed Course Over Ground Filter	12
	6.4 Static Hold	12
	6.5 Freezing the Course Over Ground	12
	6.6 Degraded Navigation	12
	6.6.1 2D Navigation	12
7	Clocks and Time	12
	7.1 Receiver Local Time	
	7.2 Navigation Epochs	13
	7.3 iTOW Timestamps	14



	7.4	UTC	Representation	14
	7.5	Lea	p Seconds	15
	7.6	Rea	I Time Clock	15
	7.7	GPS	Week Number Rollover	15
8	Seria	al Co	ommunication Ports Description	16
	8.1	TX-ı	ready indication	16
	8.2	Exte	ended TX timeout	16
	8.3	UAF	RT Ports	17
	8.4	USB	Port	17
	8.5	DDO	2 Port	18
	8.5	5.1	Read Access	18
	8.5	5.2	Write Access	20
	8.6	SPI I	Port	21
	8.6	5.1	Maximum SPI clock speed	21
	8.6	5.2	Read Access	21
	8.6	5.3	Back-To-Back Read and Write Access	21
	8.7	Hov	v to change between protocols	22
9	Mult	tiple	GNSS Assistance (MGA)	22
	9.1	Intr	oduction	22
	9.2	Assi	stance Data	22
	9.3	Assi	stNow Online	23
	9.3	3.1	Host Software	24
	9.3	3.2	AssistNow Online Sequence	24
	9.3	3.3	Flow Control	25
	9.3	3.4	Authorization	25
	9.3	3.5	Service Parameters	25
	9.3	3.6	Multiple Servers	27
	9.4	Assi	stNow Offline	27
	9.4	4.1	Service Parameters	28
	9.4	1.2	Authorization	29
	9.4	1.3	Multiple Servers	29
	9.4	1.4	Time, Position and Almanac	29
	9.4	4.5	Flash-based AssistNow Offline	29
	9.4	1.6	Host-based AssistNow Offline	30
	9.5	Pres	erving Information During Power-off	31
	9.6	Assi	stNow Autonomous	31
	9.6	5.1	Introduction	31
	9.6	5.2	Concept	32
	9.6	5.3	Interface	33
	9.6	5.4	Benefits and Drawbacks	34
1() Pov	wer	Management	35
	10.1	Co	ntinuous Mode	36
	10.2	Po	wer Save Mode	36



10.2.1 Operation	36
10.2.2 Configuration	39
10.2.3 Features	42
10.2.4 Examples	43
10.3 Peak current settings	43
10.4 Power On/Off command	43
10.5 EXTINT pin control when Power Save Mode is not active	44
10.6 Measurement and navigation rate with Power Save Mode	44
11 Forcing a Receiver Reset	44
12 Receiver Status Monitoring	45
12.1 Input/Output system	45
12.2 Jamming/Interference Indicator	46
12.3 Jamming/Interference Monitor (ITFM)	46
13 Remote Inventory	
13.1 Description	47
13.2 Usage	47
14 Time pulse	47
14.1 Introduction	47
14.2 Recommendations	48
14.3 GNSS time bases	49
14.4 Time pulse configuration	49
14.5 Configuring time pulse with UBX-CFG-TP5	
14.5.1 Example 1	
14.5.2 Example 2	51
15 Timemark	
16 Odometer	52
16.1 Introduction	52
16.2 Odometer Output	53
16.3 Odometer Configuration	
16.4 Resetting the Odometer	
17 Logging	53
17.1 Introduction	
17.2 Setting the logging system up	
17.3 Information about the log	
17.4 Recording	55
17.5 Retrieval	
17.6 Command message acknowledgement	57
18 Time Mode Configuration	
18.1 Introduction	57
18.2 Fixed Position	57
18.3 Survey-in	57
19 Frequency and Timing Synchronization (FTS)	58
19.1 Introduction	58



19.2 Example use cases	59
19.2.1 Stand-alone synchronization system	59
19.2.2 Oscillator control via host	60
19.2.3 Oscillator control via directly-connected DAC	60
19.2.4 External (coherent) PPS	61
19.3 Synchronization Manager Concept	62
19.4 Oscillator and source specification	63
19.5 Calibration	64
19.6 FTS device Output and Top Of Second (TOS) message	65
19.7 Message transmission time slot reservations on host interfaces	66
19.7.1 Example setup	66
Protocol Specification	68
20 NMEA Protocol	68
20.1 Protocol Overview	68
20.1.1 Message Format	68
20.1.2 Talker ID	68
20.1.3 Protocol Configuration	69
20.1.4 Satellite Numbering	70
20.1.5 Latitude and Longitude Format	70
20.1.6 Position Fix Flags	
20.1.7 Multi-GNSS considerations	
20.1.8 Output of Invalid/Unknown Data	
20.1.9 Messages Overview	
20.2 Standard Messages	
20.2.1 DTM	
20.2.2 GBQ	
20.2.3 GBS	
20.2.4 GGA	
20.2.5 GLL	
20.2.6 GLQ	
20.2.7 GNQ	
20.2.8 GNS	
20.2.9 GPQ	
20.2.10 GRS	
20.2.11 GSA	
20.2.12 GST	
20.2.13 GSV	
20.2.14 RMC	
20.2.15 TXT	
20.2.16 VLW	
20.2.17 VTG	
20.2.18 ZDA	
20.3 PUBX Messages	



2	20.3.1	CONFIG (PUBX,41)	90
2	20.3.2	POSITION (PUBX,00)	91
2	20.3.3	RATE (PUBX,40)	92
2	20.3.4	SVSTATUS (PUBX,03)	93
2	20.3.5	TIME (PUBX,04)	94
21 U	BX Pro	tocol	95
21.	1 UBX	(Protocol Key Features	95
21.	2 UBX	Yeacket Structure	95
21.	3 UBX	(Payload Definition Rules	96
2	21.3.1	Structure Packing	96
2	21.3.2	Reserved Elements	96
2	1.3.3	Undefined Values	96
2	21.3.4	Message Naming	96
2	1.3.5	Number Formats	96
21.4	4 UBX	(Checksum	97
21.	5 UB>	(Message Flow	97
2	1.5.1	Acknowledgement	97
2	1.5.2	Polling Mechanism	98
21.	6 UB>	Satellite Numbering	98
21.	7 UBX	Class IDs	98
21.	8 UB>	K Messages Overview	100
21.	9 UB>	(-ACK (0x05)	105
2	21.9.1	UBX-ACK-ACK (0x05 0x01)	105
2	21.9.2	UBX-ACK-NAK (0x05 0x00)	105
		3X-AID (0x0B)	
		UBX-AID-ALM (0x0B 0x30)	
		UBX-AID-AOP (0x0B 0x33)	
2	21.10.3	UBX-AID-EPH (0x0B 0x31)	109
2	21.10.4	UBX-AID-HUI (0x0B 0x02)	111
2	21.10.5	UBX-AID-INI (0x0B 0x01)	113
		3X-CFG (0x06)	
2	21.11.1	UBX-CFG-ANT (0x06 0x13)	116
2	21.11.2	UBX-CFG-CFG (0x06 0x09)	117
		UBX-CFG-DAT (0x06 0x06)	
2	21.11.4	UBX-CFG-DOSC (0x06 0x61)	121
		UBX-CFG-ESRC (0x06 0x60)	
2	21.11.6	UBX-CFG-GNSS (0x06 0x3E)	125
		UBX-CFG-INF (0x06 0x02)	
		UBX-CFG-ITFM (0x06 0x39)	
2	21.11.9	UBX-CFG-LOGFILTER (0x06 0x47)	130
2	21.11.1	0 UBX-CFG-MSG (0x06 0x01)	
2	21.11.1	1 UBX-CFG-NAV5 (0x06 0x24)	133
2	21.11.1	2 UBX-CFG-NAVX5 (0x06 0x23)	135



3 UBX-CFG-NMEA (0x06 0x17)	137
UBX-CFG-ODO (0x06 0x1E)	144
5 UBX-CFG-PM2 (0x06 0x3B)	146
5 UBX-CFG-PRT (0x06 0x00)	148
7 UBX-CFG-PWR (0x06 0x57)	159
3 UBX-CFG-RATE (0x06 0x08)	159
9 UBX-CFG-RINV (0x06 0x34)	160
) UBX-CFG-RST (0x06 0x04)	161
UBX-CFG-RXM (0x06 0x11)	163
2 UBX-CFG-SBAS (0x06 0x16)	164
3 UBX-CFG-SMGR (0x06 0x62)	166
UBX-CFG-TMODE2 (0x06 0x3D)	169
5 UBX-CFG-TP5 (0x06 0x31)	170
5 UBX-CFG-TXSLOT (0x06 0x53)	174
UBX-CFG-USB (0x06 0x1B)	175
X-INF (0x04)	177
UBX-INF-ERROR (0x04 0x00)	177
UBX-INF-NOTICE (0x04 0x02)	178
UBX-LOG-ERASE (0x21 0x03)	181
UBX-LOG-FINDTIME (0x21 0x0E)	181
UBX-LOG-INFO (0x21 0x08)	182
UBX-LOG-RETRIEVEPOSEXTRA (0x21 0x0f)	184
UBX-LOG-RETRIEVESTRING (0x21 0x0d)	186
UBX-LOG-RETRIEVE (0x21 0x09)	186
UBX-LOG-STRING (0x21 0x04)	187
X-MGA (0x13)	188
UBX-MGA-ANO (0x13 0x20)	189
UBX-MGA-DBD (0x13 0x80)	189
UBX-MGA-FLASH (0x13 0x21)	190
UBX-MGA-GLO (0x13 0x06)	192
UBX-MGA-GPS (0x13 0x00)	195
UBX-MGA-INI (0x13 0x40)	200
UBX-MGA-QZSS (0x13 0x05)	205
X-MON (0x0A)	209
UBX-MON-GNSS (0x0A 0x28)	209
UBX-MON-HW2 (0x0A 0x0B)	211
	UBX-CFG-NMEA (0x06 0x12) UBX-CFG-PM2 (0x06 0x38) UBX-CFG-PM7 (0x06 0x00) UBX-CFG-PM7 (0x06 0x08) UBX-CFG-RATE (0x06 0x08) UBX-CFG-RATE (0x06 0x04) UBX-CFG-RATE (0x06 0x04) UBX-CFG-RATE (0x06 0x04) UBX-CFG-RATE (0x06 0x16) UBX-CFG-RATE (0x06 0x62) UBX-CFG-RATE (0x06 0x62) UBX-CFG-RATE (0x06 0x62) UBX-CFG-TMODE2 (0x06 0x31) UBX-CFG-TMODE2 (0x06 0x32) UBX-CFG-TSUSCI (0x06 0x53) UBX-CFG-TSUSCI (0x06 0x53) UBX-INF-DEBUG (0x04 0x04) UBX-INF-DEBUG (0x04 0x04) UBX-INF-NOTICE (0x04 0x02) UBX-INF-NOTICE (0x04 0x02) UBX-INF-NOTICE (0x04 0x03) UBX-INF-NOTICE (0x04 0x03) UBX-INF-NOTICE (0x21 0x07) UBX-LOG-REASE (0x21 0x03) UBX-LOG-REASE (0x21 0x03) UBX-LOG-RETRIEVEPOSEXTRA (0x21 0x0f) UBX-LOG-RETRIEVESTRING (0x21 0x0d) UBX-LOG-RETRIEVESTRING (0x21 0x0d)



21.15.3 UBX-MON-HW (0x0A 0x09)	212
21.15.4 UBX-MON-IO (0x0A 0x02)	213
21.15.5 UBX-MON-MSGPP (0x0A 0x06)	214
21.15.6 UBX-MON-PATCH (0x0A 0x27)	214
21.15.7 UBX-MON-RXBUF (0x0A 0x07)	216
21.15.8 UBX-MON-RXR (0x0A 0x21)	216
21.15.9 UBX-MON-SMGR (0x0A 0x2E)	217
21.15.10 UBX-MON-TXBUF (0x0A 0x08)	220
21.15.11 UBX-MON-VER (0x0A 0x04)	221
21.16 UBX-NAV (0x01)	222
21.16.1 UBX-NAV-AOPSTATUS (0x01 0x60)	222
21.16.2 UBX-NAV-CLOCK (0x01 0x22)	223
21.16.3 UBX-NAV-DGPS (0x01 0x31)	223
21.16.4 UBX-NAV-DOP (0x01 0x04)	224
21.16.5 UBX-NAV-ODO (0x01 0x09)	225
21.16.6 UBX-NAV-ORB (0x01 0x34)	
21.16.7 UBX-NAV-POSECEF (0x01 0x01)	228
21.16.8 UBX-NAV-POSLLH (0x01 0x02)	229
21.16.9 UBX-NAV-PVT (0x01 0x07)	229
21.16.10 UBX-NAV-RESETODO (0x01 0x10)	232
21.16.11 UBX-NAV-SAT (0x01 0x35)	
21.16.12 UBX-NAV-SBAS (0x01 0x32)	234
21.16.13 UBX-NAV-SOL (0x01 0x06)	235
21.16.14 UBX-NAV-STATUS (0x01 0x03)	
21.16.15 UBX-NAV-SVINFO (0x01 0x30)	238
21.16.16 UBX-NAV-TIMEBDS (0x01 0x24)	240
21.16.17 UBX-NAV-TIMEGLO (0x01 0x23)	241
21.16.18 UBX-NAV-TIMEGPS (0x01 0x20)	242
21.16.19 UBX-NAV-TIMEUTC (0x01 0x21)	243
21.16.20 UBX-NAV-VELECEF (0x01 0x11)	244
21.16.21 UBX-NAV-VELNED (0x01 0x12)	
21.17 UBX-RXM (0x02)	
21.17.1 UBX-RXM-PMREQ (0x02 0x41)	246
21.17.2 UBX-RXM-RAWX (0x02 0x15)	246
21.17.3 UBX-RXM-SFRBX (0x02 0x13)	250
21.17.4 UBX-RXM-SVSI (0x02 0x20)	251
21.18 UBX-TIM (0x0D)	
21.18.1 UBX-TIM-DOSC (0x0D 0x11)	
21.18.2 UBX-TIM-FCHG (0x0D 0x16)	
21.18.3 UBX-TIM-HOC (0x0D 0x17)	
21.18.4 UBX-TIM-SMEAS (0x0D 0x13)	
21.18.5 UBX-TIM-SVIN (0x0D 0x04)	
21.18.6 UBX-TIM-TM2 (0x0D 0x03)	258



21.18.7 UBX-TIM-TOS (0x0D 0x12)	259
21.18.8 UBX-TIM-TP (0x0D 0x01)	261
21.18.9 UBX-TIM-VCOCAL (0x0D 0x15)	263
21.18.10 UBX-TIM-VRFY (0x0D 0x06)	265
21.19 UBX-UPD (0x09)	266
21.19.1 UBX-UPD-SOS (0x09 0x14)	266
22 RTCM Protocol	269
22.1 Introduction	269
22.2 Supported Messages	269
22.3 Configuration	269
22.4 Output	269
22.5 Restrictions	270
22.6 Reference	270
Appendix	271
A Protocol Versions	271
A.1 Supported Protocol Versions	271
B Satellite Numbering	272
C u-blox M8 Default Settings	272
C.1 Antenna Supervisor Settings (UBX-CFG-ANT)	272
C.2 Datum Settings (UBX-CFG-DAT)	272
C.3 Navigation Settings (UBX-CFG-NAV5)	273
C.4 Navigation Settings (UBX-CFG-NAVX5)	273
C.5 Output Rates (UBX-CFG-RATE)	274
C.6 Power Management 2 Configuration (UBX-CFG-PM2)	274
C.7 Receiver Manager Configuration (UBX-CFG-RXM)	274
C.8 GNSS system configuration (UBX-CFG-GNSS)	274
C.9 SBAS Configuration (UBX-CFG-SBAS)	275
C.10 Port Configuration (UBX-CFG-PRT)	275
C.10.1 UART Port Configuration	275
C.10.2 USB Port Configuration	275
C.10.3 SPI Port Configuration	276
C.10.4 DDC Port Configuration	276
C.11 USB Settings (UBX-CFG-USB)	276
C.12 Message Settings (UBX-CFG-MSG)	276
C.13 NMEA Protocol Settings (UBX-CFG-NMEA)	277
C.14 Logging Configuration (UBX-CFG-LOGFILTER)	277
C.15 Remote Inventory (UBX-CFG-RINV)	278
C.16 INF Messages Settings (UBX-CFG-INF)	278
C.17 Timepulse Settings (UBX-CFG-TP5)	278
C.18 Jammer/Interference Monitor (UBX-CFG-ITFM)	279
D u-blox M8 Standard firmware versions	279
Related Documents	280
Overview	280



Revision History	281
Contact	282
u-blox Offices	282



Preface

1 Document Overview

The Receiver Description Including Protocol Specification is an important resource for integrating and configuring u-blox positioning chips and modules. This document has a modular structure and it is not necessary to read it from the beginning to the end. There are two main sections: The Receiver Description and the Protocol Specification.

The Receiver Description describes the software aspects of system features and configuration of u-blox positioning technology. The Receiver Description is structured according to areas of functionality, with links provided to the corresponding NMEA and UBX messages, which are described in the Protocol Specification.

The Protocol Specification is a reference describing the software messages used by your u-blox GNSS (Global Navigation Satellite System: e.g. GPS, GLONASS, etc.) receiver and is organized by the specific NMEA and UBX messages.



This document provides general information on u-blox GNSS receivers. Some information might not apply to certain products. Refer to the product Data Sheet and/or Hardware Integration Manual for possible restrictions or limitations.



Receiver Description

2 Receiver Configuration

2.1 Configuration Concept

u-blox positioning technology is fully configurable with UBX protocol configuration messages (message class UBX-CFG). The configuration used by the GNSS receiver during normal operation is termed "Current Configuration". The Current Configuration can be changed during normal operation by sending any UBX-CFG-XXX message to the receiver over an I/O port. The receiver will change its Current Configuration immediately after receiving the configuration message. The GNSS receiver always uses only the Current Configuration.

Unless the Current Configuration is made permanent by using UBX-CFG-CFG as described below, the Current Configuration will be lost when there is:

- a power cycle
- a hardware reset
- a (complete) controlled software reset

See the section on resetting a receiver for details.

The Current Configuration can be made permanent (stored in a non-volatile memory) by saving it to the "Permanent Configuration". This is done by sending a UBX-CFG-CFG message with an appropriate **saveMask** (UBX-CFG-CFG/save).

The Permanent Configuration is copied to the Current Configuration after start-up or when a UBX-CFG-CFG message with an appropriate **loadMask** (UBX-CFG-CFG/load) is sent to the receiver.

The Permanent Configuration can be restored to the receiver's Default Configuration by sending a UBX-CFG-CFG message with an appropriate **clearMask** (UBX-CFG-CFG/clear) to the receiver.


This only replaces the Permanent Configuration, not the Current Configuration. To make the receiver operate with the Default Configuration which was restored to the Permanent Configuration, a UBX-CFG-CFG/load command must be sent or the receiver must be reset.

The mentioned masks (saveMask, loadMask, clearMask) are 4-byte bitfields. Every bit represents one configuration sub-section. These sub-sections are defined in section "Organization of the Configuration Sections". All three masks are part of every UBX-CFG-CFG message. Save, load and clear commands can be combined in the same message. Order of execution is: clear, save, load.

The following diagram illustrates the process:







It is possible to change the current communications port settings using a UBX-CFG-CFG message. This could affect baud rate and other transmission parameters. Because there may be messages queued for transmission there may be uncertainty about which protocol applies to such messages. In addition a message currently in transmission may be corrupted by a protocol change. Host data reception parameters may have to be changed to be able to receive future messages, including the acknowledge message associated with the UBX-CFG-CFG message.

2.2 Organization of the Configuration Sections

The configuration is divided into several sub-sections. Each of these sub-sections corresponds to one or several UBX-CFG-XXX messages. The sub-section numbers in the following tables correspond to the bit position in the masks mentioned above. All values not listed are reserved

Number	Name	CFG messages	Description
0	PRT	UBX-CFG-PRT	Port and USB settings
		UBX-CFG-USB	
1	MSG	UBX-CFG-MSG	Message settings (enable/disable, update rate)
2	INF	UBX-CFG-INF	Information output settings (Errors, Warnings, Notice, Test etc.)
3	NAV	UBX-CFG-NAV5	Settings for Navigation Parameters, Receiver Datum,
		UBX-CFG-NAVX5	Measurement and Navigation Rate, SBAS, NMEA protocol and
		UBX-CFG-DAT	Time mode (Timing and FTS product variants only)
		UBX-CFG-RATE	
		UBX-CFG-SBAS	
		UBX-CFG-NMEA	
		UBX-CFG-TMODE2	
4	RXM	UBX-CFG-GNSS	GNSS Settings, Power Mode Settings, Time Pulse Settings,
		UBX-CFG-TP5	Jamming/Interference Monitor Settings
		UBX-CFG-RXM	
		UBX-CFG-PM2	
		UBX-CFG-ITFM	
9	RINV	UBX-CFG-RINV	Remote Inventory configuration
10	ANT	UBX-CFG-ANT	Antenna configuration
11	LOG	UBX-CFG-LOGFILTER	Logging configuration

Configuration sub-sections



Configuration sub-sections continued

Number	Name	CFG messages	Description
12	FTS	UBX-CFG-DOSC	Disciplining configuration. Only applicable to the FTS product
		UBX-CFG-ESRC	variant.
		UBX-CFG-SMGR	
		UBX-CFG-SWI2C	
		UBX-CFG-SWI2CDAC	

2.3 Permanent Configuration Storage Media

The Current Configuration is stored in the receiver's volatile RAM. Hence, any changes made to the Current Configuration without saving will be lost if any of the reset events listed in the section above occur. By using UBX-CFG-CFG/save, the selected configuration sub-sections are saved to all non-volatile memories available:

- On-chip BBR (battery backed RAM). In order for the BBR to work, a backup battery must be applied to the receiver.
- External flash memory, where available.

2.4 Receiver Default Configuration

The Permanent Configuration can be reset to Default Configuration through a UBX-CFG-CFG/clear message. The receiver's Default Configuration is normally determined when the receiver is manufactured. Refer to specific product data sheet for further details.

3 Concurrent GNSS

The latest products from u-blox are multi-GNSS receivers capable of receiving and processing signals from multiple Global Navigation Satellite Systems (GNSS).

u-blox concurrent GNSS receivers are multi-GNSS receivers that can acquire and track satellites from more than one GNSS system at the same time, and utilize them in positioning.

3.1 Navigation Systems

This sections briefly describes the different navigation and augmentation systems.

3.1.1 GPS

The Global Positioning System (GPS) is a GNSS operated by the US department of defense. Its purpose is to provide position, velocity and time for civilian and defense users on a global basis. The system currently consists of 32 medium earth orbit satellites and several ground control stations.



GPS receivers are unaffected by leap second changes as their time base (GPS time) is independent of leap seconds. GPS satellites periodically transmit information that allows the receiver to calculate UTC.

3.1.2 GLONASS

GLONASS is a GNSS operated by Russian Federation department of defense. Its purpose is to provide position, velocity and time for civilian and defense users on a global basis. The system consists of 24 medium earth orbit satellites and ground control stations.

It has a number of significant differences when compared to GPS. In most cases, u-blox receivers operate in a very similar manner when they are configured to use GLONASS signals instead of GPS. However some aspects of receiver output are likely to be noticeably affected.



3.1.3 BeiDou

BeiDou is a GNSS operated by China. Its purpose is to initially provide navigation in Asia. In a later stage when the system is fully deployed it will have worldwide coverage. The full system will consist of five geostationary, five inclined geosynchronous and 27 medium earth orbit satellites, as well as control, upload and monitoring stations.

3.1.4 SBAS

There are a number of Space Based Augmentation Systems (SBAS) operated by different countries. They are geostationary satellites.

- WAAS (Wide Area Augmentation System) operated by the US.
- EGNOS (European Geostationary Navigation Overlay Service) operated by the EU.
- MSAS (MUlti-functional Satellite Augmentation System) operated by Japan.

See section SBAS for more details.

3.1.5 QZSS

The Quasi Zenith Satellite System (QZSS) is a regional satellite augmentation system operated by Japan Aerospace Exploration Agency (JAXA). It is intended as an enhancement to GPS, to increase availability and positional accuracy. The QZSS system achieves this by transmitting GPS-compatible signals in the GPS bands. NMEA messages will show the QZSS satellites only if configured to do so (see section Satellite Numbering). The QZSS L1SAIF, or L1S signal, is an additional signal broadcast by QZSS satellites that contains augmentation and other data.

3.1.6 IMES

The Indoor MEssaging System (IMES) is an extension to the QZSS specification. See section IMES for more details.

3.2 Configuration

Use the UBX-CFG-GNSS message to configure the u-blox receiver into the required mode of operation. This message allows the user to specify which GNSS signals should be processed along with limits on how many tracking channels should be allocated to each GNSS. The receiver will respond to such a request with a UBX-ACK-ACK message if it can support the requested configuration or a UBX-ACK-NAK message if not.

The combinations of systems, which can be configured simultaneously depends on the receivers capability to receive several carrier frequencies. Please check the data sheet of your receiver. Usually GPS, SBAS (e.g. WAAS, EGNOS, MSAS), QZSS L1 and Galileo can be enabled together, because they all use the 1575.42MHz L1 frequency. GLONASS and BeiDou both operate on different frequencies, therefore the receiver must be able to receive a second or even third carrier frequency in order to process these systems together with GPS.



It is recommended to disable GLONASS and BeiDou if a GPS-only antenna or GPS-only SAW filter is used.

3.2.1 Configuring QZSS L1SAIF

By default the receiver will be configured for QZSS L1CA, this can be changed so the receiver can be configured for QZSS L1SAIF also. See the table below for UBX-CFG-GNSS sigCfgMask settings for signals on QZSS. For example, to enable QZSS L1CA and QZSS L1SAIF, set the gnssId to 5 (for QZSS) and sigCfgMask to 0x05. If supported by the firmware, L1SAIF would then be enabled.



QZSS Signal configuration for UBX-CFG-GNSS

Gnssld	Description	Signal mask	
5	QZSS	0x01 = QZSS L1CA	
		0x04 = QZSS L1SAIF	

4 SBAS Configuration Settings Description


4.1 SBAS (Satellite Based Augmentation Systems)

SBAS (Satellite Based Augmentation System) is an augmentation technology for GPS, which calculates GPS integrity and correction data with RIMS (Ranging and Integrity Monitoring Stations) on the ground and uses geostationary satellites to broadcast GPS integrity and correction data to GPS users. The correction data is transmitted on the GPS L1 frequency (1575.42 MHz), and therefore no additional receiver is required to make use of the correction and integrity data.

i

Currently, there are no operational augmentation systems for any GNSS other than GPS. Consequently this section only addresses GPS.

SBAS Principle



There are several compatible SBAS systems available or in development all around the world:

- WAAS (Wide Area Augmentation System) for North America has been in operation since 2003.
- MSAS (Multi-Functional Satellite Augmentation System) for Asia has been in operation since 2007.
- EGNOS (European Geostationary Navigation Overlay Service) has been in operation since 2009.
- GAGAN (GPS Aided Geo Augmented Navigation), developed by the Indian government is at the time of writing in test mode.

Support of SBAS allows u-blox GPS technology to take full advantage of the augmentation systems that are currently available (WAAS, EGNOS, MSAS), as well as those being tested and planned (such as GAGAN).



With SBAS enabled, the user benefits from additional satellites for ranging (navigation). u-blox GPS technology uses the available SBAS satellites for navigation just like GPS satellites, if the SBAS satellites offer this service.

To improve position accuracy, SBAS uses different types of correction data:

- Fast Corrections for short-term disturbances in GPS signals (due to clock problems, etc).
- Long-term corrections for GPS clock problems, broadcast orbit errors etc.
- **Ionosphere corrections** for Ionosphere activity

Another benefit of SBAS is the use of GPS integrity information. In this way SBAS control stations can 'disable' the use of GPS satellites within a 6-second alarm time in case of major GPS satellite problems. If integrity monitoring is enabled, u-blox GPS technology only uses satellites, for which integrity information is available.

For more information on SBAS and associated services, refer to the following resources:

- RTCA/DO-229D (MOPS). Available from <u>www.rtca.org</u>
- <u>gps.faa.gov</u> for information on WAAS.
- <u>www.esa.int</u> for information on EGNOS.
- <u>www.essp-sas.eu</u> for information about European Satellite Services Provider (ESSP), the EGNOS operations manager.
- <u>www.isro.org</u> for information on GAGAN.

Identification	Position	GPS PRN	SBAS Provider
AMR	98° W	133	WAAS
PanAmSat Galaxy XV	133.1° W	135	WAAS
TeleSat Anik F1R	107.3° W	138	WAAS
Inmarsat 3F2 AOR-E	15.5° W	120	EGNOS
Artemis	21.5° W	124	EGNOS
Inmarsat 3F5 IOR-W	25° E	126	EGNOS
MTSAT-1R	140° E	129	MSAS
MTSAT-2	145° E	137	MSAS
GSAT-8	55.1° E	127	GAGAN
GSAT-10	83° E	128	GAGAN

SBAS satellites tracked (as of June 2013)

4.2 SBAS Features

This u-blox SBAS implementation is, in accordance with standard RTCA/DO-229D, a class Beta-1 equipment. All timeouts etc. are chosen for the En Route Case. Do not use this equipment under any circumstances for "safety of life" applications!

u-blox receivers are capable of receiving multiple SBAS signals concurrently, even from different SBAS systems (WAAS, EGNOS, MSAS, etc.). They can be tracked and used for navigation simultaneously. Every tracked SBAS satellite utilizes one vacant receiver tracking channel. Only the number of receiver channels limits the total number of satellites used. Every SBAS satellite that broadcasts ephemeris or almanac information can be used for navigation, just like a normal GPS satellite.

For receiving correction data, the u-blox GNSS receiver automatically chooses the best SBAS satellite as its primary source. It will select only one since the information received from other SBAS satellites is redundant and/or could be inconsistent. The selection strategy is determined by the proximity of the satellites, the services offered by the satellite, the configuration of the receiver (Testmode allowed/disallowed, Integrity enabled/disabled) and the signal link quality to the satellite.



If corrections are available from the chosen SBAS satellite and used in the navigation calculation, the DGPS flag is set in the receiver's output protocol messages (see NAV-PVT, NAV-SOL, NAV-STATUS, NAV-SVINFO, NMEA Position Fix Flags description). The message NAV-SBAS provides detailed information about which corrections are available and applied.

The most important SBAS feature for accuracy improvement is lonosphere correction. The measured data from regional RIMS stations are combined to make a TEC (Total Electron Content) Map. This map is transferred to the receiver via the satellites to allow a correction of the ionosphere error on each received satellite.

Supported SBAS messages

Message Type	Message Content	Source
0(0/2)	Test Mode	All
1	PRN Mask Assignment	Primary
2, 3, 4, 5	Fast Corrections	Primary
6	Integrity	Primary
7	Fast Correction Degradation	Primary
9	Satellite Navigation (Ephemeris)	All
10	Degradation	Primary
12	Time Offset	Primary
17	Satellite Almanac	All
18	Ionosphere Grid Point Assignment	Primary
24	Mixed Fast / Long term Corrections	Primary
25	Long term Corrections	Primary
26	lonosphere Delays	Primary

Each satellite services a specific region and its correction signal is only useful within that region. Planning is crucial to determine the best possible configuration, especially in areas where signals from different SBAS systems can be received:

Example 1: SBAS Receiver in North America

In the eastern parts of North America, make sure that EGNOS satellites do not take preference over WAAS satellites. The satellite signals from the EGNOS system should be disallowed by using the PRN Mask.

Example 2: SBAS Receiver in Europe

Some WAAS satellite signals can be received in the western parts of Europe, therefore it is recommended that the satellites from all but the EGNOS system should be disallowed using the PRN Mask.



Although u-blox receivers try to select the best available SBAS correction data, it is recommended to configure them to disallow using unwanted SBAS satellites.

The EGNOS SBAS system does not provide the satellite ranging function.

4.3 SBAS Configuration

To configure the SBAS functionalities use the UBX proprietary message UBX-CFG-SBAS (SBAS Configuration).

SBAS Configuration parameters

Parameter	Description	
Mode - SBAS Subsystem	Enables or disables the SBAS subsystem	
Mode - Allow test mode usage	Allow / Disallow SBAS usage from satellites in Test Mode (Message 0)	
Services/Usage - Ranging	Use the SBAS satellites for navigation	



SBAS Configuration parameters continued

Parameter	Description	
Services/Usage - Apply SBAS	Combined enable/disable switch for Fast-, Long-Term and lonosphere	
correction data	Corrections	
Services/Usage - Apply integrity	Use integrity data	
information		
Number of tracking channels	Should be set using UBX-CFG-GNSS. The field in UBX-CFG-SBAS is	
	no longer supported.	
PRN Mask	Allows selectively enabling/disabling SBAS satellites (e.g. restrict SBAS	
	usage to WAAS-only).	

By default, SBAS is enabled with three prioritized SBAS channels and it will use any received SBAS satellites (except for those in test mode) for navigation, ionosphere parameters and corrections.

5 IMES Description

Indoor MEssaging System (IMES) is an extension to the QZSS specification using ground based beacons that are broadcasting their location. Its purpose is to allow users to navigate inside buildings.



Operation of IMES beacons is only allowed within Japan.

A receiver with IMES enabled is conforming to **IS-QZSS v1.5** and is not working with IMES signals according to v1.4 or below. In particular it is relying on the IMES station's carrier frequency being 1575.4282MHz ± 0.2ppm as specified in the IMES specification. Working with IMES stations that are not within this frequency range can result in delayed or missing IMES/GNSS signal acquisition. Also the receiver expects the preamble 0x9E as well as the correct sequence of CNT values as specified by the IS-QZSS.

5.1 IMES Features

- **50/250bps Auto-Detection:** A receiver configured to receive IMES signals supports both 50bps and 250bps IMES signals. The transmitter's data rate is detected automatically which allows the receiver to even work in a mixed 50bps/250bps IMES environment.
- Dynamic Tracking Channel Allocation: The allocation of the tracking channels is done dynamically. If IMES stations are within reach of the receiver, by default up to 8 (or any other number of maxTrkCh configured in CFG-GNSS) tracking channels can be assigned for IMES usage. Still, if no IMES station is around, all channels can be used by other systems. To reserve a certain number of channels for IMES only (can not be used by other systems anymore!), resTrkCh in CFG-GNSS can be used.
- Raw IMES frames: The raw IMES subframes received from the IMES stations are given in RXM-SFRBX.

6 Navigation Configuration Settings Description

This section relates to the configuration message UBX-CFG-NAV5.

6.1 Platform settings

u-blox positioning technology supports different dynamic platform models (see table below) to adjust the navigation engine to the expected application environment. These platform settings can be changed dynamically without performing a power cycle or reset. The settings improve the receiver's interpretation of the measurements and thus provide a more accurate position output. Setting the receiver to an unsuitable platform model for the given application environment is likely to result in a loss of receiver performance and position



accuracy.

Dynamic Platform Models

Platform	Description	
Portable	Applications with low acceleration, e.g. portable devices. Suitable for most situations.	
Stationary	Used in timing applications (antenna must be stationary) or other stationary applications.	
	Velocity restricted to 0 m/s. Zero dynamics assumed.	
Pedestrian	Applications with low acceleration and speed, e.g. how a pedestrian would move. Low	
	acceleration assumed.	
Automotive Used for applications with equivalent dynamics to those of a passenger car. Lov		
	acceleration assumed.	
At sea Recommended for applications at sea, with zero vertical velocity. Zero vertical velo		
	assumed. Sea level assumed.	
Airborne <1g	Used for applications with a higher dynamic range and greater vertical acceleration than	
	passenger car. No 2D position fixes supported.	
Airborne <2g	Recommended for typical airborne environments. No 2D position fixes supported.	
Airborne <4g	Only recommended for extremely dynamic environments. No 2D position fixes supported.	

Dynamic Platform Model Details

Platform	Max Altitude	MAX Horizontal	MAX Vertical	Sanity check type	Max Position Deviation
	[m]	Velocity [m/s]	Velocity [m/s]		
Portable	12000	310	50	Altitude and Velocity	Medium
Stationary	9000	10	6	Altitude and Velocity	Small
Pedestrian	9000	30	20	Altitude and Velocity	Small
Automotive	6000	100	15	Altitude and Velocity	Medium
At sea	500	25	5	Altitude and Velocity	Medium
Airborne <1g	50000	100	100	Altitude	Large
Airborne <2g	50000	250	100	Altitude	Large
Airborne <4g	50000	500	100	Altitude	Large



Dynamic platforms designed for high acceleration systems (e.g. airborne <2g) can result in a higher standard deviation in the reported position.

6.2 Navigation Input Filters

The navigation input filters in CFG-NAV5 mask the input data of the navigation engine.



These settings are already optimized. Do not change any parameters unless advised by u-blox support engineers.

Navigation Input Filter parameters

Parameter	Description		
fixMode	By default, the receiver calculates a 3D position fix if possible but reverts to 2D position if		
	necessary (Auto 2D/3D). The receiver can be forced to only calculate 2D (2D only) or 3D (
	3D only) positions.		
fixedAlt and	The fixed altitude is used if fixMode is set to 2D only. A variance greater than zero must		
fixedAltVar	also be supplied.		
minElev	Minimum elevation of a satellite above the horizon in order to be used in the navigation		
	solution. Low elevation satellites may provide degraded accuracy, due to the long signal		
	path through the atmosphere.		



Navigation Input Filter parameters continued

Parameter	Description
cnoThreshNumSVs	A navigation solution will only be attempted if there are at least the given number of SVs
and cnoThresh	with signals at least as strong as the given threshold.

See also comments in section Degraded Navigation below.

6.3 Navigation Output Filters

The result of a navigation solution is initially classified by the fix type (as detailed in the fixType field of UBX-NAV-PVT message). This distinguishes between failures to obtain a fix at all ("No Fix") and cases where a fix has been achieved, which are further subdivided into specific types of fixes (e.g. 2D, 3D, dead reckoning).

Where a fix has been achieved, a check is made to determine whether the fix should be classified as valid or not. A fix is only valid if it passes the navigation output filters as defined in UBX-CFG-NAV5. In particular, both PDOP and accuracy values must lie below the respective limits.

Valid fixes are marked using the valid flag in certain NMEA messages (see Position Fix Flags in NMEA) and the gnssFixOK flag in UBX-NAV-PVT message.

Important: Users are recommended to check the gnssFixOK flag in the UBX-NAV-PVT or the NMEA valid flag. Fixes not marked valid should not normally be used.

The UBX-NAV-SOL and UBX-NAV-STATUS messages also report whether a fix is valid in their gpsFixOK and GPSfixOk flags. These messages have only been retained for backwards compatibility and users are recommended to use the UBX-NAV-PVT message in preference.

The UBX-CFG-NAV5 message also defines TDOP and time accuracy values that are used in order to establish whether a fix is regarded as locked to GNSS or not, and as a consequence of this, which time pulse setting has to be used. Fixes that do not meet both criteria will be regarded as unlocked to GNSS, and the corresponding time pulse settings of UBX-CFG-TP5 will be used to generate a time pulse.

6.3.1 Speed (3-D) Low-pass Filter

The UBX-CFG-ODO message offers the possibility to activate a speed (3-D) low-pass filter. The output of the speed low-pass filter is published in the UBX-NAV-VELNED message (*speed* field). The filtering level can be set via the UBX-CFG-ODO message (*velLpGain* field) and must be comprised between 0 (heavy low-pass filtering) and 255 (weak low-pass filtering).



Strictly speaking, the internal filter gain is computed as a function of speed. Therefore, the level as defined in the UBX-CFG-ODO message (velLpGain field) defines the nominal filtering level for speeds below 5m/s.

6.3.2 Course over Ground Low-pass Filter

The UBX-CFG-ODO message offers the possibility to activate a course over ground low-pass filter when the speed is below 8m/s. The output of the course over ground (also named *heading of motion 2-D*) low-pass filter is published in the UBX-NAV-PVT message (*headMot* field), UBX-NAV-VELNED message (*heading* field), NMEA-RMC message (*cog* field) and NMEA-VTG message (*cogt* field). The filtering level can be set via the UBX-CFG-ODO message (*cogLpGain* field) and must be comprised between 0 (heavy low-pass filtering) and 255 (weak low-pass filtering).



The filtering level as defined in the UBX-CFG-ODO message (cogLpGain field) defines the filter gain for speeds below 8m/s. If the speed is higher than 8m/s, no course over ground low-pass filtering is performed.



6.3.3 Low-speed Course Over Ground Filter

The UBX-CFG-ODO message offers the possibility to activate a low-speed course over ground filter (also named *heading of motion 2-D*). This filter derives the course over ground from position at very low speed. The output of the low-speed course over ground filter is published in the UBX-NAV-PVT message (*headMot* field), UBX-NAV-VELNED message (*heading* field), NMEA-RMC message (*cog* field) and NMEA-VTG message (*cogt* field). If the low-speed course over ground filter is not activated or inactive, then the course over ground is computed as described in section Freezing the Course Over Ground.

6.4 Static Hold

Static Hold Mode allows the navigation algorithms to decrease the noise in the position output when the velocity is below a pre-defined 'Static Hold Threshold. This reduces the position wander caused by environmental factors such as multi-path and improves position accuracy especially in stationary applications. By default, static hold mode is disabled.

If the speed drops below the defined 'Static Hold Threshold, the Static Hold Mode will be activated. Once Static Hold Mode has been entered, the position output is kept static and the velocity is set to zero until there is evidence of movement again. Such evidence can be velocity, acceleration, changes of the valid flag (e.g. position accuracy estimate exceeding the Position Accuracy Mask, see also section Navigation Output Filters), position displacement, etc.

The UBX-CFG-NAV5 message additionally allows for configuration of distance threshold (field staticHoldMaxDist). If the estimated position is farther away from the static hold position than this threshold, static mode will be quit.

6.5 Freezing the Course Over Ground

If the low-speed course over ground filter is deactivated or inactive (see section Low-speed Course over Ground Filter), the receiver derives the course over ground from the GNSS velocity information. If the velocity cannot be calculated with sufficient accuracy (e.g., with bad signals) or if the absolute speed value is very low (under 0. 1m/s) then the course over ground value becomes inaccurate too. In this case the course over ground value is frozen, i.e. the previous value is kept and its accuracy is degraded over time. These frozen values will not be output in the NMEA messages NMEA-RMC and NMEA-VTG unless the NMEA protocol is explicitely configured to do so (see NMEA Protocol Configuration).

6.6 Degraded Navigation

Degraded navigation describes all navigation modes which use less than four Satellite Vehicles (SV).

6.6.1 2D Navigation

If the receiver only has three SVs for calculating a position, the navigation algorithm uses a constant altitude to compensate for the missing fourth SV. When an SV is lost after a successful 3D fix (min. four SVs available), the altitude is kept constant at the last known value. This is called a 2D fix.



u-blox positioning technology does not calculate any solution with less than three SVs. Only u-blox timing receivers can, when stationary, calculate a timing solution with only one SV.

7 Clocks and Time



7.1 Receiver Local Time

The receiver is dependent on a local oscillator (normally a TCXO or Crystal oscillator) for both the operation of its radio parts and also for timing within its signal processing. No matter what nominal frequency the local oscillator has (e.g. 26 MHz), u-blox receivers subdivide the oscillator signal to provide a 1 kHz reference clock signal, which is used to drive many of the receiver's processes. In particular, the measurement of satellite signals is arranged to be synchronised with the "ticking" of this 1 kHz clock signal.

When the receiver first starts, it has no information about how these clock ticks relate to other time systems; it can only count time in 1 millisecond steps. However, as the receiver derives information from the satellites it is tracking or from aiding messages, it estimates the time that each 1 kHz clock tick takes in the time-base of the relevant GNSS system. (In previous versions of the firmware for u-blox receivers this was always the GPS time-base, but in the latest firmware it could be GPS, GLONASS, or BeiDou, and in the future it could also be other GNSS systems, such as Galileo.) This estimate of GNSS time based on the local 1 kHz clock is called **receiver local time**.

As receiver local time is a mapping of the local 1 kHz reference onto a GNSS time-base, it may experience occasional discontinuities, especially when the receiver first starts up and the information it has about the time-base is changing. Indeed after a cold start receiver local time will indicate the length of time that the receiver has been running. However, when the receiver obtains some credible timing information from a satellite or aiding message, it will jump to an estimate of GNSS time.

7.2 Navigation Epochs

Each navigation solution is triggered by the tick of the 1 kHz clock nearest to the desired navigation solution time. This tick is referred to as a **navigation epoch**. If the navigation solution attempt is successful, one of the results is an accurate measurement of time in the time-base of the chosen GNSS system, called **GNSS system time**. The difference between the calculated GNSS system time and receiver local time is called the **clock bias** (and the **clock drift** is the rate at which this bias is changing).

In practice the receiver's local oscillator will not be as stable as the atomic clocks to which GNSS systems are referenced and consequently clock bias will tend to accumulate. However, when selecting the next navigation epoch, the receiver will always try to use the 1 kHz clock tick which it estimates to be closest to the desired fix period as measured in GNSS system time. Consequently the number of 1 kHz clock ticks between fixes will occasionally vary (so when producing one fix per second, there will normally be 1000 clock ticks between fixes, but sometimes, to correct drift away from GNSS system time, there will be 999 or 1001).

The GNSS system time calculated in the navigation solution is always converted to a time in both the GPS and UTC time-bases for output.

Clearly when the receiver has chosen to use the GPS time-base for its GNSS system time, conversion to GPS time requires no work at all, but conversion to UTC requires knowledge of the number of leap seconds since GPS time started (and other minor correction terms). The relevant GPS to UTC conversion parameters are transmitted periodically (every 12.5 minutes) by GPS satellites, but can also be supplied to the receiver via the UBX-MGA-GPS-UTC aiding message. By contrast when the receiver has chosen to use the GLONASS time-base as its GNSS system time, conversion to GPS time is more difficult as it requires knowledge of the difference between the two time-bases, but conversion to UTC is easier (as GLONASS time is closely linked to UTC).

Where insufficient information is available for the receiver to perform any of these time-base conversions precisely, pre-defined default offsets are used. Consequently plausible times are nearly always generated, but they may be wrong by a few seconds (especially shortly after receiver start). Depending on the configuration of the receiver, such "invalid" times may well be output, but with flags indicating their state (e.g. the "valid" flags in UBX-NAV-PVT).



u-blox GNSS receivers employ multiple GNSS system times and/or receiver local times (in order to support multiple GNSS systems concurrently), so users should not rely on UBX messages that report GNSS system time or receiver local time being supported in future. It is therefore recommended to give preference to those messages that report UTC time.

7.3 iTOW Timestamps

All the main UBX-NAV messages (and some other messages) contain an **iTOW** field which indicates the GPS time at which the navigation epoch occurred. Messages with the same iTOW value can be assumed to have come from the same navigation solution.

Note that iTOW values may not be valid (i.e. they may have been generated with insufficient conversion data) and therefore it is not recommended to use the iTOW field for any other purpose. If reliable absolute time information is required, users are recommended to use the UBX-NAV-TIMEUTC, UBX-NAV-TIMEGPS, UBX-NAV-TIMEGLO, UBX-NAV-TIMEBDS, UBX-NAV-PVT or UBX-NAV-SOL messages, which contain additional fields that indicate the validity and accuracy of the calculated times.



The original designers of GPS chose to express time/date as an integer week number (starting with the first full week in January 1980) and a time of week (often abbreviated to TOW) expressed in seconds. Manipulating time/date in this form is far easier for digital systems than the more "conventional" year/month/day, hour/minute/second representation. Consequently, most GNSS receivers use this representation internally, only converting to a more "conventional form" at external interfaces. The iTOW field is the most obvious externally visible consequence of this internal representation.

7.4 UTC Representation

UTC time is used in many NMEA and UBX messages. In NMEA messages it is always reported rounded to the nearest hundredth of a second. Consequently, it is normally reported with two decimal places (e.g. 124923. 52). What is more, although compatibility mode (selected using UBX-CFG-NMEA) requires three decimal places, rounding to the nearest hundredth of a second remains, so the extra digit is always 0.

UTC time is also reported within some UBX messages, such as UBX-NAV-TIMEUTC and UBX-NAV-PVT. In these messages date and time are separated into seven distinct integer fields. Six of these (year, month, day, hour, min and sec) have fairly obvious meanings and are all guaranteed to match the corresponding values in NMEA messages generated by the same navigation epoch. This facilitates simple synchronisation between associated UBX and NMEA messages.

The seventh field is called nano and it contains the number of nanoseconds by which the rest of the time and date fields need to be corrected to get the precise time. So, for example, the UTC time 12:49:23.521 would be reported as: hour: 12, min: 49, sec: 23, nano: 521000000.

It is however important to note that the first six fields are the result of rounding to the nearest hundredth of a second. Consequently the nano value can range from -5000000 (i.e. -5 ms) to +9949999999 (i.e. nearly 995 ms).

When the nano field is negative, the number of seconds (and maybe minutes, hours, days, months or even years) will have been rounded up. Therefore, some or all of them will need to be adjusted in order to get the correct time and date. Thus in an extreme example, the UTC time 23:59:59.9993 on 31st December 2011 would be reported as: year: 2012, month: 1, day: 1, hour: 0, min: 0, sec: 0, nano: -700000.

Of course, if a resolution of one hundredth of a second is adequate, negative nano values can simply be rounded up to 0 and effectively ignored.

Which master clock the UTC time is referenced to is output in the message UBX-NAV-TIMEUTC.



7.5 Leap Seconds

Occasionally it is decided (by one of the international time keeping bodies) that, due to the slightly uneven spin rate of the Earth, UTC has moved sufficiently out of alignment with mean solar time (i.e. the Sun no longer appears directly overhead at 0 longitude at midday). A "leap second" is therefore announced to bring UTC back into close alignment. This normally involves adding an extra second to the last minute of the year, but it can also happen on 30th June. When this happens UTC clocks are expected to go from 23:59:59 to 23:59:60 and only then on to 00:00:00.

It is also theoretically possible to have a negative leap second, in which case there will only be 59 seconds in a minute and 23:59:58 will be followed by 00:00:00.

u-blox receivers are designed to handle leap seconds in their UTC output and consequently users processing UTC times from either NMEA and UBX messages should be prepared to handle minutes that are either 59 or 61 seconds long.

7.6 Real Time Clock

u-blox receivers contain circuitry to support a **real time clock**, which (if correctly fitted and powered) keeps time while the receiver is otherwise powered off. When the receiver powers up, it attempts to use the real time clock to initialise receiver local time and in most cases this leads to appreciably faster first fixes.

7.7 GPS Week Number Rollover

GPS Time is a continuous counting time scale beginning at the January 5, 1980 to January 6, 1980 midnight. It is split into two parts: a time of week measured in seconds from midnight Sat/Sun and a week number. The time of week is transmitted in an unambiguous manner by the satellites, but only the bottom 10 bits of the week number are transmitted. This means that a receiver will see a week number count that goes up steadily until it reaches 1023 after which it will "roll over" back to zero, before steadily going up again. Such a week rollover will occur approx. every 20 years. The last week rollover occurred in 1999 and the next one will be in 2019. It is up to the GPS receiver to correctly handle such the ambiguity of the transmitted week numbers and the associated rollovers.

u-blox GNSS receivers solve this problem by assuming that all week numbers must be at least as large as a reference rollover week number. This reference rollover week number is hard-coded into the firmware at compile time and is normally set a few weeks before the s/w is completed, but it can be overridden by the wknRollover field of the UBX-CFG-NAVX5 message to any value the user wishes.

The following example illustrates how this works: Assume that the reference rollover week number set in the firmware at compile time is 1524 (which corresponds to a week in calendar year 2009, but would be transmitted by the satellites as 500). In this case, if the receiver sees transmissions containing week numbers in the range 500 ... 1023, these will be interpreted as week numbers 1524 ... 2027 (CY 2009 ... 2019), whereas transmissions with week numbers from 0 to 499 are interpreted as week numbers 2028 ... 2526 (CY 2019 ... 2029).

BeiDou and Galileo have similar representations of time, but transmit sufficient bits for the week number not to be ambiguous for the forseeable future. GLONASS has a different structure, but again transmits sufficient information to avoid any rollover during the expected lifetime of the system.



It is important to set the reference rollover week number appropriately when supplying u-blox receivers with simulated signals, especially when the scenarios are in the past.



8 Serial Communication Ports Description

u-blox positioning technology comes with a highly flexible communication interface. It supports the NMEA and the proprietary UBX protocols, and is truly multi-port and multi-protocol capable. Each protocol (UBX, NMEA) can be assigned to several ports at the same time (multi-port capability) with individual settings (e.g. baud rate, message rates, etc.) for each port. It is even possible to assign more than one protocol (e.g. UBX protocol and NMEA at the same time) to a single port (multi-protocol capability), which is particularly useful for debugging purposes.

To enable a message on a port the UBX and/or NMEA protocol must be enabled on that port using the UBX proprietary message CFG-PRT. This message also allows changing port-specific settings (baud rate, address etc.). See CFG-MSG for a description of the mechanism for enabling and disabling messages.

The following table shows the port numbers used. Note that any numbers not listed are reserved for future use.

Port #	Electrical Interface	
0	DDC (I ² C compatible)	
1	UART 1	
3	USB	
4	SPI	

Port Number assignment

8.1 TX-ready indication

This feature enables each port to define a corresponding pin, which indicates if bytes are ready to be transmitted. By default, this feature is disabled. For USB, this feature is configurable but might not behave as described below due to a different internal transmission mechanism. If the number of pending bytes reaches the threshold configured for this port, the corresponding pin will become active (configurable active-low or active-high), and stay active until the last bytes have been transferred from software to hardware (note that this is not necessarily equal to all bytes transmitted, i.e. after the pin has become inactive, up to 16 bytes can still need to be transferred to the host).

The TX-ready pin can be selected from all PIOs which are not in use (see MON-HW for a list of the PIOs and their mapping), each TX-ready pin is exclusively for one port and cannot be shared. If the PIO is invalid or already in use, only the configuration for the TX-ready pin is ignored, the rest of the port configuration is applied if valid. The acknowledge message does not indicate if the TX-ready configuration is successfully set, it only indicates the successful configuration of the port. To validate successful configuration of the TX-ready pin, the port configuration should be polled and the settings of TX-ready feature verified (will be set to disabled/all zero if settings invalid).

The threshold should not be set above 2 kB, as the internal message buffer limit can be reached before this, resulting in the TX-ready pin never being set as messages are discarded before the threshold is reached.

8.2 Extended TX timeout

If the host does not communicate over SPI or DDC for more than approximately 2 seconds, the device assumes that the host is no longer using this interface and no more packets are scheduled for this port. This mechanism can be changed enabling "extended TX timeouts", in which case the receiver delays idling the port until the allocated and undelivered bytes for this port reach 4 kB. This feature is especially useful when using the TX-ready feature with a message output rate of less than once per second, and polling data only when data is available, determined by the TX-ready pin becoming active.



8.3 UART Ports

One or two Universal Asynchronous Receiver/Transmitter (<u>UART</u>) ports are featured, that can be used to transmit GNSS measurements, monitor status information and configure the receiver. See our online product descriptions for availability.

The serial ports consist of an RX and a TX line. Neither handshaking signals nor hardware flow control signals are available. These serial ports operate in asynchronous mode. The baud rates can be configured individually for each serial port. However, there is no support for setting different baud rates for reception and transmission.

Baud Rate	Data Bits	Parity	Stop Bits
4800	8	none	1
9600	8	none	1
19200	8	none	1
38400	8	none	1
57600	8	none	1
115200	8	none	1
230400	8	none	1
460800	8	none	1

Possible UART Interface Configurations

Note that for protocols such as NMEA or UBX, it does not make sense to change the default word length values (data bits) since these properties are defined by the protocol and not by the electrical interface.

If the amount of data configured is too much for a certain port's bandwidth (e.g. all UBX messages output on a UART port with a baud rate of 9600), the buffer will fill up. Once the buffer space is exceeded, new messages to be sent will be dropped. To prevent message losses, the baud rate and communication speed or the number of enabled messages should be selected so that the expected number of bytes can be transmitted in less than one second.

See CFG-PRT for UART for a description of the contents of the UART port configuration message.

8.4 USB Port

One Universal Serial Bus (<u>USB</u>) port is featured. See the Data Sheet of your specific product for availability. This port can be used for communication purposes and to power the positioning chip or module.

The USB interface supports two different power modes:

- In *Self Powered Mode* the receiver is powered by its own power supply. **VDDUSB** is used to detect the availability of the USB port, i.e. whether the receiver is connected to a USB host.
- In *Bus Powered Mode* the device is powered by the USB bus, therefore no additional power supply is needed. See the table below for the default maximum current that can be drawn by the receiver. See CFG-USB for a description on how to change this maximum. Configuring Bus Powered Mode indicates that the device will enter a low power state with disabled GNSS functionality when the host suspends the device, e.g. when the host is put into stand-by mode.

Maximum Current in Bus Powered Mode

Generation	Max Current
u-blox M8	100 mA



The voltage range for **VDDUSB** is specified from 3.0V to 3.6V, which differs slightly from the specification for VCC



 \mathbf{i}

The boot screen is retransmitted on the USB port after the enumeration. However, messages generated between bootup of the receiver and USB enumeration are not visible on the USB port.

8.5 DDC Port

The Display Data Channel (DDC) bus is a two-wire communication interface compatible with the I²C standard (Inter-Integrated Circuit). See our online product selector matrix for availability.

Unlike all other interfaces, the DDC is not able to communicate in full-duplex mode, i.e. TX and RX are mutually exclusive. u-blox receivers act as a slave in the communication setup, therefore they cannot initiate data transfers on their own. The host, which is always master, provides the data clock (SCL), and the clock frequency is therefore not configurable on the slave.

The receiver's DDC address is set to 0x42 by default. This address can be changed by setting the mode field in CFG-PRT for DDC accordingly.

As the receiver will be run in slave mode and the DDC physical layer lacks a handshake mechanism to inform the master about data availability, a layer has been inserted between the physical layer and the UBX and NMEA layer. The receiver DDC interface implements a simple streaming interface that allows the constant polling of data, discarding everything that is not parse-able. The receiver returns 0xFF if no data is available. The TX-ready feature can be used to inform the master about data availability and can be used as a trigger for data transmission.

8.5.1 Read Access


The DDC interface allows 256 slave registers to be addressed. As shown in Figure *DDC Register Layout* only three of these are currently implemented. The data registers 0 to 252, at addresses 0x00 to 0xFC, each 1 byte in size, contain information to be defined later - the result of reading them is undefined. The currently available number of bytes in the message stream can be read at addresses 0xFD and 0xFE. The register at address 0xFF allows the data stream to be read. If there is no data awaiting transmission from the receiver, then this register will deliver the value 0xff, which cannot be the first byte of a valid message. If message data is ready for transmission then successive reads of register 0xff will deliver the waiting message data.



The registers 0x00 to 0xFC will be defined in a later firmware release. Do not use them, as they don't provide any meaningful data!




DDC Register Layout



8.5.1.1 Read Access Forms

There are two forms of DDC read transfer. The 'random access' form includes a slave register address and thus allows any register to be read. The second 'current address' form omits the register address. If this second form is used then an address pointer in the receiver is used to determine which register to read. This address pointer will increment after each read unless it is already pointing at register 0xff, the highest addressable register, in which case it remains unaltered. The initial value of this address pointer at startup is 0xff, so by default all current address reads will repeatedly read register 0xff and receive the next byte of message data (or 0xff if no message data is waiting). Figure *DDC Random Read Access*) shows the format of the random access form of the request. Following the start condition from the master, the 7-bit device address and the RW bit (which is a logic low for write access) are clocked onto the bus by the master transmitter. The receiver answers with an acknowledge (logic low) to indicate that it recognises the address. Next, the 8-bit address of the register to be read must be written to the bus. Following the receiver's acknowledge, the master again triggers a start condition and writes the device address, but this time the RW bit is a logic high to initiate the read access. Now, the master can read 1 to N bytes from the receiver, generating a not-acknowledge and a stop condition after the last byte being read.






DDC Random Read Access

The format of the current address read request is :

DDC Current Address Read Access




8.5.2 Write Access

The receiver does not provide any write access except for writing UBX and NMEA messages to the receiver, such as configuration or aiding data. Therefore, the register set mentioned in section Read Access is not writeable. Following the start condition from the master, the 7-bit device address and the RW bit (which is a logic low for write access) are clocked onto the bus by the master transmitter. The receiver answers with an acknowledge (logic low) to indicate that it is responsible for the given address. Now, the master can write 2 to N bytes to the receiver, generating a stop condition after the last byte being written. The number of data bytes must be at least 2 to properly distinguish from the write access to set the address counter in random read accesses.



DDC Write Access



8.6 SPI Port

A Serial Peripheral Interface (<u>SPI</u>) bus is available with selected receivers. See our online product descriptions for availability.

SPI is a four-wire synchronous communication interface. In contrast to UART, the master provides the clock signal, which therefore doesn't need to be specified for the slave in advance. Moreover, a baud rate setting is not applicable for the slave. SPI modes 0-3 are implemented and can be configured using the field mode. spiMode in CFG-PRT for SPI (default is SPI mode 0).

The SPI clock speed is limited depending on hardware and firmware versions!

8.6.1 Maximum SPI clock speed

8.6.2 Read Access

As the register mode is not implemented for the SPI port, only the UBX/NMEA message stream is provided. This stream is accessed using the Back-To-Back Read and Write Access (see section Back-To-Back Read and Write Access). When no data is available to be written to the receiver, MOSI should be held logic high, i.e. all bytes written to the receiver are set to 0xFF.

To prevent the receiver from being busy parsing incoming data, the parsing process is stopped after 50 subsequent bytes containing 0xFF. The parsing process is re-enabled with the first byte not equal to 0xFF. The number of bytes to wait for deactivation (50 by default) can be adjusted using the field mode.ffCnt in CFG-PRT for SPI, which is only necessary when messages shall be sent containing a large number of subsequent 0xFF bytes.

If the receiver has no more data to send, it sets MISO to logic high, i.e. all bytes transmitted decode to 0xFF. An efficient parser in the host will ignore all 0xFF bytes which are not part of a message and will resume data processing as soon as the first byte not equal to 0xFF is received.


8.6.3 Back-To-Back Read and Write Access

The receiver does not provide any write access except for writing UBX and NMEA messages to the receiver, such as configuration or aiding data. For every byte written to the receiver, a byte will simultaneously be read from the receiver. While the master writes to MOSI, at the same time it needs to read from MISO, as any pending data will be output by the receiver with this access. The data on MISO represents the results from a



current address read, returning 0xFF when no more data is available.

SPI Back-To-Back Read/Write Access



8.7 How to change between protocols

Reconfiguring a port from one protocol to another is a two-step process:

- Step 1: the preferred protocol(s) needs to be enabled on a port using CFG-PRT. One port can handle several protocols at the same time (e.g. NMEA and UBX). By default, all ports are configured for UBX and NMEA protocol so in most cases, it's not necessary to change the port settings at all. Port settings can be viewed and changed using the CFG-PRT messages.
- Step 2: activate certain messages on each port using CFG-MSG.

9 Multiple GNSS Assistance (MGA)

9.1 Introduction

Users would ideally like GNSS receivers to provide accurate position information the moment they are turned on. With standard GNSS receivers there can be a significant delay in providing the first position fix, principally because the receiver needs to obtain data from several satellites and the satellites transmit that data slowly. Under adverse signal conditions, data downloads from the satellites to the receiver can take minutes, hours or even fail altogether.

Assisted GNSS (A-GNSS) is a common solution to this problem and involves some form of reference network of receivers that collect data such as ephemeris, almanac, accurate time and satellite status and pass this onto to the target receiver via any suitable communications link. Such assistance data enables the receiver to compute a position within a few seconds, even under poor signal conditions.

The UBX-MGA message class provides the means for delivering assistance data to u-blox GNSS receivers and customers can obtain it from the u-blox AssistNow Online or AssistNow Offline Services. Alternatively they can obtain assistance data from third-party sources (e.g. SUPL/RRLP) and generate the appropriate UBX-MGA messages to send this data to the receiver.

9.2 Assistance Data

u-blox GNSS receivers currently accept the following types of assistance data:

- **Position:** Estimated receiver position can be submitted to the receiver using the UBX-MGA-INI-POS_XYZ or UBX-MGA-INI-POS_LLH messages.
- Time: The current time can either be supplied as an inexact value via the standard communication interfaces,



suffering from latency depending on the baud rate, or using hardware time synchronization where an accurate time pulse is connected to an external interrupt. The preferred option is to supply UTC time using the UBX-MGA-INI-TIME_UTC message, but times referenced to some GNSS can be delivered with the UBX-MGA-INI-TIME_GNSS message.


- **Clock drift:** An estimate of the clock drift can be sent to the receiver using the UBX-MGA-INI-CLKD message.
- **Frequency:** It is possible to supply hardware frequency aiding by connecting a periodic rectangular signal with a frequency up to 500 kHz and arbitrary duty cycle (low/high phase duration must not be shorter than 50 ns) to an external interrupt, and providing the applied frequency value using the UBX-MGA-INI-FREQ message.
- **Current orbit data:** Each different GNSS transmits orbit data in slightly different forms. For each system there are separate messages for delivering ephemeris and almanac. So for example GPS ephemeris is delivered to the receiver using the UBX-MGA-GPS-EPH message, while GLONASS almanac is delivered with the UBX-MGA-GLO-ALM message.
- **Predicted orbit data:** UBX-MGA-ANO messages can be used to supply predictions of future orbit information to a u-blox receiver. These messages can be obtained from the AssistNow Offline Service and allow a receiver to improve its TTFF even when it is no longer connected to the Internet.
- Auxiliary information: Each GNSS transmits some auxiliary data (such as SV health information or UTC parameters) to the receiver. A selection of messages exist for providing such information to the receiver, such as UBX-MGA-GPS-IONO for ionospheric data from GPS.
- **EOP:** Earth Orientation Parameters can be sent to the receiver using the UBX-MGA-INI-EOP message. This will replace the default model used by the AssistNow Autonomous feature and may improve performance (particularly as the receiver gets older and the built-in model decays).
- Navigation Database: u-blox receivers can be instructed to dump the current state of their internal navigation database with the UBX-MGA-DBD-POLL message; sending this information back to the receiver (e.g. after a period when the receiver was turned off) restores the database to its former state, and thus allows the receiver to restart rapidly.

9.3 AssistNow Online

AssistNow Online is u-blox' end-to-end Assisted GNSS (A-GNSS) solution for receivers that have access to the Internet. Data supplied by the AssistNow Online Service can be directly uploaded to a u-blox GNSS receiver in order to substantially reduce Time To First Fix (TTFF), even under poor signal conditions. The system works by collecting data such as ephemeris and almanac from the satellites through u-blox' Global Reference Network of GNSS receivers and providing this data to customers in a convenient form that can be forwarded on directly to u-blox receivers.

The AssistNow Online Service uses a simple, stateless, HTTP interface. Therefore, it works on all standard mobile communication networks that support Internet access, including GPRS, UMTS and Wireless LAN. No special arrangements need to be made with mobile network operators to enable AssistNow Online.





Multiple GNSS Assistance Architecture

The data returned by the AssistNow Online Service is a sequence of UBX-MGA messages, starting with an estimate of the current time in the form of a UBX-MGA-INI-TIME_UTC message.



AssistNow Online currently supports GPS, GLONASS and QZSS. u-blox intend to expand the AssistNow Online Service to support other GNSS (such as BeiDou and Galileo) in due course.

9.3.1 Host Software

As u-blox receivers have no means to connect directly with the Internet, the AssistNow Online system can only work if the host system that contains the receiver can connect to the Internet, download the data from the AssistNow Online Service and forward it on to the receiver. In the simplest case that may involve fetching the data from the AssistNow Online Service (by means of a single HTTP GET request), and sending the resulting data to the receiver.

Depending on the circumstances, it may be beneficial for the host software to include:

- Creating an appropriate UBX-MGA-INI-TIME_UTC message to deliver a better sense of time to the receiver, especially if the host system has a very good sense of the current time and can deliver a time pulse to one of the receiver's EXTINT pins.
- Enable and use flow control to prevent loss of data due to buffer overflow in the receiver.



u-blox provides the source code for an example library, called libMGA, that provides all of the functionality we expect in most host software.

9.3.2 AssistNow Online Sequence

A typical sequence of use of the AssistNow Online Service comprises the following steps:

- Power-up the GNSS receiver
- Request data from the AssistNow Online Service
- Optionally send UBX-MGA-INI-TIME_UTC followed by hardware time synchronization pulse if hardware time synchronization is required.



• Send the UBX messages obtained from the AssistNow Online Service to the receiver.

9.3.3 Flow Control

u-blox GNSS receivers aim to process incoming messages as quickly as possible, but there will always be a small delay in processing each message. Uploading assistance data to the receiver can involve sending as many as one hundred of individual messages to the receiver, one after the other. If the communication link is fast, and/or the receiver is busy (trying to acquire new signals), it is possible that the internal buffers will overflow and some messages will be lost. In order to combat this, u-blox receivers support an optional flow control mechanism for assistance.

Flow control is activated by setting the ackAiding parameter in the UBX-CFG-NAVX5 message. As a result the receiver will issue an acknowledgement message (UBX-MGA-ACK) for each assistance message it successfully receives. The host software can examine these acknowledgements to establish whether there were any problems with the data sent to the receiver and deduce (by the lack of acknowledgement) if any messages have been lost. It may then be appropriate to resend some of the assistance messages.

The simplest way to implement flow control would be to send one UBX-MGA assistance message at a time, waiting for the acknowledgement, before sending the next. However, such a strategy is likely to introduce significant delays into the whole assistance process. The best strategy will depend on the amount of assistance data being sent and the nature of the communications link (e.g. baud rate of serial link). u-blox recommends that when customers are developing their host software they start by sending all assistance messages and then analyse the resulting acknowledgements to see whether there have been significant losses. Adding small delays during the transmission may be a simple but effective way to avoid substantial loss of data.

9.3.4 Authorization

The AssistNow Online Service is only available for use by u-blox customers. In order to use the services, customers will need to obtain an authorization token from u-blox. This token must be supplied as a parameter whenever a request is made to either service.

9.3.5 Service Parameters

The information exchange with the AssistNow Online Service is based on the HTTP protocol. Upon reception of an HTTP GET request, the server will respond with the required messages in binary format or with an error string in text format. After delivery of all data, the server will terminate the connection.

The HTTP GET request from the client to the server should contain a standard HTTP query string in the request URL. The query string consists of a set of "key=value" parameters in the following form:

key=value;key=value;key=value;

The following rules apply:

- The order of keys is not important.
- Keys and values are case sensitive.
- Keys and values must be separated by an equals character ('=').
- Key/value pairs must be separated by semicolons (';').
- If a value contains a list, each item in the list must be separated by a comma (',').

The following table describes the keys that are supported.

AssistNow	Online	Parameter	Keys
-----------	--------	-----------	------

Key Name	Unit/Range	Optional	Description
token	String	Mandatory	The authorization token supplied by u-blox when a client registers to
			use the service.



AssistNow Online Parameter Keys continued

Key Name	Unit/Range	Optional	Description
gnss	String	Mandatory	A comma separated list of the GNSS for which data should be
			returned. Valid GNSS are: gps, qzss and glo.
datatype	String	Mandatory	A comma separated list of the data types required by the client. Valid
			data types are: eph, alm, aux and pos. Time data is always returned for
			each request. If the value of this parameter is an empty string, only
			time data will be returned.
lat	Numeric	Optional	Approximate user latitude in WGS 84 expressed in degrees and
	[degrees]		fractional degrees. Must be in range -90 to 90. Example: lat=47.2.
lon	Numeric	Optional	Approximate user longitude in WGS 84 expressed in degrees and
	[degrees]		fractional degrees. Must be in range -180 to 180. Example: lon=8.55.
alt	Numeric	Optional	Approximate user altitude above WGS 84 Ellipsoid. If this value is not
	[meters]		provided, the server assumes an altitude of 0 meters. Must be in range
			-1000 to 50000.
расс	Numeric	Optional	Approximate accuracy of submitted position (see position parameters
	[meters]		note below). If this value is not provided, the server assumes an
			accuracy of 300km. Must be in range 0 to 6000000.
tacc	Numeric	Optional	The timing accuracy (see time parameters note below). If this value is
	[seconds]		not provided, the server assumes an accuracy of 10 seconds. Must be
			in range 0 to 3600.
latency	Numeric	Optional	Typical latency between the time the server receives the request, and
	[seconds]		the time when the assistance data arrives at the GNSS receiver. The
			server can use this value to correct the time being transmitted to the
			client. If this value is not provided, the server assumes a latency of 0.
			Must be in range 0 to 3600.
filteronpos	(no value	Optional	If present, the ephemeris data returned to the client will only contain
	required)		data for the satellites which are likely to be visible from the
			approximate position provided by the lat, lon, alt and pacc parameters.
			If the lat and lon parameters are not provided the service will return an
			error.
filteronsv	String	Optional	A comma separated list of u-blox gnssld:svld pairs. The ephemeris data
			returned to the client will only contain data for the listed satellites.

Thus, as an example, a valid parameter string would be:

9.3.5.1 Position parameters (lat, lon, alt and pacc)

The position parameters (lat, lon, alt and pacc) are used by the server for two purposes:

- If the filteronpos parameter is provided, the server determines the currently visible satellites at the user position, and only sends the ephemeris data of those satellites which should be in view at the location of the user. This reduces bandwidth requirements. In this case the 'pacc' value is taken into account, meaning that the server will return all SVs visible in the given uncertainty region.
- If the datatype 'pos' is requested, the server will return the position and accuracy in the response data. When this data is supplied to the u-blox GNSS receiver, depending on the accuracy of the provided data, the receiver can then choose to select a better startup strategy. For example, if the position is accurate to 100km or better, the u-blox receiver will choose to go for a more optimistic startup strategy. This will result in



quicker startup time. The receiver will decide which strategy to choose, depending on the 'pacc' parameter. If the submitted user position is less accurate than what is being specified with the 'pacc' parameter, then the user will experience prolonged or even failed startups.

9.3.5.2 Time parameters (tacc and latency)

Time data is always returned with each request. The time data refers to the time at which the response leaves the server, corrected by an optional latency value. This time data provided by the service is accurate to approximately 10ms but by default the time accuracy is indicated to be +/-10 seconds in order to account for network latency and any time between the client receiving the data and it being provided to the receiver. If both the network latency and the client latency can safely be assumed to be very low (or are known), the client can choose to set the accuracy of the time message (tacc) to a much smaller value (e.g. 0.5s). This will result in a faster TTFF. The latency can also be adjusted as appropriate. However, these fields should be used with caution: if the time accuracy is not correct when the time data reaches the receiver, the receiver may experience prolonged or even failed start-ups.

For optimal results, the client should establish an accurate sense of time itself (e.g. by calibrating its system clock using a local NTP service) and then modify the time data received from the service as appropriate.

9.3.6 Multiple Servers

u-blox has designed and implemented the AssistNow Online Service in a way that should provide very high reliability. Nonetheless, there will be rare occasions when a server is not available (e.g. due to failure or some form of maintenance activity). In order to protect customers against the impact of such outages, u-blox will run at least two instances of the AssistNow Online Service on independent machines. Customers will have a free choice of requesting assistance data from any of these servers, as all will provide the same information. However, should one fail for whatever reason, it is highly unlikely that the other server(s) will also be unavailable. Therefore customers requiring the best possible availability are recommended to implement a scheme where they direct their requests to a chosen server, but, if that server fails to respond, have a fall-back mechanism to use another server instead.

9.4 AssistNow Offline

AssistNow Offline is a feature that combines special firmware in u-blox GNSS receivers and a proprietary service run by u-blox. It is targetted at receivers that only have occasional Internet access and so can't use AssistNow Online. AssistNow Offline speeds up Time To First Fix (TTFF), typically to considerably less than 10s



AssistNow Offline currently supports GPS and GLONASS. u-blox intend to expand the AssistNow Offline Service to support other GNSS (such as BeiDou and Galileo) in due course.

The AssistNow Offline Service uses a simple, stateless, HTTP interface. Therefore, it works on all standard mobile communication networks that support Internet access, including GPRS, UMTS and Wireless LAN. No special arrangements need to be made with mobile network operators to enable AssistNow Offline.

Users of AssistNow Offline are expected to download data from the AssistNow Offline Service, specifying the time period they want covered (1 to 5 weeks) and the types of GNSS. This data must be uploaded to a u-blox receiver, so that it can estimate the positions of the satellites, when no better data is available. Using these estimates will not provide as accurate a position fix as if current ephemeris data is used, but it will allow much faster TTFFs in nearly all cases.

The data obtained from the AssistNow Offline Service is organised by date, normally a day at a time. Consequently the more weeks for which coverage is requested, the larger the amount of data to handle. Similarly, each different GNSS requires its own data and in the extreme cases, several hundred kilobytes of data will be provided by the service. This amount can be reduced by requesting lower resolution, but this will have a



small negative impact on both position accuracy and TTFF. See the section on Offline Service Parameters for details of how to specify these options.

The downloaded Offline data is encoded in a sequence of UBX-MGA-ANO messages, one for every SV for every day of the period covered. Thus, for example, data for all GPS SVs for 4 weeks will involve in excess of 900 separate messages, taking up around 70kbytes. Where a u-blox receiver has flash storage, all the data can be directly uploaded to be stored in the flash until it is needed. In this case, the receiver will automatically select the most appropriate data to use at any time. See the section on flash-based AssistNow Offline for further details.

AssistNow Offline can also be used where the receiver has no flash storage, or there is insufficient spare flash memory. In this case the customer's system must store the AssistNow Offline data until the receiver needs it and then upload only the appropriate part for immediate use. See the section on host-based AssistNow Offline for further details.

9.4.1 Service Parameters

The information exchange with the AssistNow Offline Service is based on the HTTP protocol. Upon reception of an HTTP GET request, the server will respond with the required messages in binary format or with an error string in text format. After delivery of all data, the server will terminate the connection.

The HTTP GET request from the client to the server should contain a standard HTTP querystring in the request URL. The querystring consists of a set of "key=value" parameters in the following form:

key=value;key=value;key=value;

The following rules apply:

- The order of keys is not important.
- Keys and values are case sensitive.
- Keys and values must be separated by an equals character ('=').
- Key/value pairs must be separated by semicolons (';').
- If a value contains a list, each item in the list must be separated by a comma (',').

The following table describes the keys that are supported.

Key Name	Unit/Range	Optional	Description
token	String	Mandatory	The authorization token supplied by u-blox when a client registers to
			use the service.
gnss	String	Mandatory	A comma separated list of the GNSS for which data should be
			returned. The currently supported GNSS are: gps and glo.
period	Numeric	Optional	The number of weeks into the future the data should be valid for. Data
	[weeks]		can be requested for up to 5 weeks in to the future. If this value is not
			provided, the server assumes a period of 4 weeks.
resolution	Numeric	Optional	The resolution of the data: 1=every day, 2=every other day, 3=every
	[days]		third day. If this value is not provided, the server assumes a resolution
			of 1 day.

AssistNow Offline Parameter Keys

Thus, as an example, a valid parameter string would be:

token=XXXXXXXXXXXXXXXXXXXXXXXXXXXX;gnss=gps,glo;



9.4.2 Authorization

The AssistNow Offline Service uses the same authorization process as AssistNow Online; see above for details.

9.4.3 Multiple Servers

The AssistNow Offline Service uses the same multiple server mechanism to provide high availability as AssistNow Online; see above for details.

9.4.4 Time, Position and Almanac

While AssistNow Offline can be used on its own, it is expected that the user will provide estimates of the receiver's current position, the current time and ensure that a reasonably up to date almanac is available. In most cases this information is likely to be available without the user needing to do anything. For example, where the receiver is connected to a battery backup power supply and has a functioning real time clock (RTC), the receiver will keep its own sense of time and will retain the last known position and any almanac. However, should the receiver be completely unpowered before startup, then it will greatly improve TTFF if time, position and almanac can be supplied in some form.

Almanac data has a validity period of several weeks, so can be downloaded from the AssistNow Online service at roughly the same time the Offline data is obtained. It can then be stored in the host for uploading on receiver startup, or it can be transferred to the receiver straight away and preserved there (provided suitable non-voltaile storage is available).

Obviously, where a receiver has a functioning RTC, it should be able to keep its own sense of time, but where no RTC is fitted (or power is completely turned off), providing a time estimate via the UBX-MGA-INI-TIME_UTC message will be beneficial.

Similarly, where a receiver has effective non-volatile storage, the last known position will be recalled, but if this is not the case, then it will help TTFF to provide a position estimate via one of the UBX-MGA-INI-POS_XYZ or UBX-MGA-INI-POS_LLH messages.

Where circumstance prevent the provision of all three of these pieces of data, providing some is likely to be better than none at all.

9.4.5 Flash-based AssistNow Offline

Flash-based AssistNow Offline functionality means that AssistNow Offline data is stored in the flash memory connected to the chip.

The user's host system must download the data from the AssistNow Offline service when an Internet connection is available, and then deliver all of that data to the GNSS receiver. As the total amount of data to be uploaded is large (typically around 100 kbytes) and writing to flash memory is slow, the upload must be done in blocks of up to 512 bytes, one at a time. The UBX-MGA-FLASH-DATA message is used to transmit each block to the receiver.



AssistNow Offline data stored in flash memory is not affected by any reset of the receiver. The only simple ways to clear it are to completely erase the whole flash memory or to overwrite it with a new set of AssistNow Offline data. Uploading a dummy block of data (e.g. all zeros) will also have the effect of deleting the data, although a small amount of flash storage will be used.

9.4.5.1 Flash-based Storage Procedure

The following steps are a typical sequence for transferring AssistNow Offline data into the receiver's flash memory:

• The host downloads a copy of a latest data from the AssistNow Offline service and stores it locally.



- It sends the first 512 bytes of that data using the UBX-MGA-FLASH-DATA message.
- It awaits a UBX-MGA-FLASH-ACK message in reply.
- Based on the contents of the UBX-MGA-FLASH-ACK message it, sends the next block, resends the last block or aborts the whole process.
- The above three steps are repeated until all the rest of the data has been successfully transferred (or the process has been aborted).
- The host sends an UBX-MGA-FLASH-STOP message to indicate completion of the upload.
- It awaits the final UBX-MGA-FLASH-ACK message in reply. Background processing in the receiver prepares the downloaded data for use at this stage. Particularly if the receiver is currently busy, this maye take quite a few seconds, so the host has to be prepared for a delay before the UBX-MGA-FLASH-ACK is seen.

Note that the final block may be smaller than 512 bytes (where the total data size is not perfectly divisible by 512). Also, the UBX-MGA-FLASH-ACK messages are distinct from the UBX-MGA-ACK messages used for other AssistNow functions.

Any existing data will be deleted as soon as the first block of new data arrives, so no useful data will be available till the completion of the data transfer. Each block of data has a sequence number, starting at zero for the first block. In order to guard against invalid partial data downloads the receiver will not accept blocks which are out of sequence.

9.4.6 Host-based AssistNow Offline

Host-based AssistNow Offline involves AssistNow Offline data being stored until it is needed by the user's host system in whatever memory it has available.

The user's host system must download the data from the AssistNow Offline service when an Internet connection is available, but retain it until the time the u-blox receiver needs it. At this point, the host must upload just the relevant portion of the data to the receiver, so that the receiver can start using it. This is achieved by parsing all the data and selecting for upload to the receiver only those UBX-MGA-ANO messages with a date-stamp nearest the current time. As each is a complete UBX message it can be sent directly to the receiver with no extra packaging. If required the user can select to employ flow control, but in most cases this is likely to prove unnecessary.

When parsing the data obtained from the AssistNow Offline service the following points should be noted:

- The data is made up of a sequence of UBX-MGA-ANO messages
- Customers should not rely on the messages all being a fixed sized, but should read their length from the UBX header to work out where the message ends (and where the next begins).
- Each message indicates the SV for which it is applicable through the svld and gnssld fields.
- Each message contains a date-stamp within the year, month and day fields.
- Midday (UTC) on the day indicated should be considered to be the point at which the data is most applicable.
- The messages will be ordered chronologically, earliest first.
- Messages with same date-stamp will be ordered by ascending gnssld and then ascending svld.

9.4.6.1 Host-based Procedure

The following steps are a typical sequence for host-based AssistNow Offline:

- The host downloads a copy of a latest data from the AssistNow Offline service and stores it locally.
- Optionally it may also download a current set of almanac data from the AssistNow Online service.



- It waits until it want to use the GNSS receiver.
- If necessary it uploads any almanac, position estimate and/or time estimate to the receiver.
- It scans through AssistNow Offline data looking for entries with a date-stamp that most closely matches the current (UTC) time/date.
- It sends each such UBX-MGA-ANO message to the receiver.

Note that when data has been downloaded from the AssistNow Offline service with the (default) resolution of one day, the means for selecting the closest matching date-stamp is simply to look for ones with the current (UTC) date.

9.5 Preserving Information During Power-off

The performance of u-blox receivers immediately after they are turnned on is enhanced by providing them with as much useful information as possible. Assistance (both Online and Offline) is one way to achieve this, but retaining information from previous use of the receiver can be just as valuable. All the types of data delivered by assistance can be retained while the receiver is powered down for use when power is restored. Obviously the value of this data will diminish as time passes, but in many cases it remains very useful and can significantly improve time to first fix.

The are several ways in which a u-blox receiver can retain useful data while it is powered down, including:

- **Battery Backed RAM:** The receiver can be supplied with sufficient power to maintain a small portion of internal storage, while it is otherwise turned off. This is the best mechanism, provided that the small amount of electrical power required can be supplied continuously.
- Save on Shutdown: The receiver can be instructed to dump its current state to the attached flash memory (where fitted) as part of the shutdown procedure; this data is then automatically retrieved when the receiver is restarted. See the description of the UBX-UPD-SOS messages for more information.
- **Database Dump:** The receiver can be asked to dump the state of its internal database in the form of a sequence of UBX messages reported to the host; these messages can be stored by the host and then sent back to the receiver when it has been restarted. See the description of the UBX-MGA-DBD messages for more information.

9.6 AssistNow Autonomous

9.6.1 Introduction

The assistance scenarios covered by *AssistNow Online* and *AssistNow Offline* require an online connection and a host that can use this connection to download aiding data and provide this to the receiver when required. The *AssistNow Autonomous* feature provides a functionality similar to *AssistNow Offline* without the need for a host and a connection. Based on a broadcast ephemeris downloaded from the satellite (or obtained by *AssistNow Online*) the receiver can autonomously (i.e. without any host interaction or online connection) generate an accurate satellite orbit representation («AssistNow Autonomous data») that is usable for navigation much longer than the underlying broadcast ephemeris was intended for. This makes downloading new ephemeris or aiding data for the first fix unnecessary for subsequent start-ups of the receiver.



The AssistNow Autonomous feature is disabled by default. It can be enabled using the UBX-CFG-NAVX5 message.




9.6.2 Concept

The figure below illustrates the *AssistNow Autonomous* concept in a graphical way. Note that the figure is a qualitative illustration and is not to scale.

- A broadcast ephemeris downloaded from the satellite is a precise representation of a part (for GPS nominally four hours) of the satellite's true orbit (trajectory). It is not usable for positioning beyond this validity period because it diverges dramatically from the true orbit afterwards.
- The *AssistNow Autonomous orbit* is an extension of one or more broadcast ephemerides. It provides a long-term orbit for the satellite for several revolutions. Although this orbit is not perfectly precise it is a sufficiently accurate representation of the true orbit to be used for navigation.
- The AssistNow Autonomous data is automatically and autonomously generated from downloaded (or assisted) ephemerides. The data is stored automatically in the on-chip battery-backed memory (BBR).
 Optionally, the data can be backed-up in external flash memory or on the host. The number of satellites for which data can be stored depends on the receiver configuration and may change during operation.
- If no broadcast ephemeris is available for navigation *AssistNow Autonomous* automatically generates the required parts of the orbits suitable for navigation from the stored data. The data is also automatically kept current in order to minimize the calculation time once the navigation engine needs orbits.
- The operation of the *AssistNow Autonomous* feature is transparent to the user and the operation of the receiver. All calculations are done in background and do not affect the normal operation of the receiver.
- The *AssistNow Autonomous* subsystem automatically invalidates data that has become too old and that would introduce unacceptable positioning errors. This threshold is configurable (see below).
- The prediction quality will be automatically improved if the satellite has been observed multiple times. However, this requires the availability of a suitable flash memory (see the *Hardware Integration Manual* for a list of supported devices). Improved prediction quality also positively affects the maximum usability period of the data.
- AssistNow Autonomous considers GPS and GLONASS satellites only. For GLONASS support a suitable flash memory is mandatory because a single broadcast ephemeris spans to little of the orbit (only approx. 30 minutes) in order to extend it in a usable way. Only multiple observations of the same GLONASS satellite that span at least four hours will be used to generate data.





9.6.3 Interface

Several UBX protocol messages provide interfaces to the *AssistNow Autonomous* feature. They are:

- The UBX-CFG-NAVX5 message is used to enable or disable the AssistNow Autonomous feature. It is disabled by default. Once enabled, the receiver will automatically produce AssistNow Autonomous data for newly received broadcast ephemerides and, if that data is available, automatically provide the navigation subsystem with orbits when necessary and adequate. The message also allows for a configuration of the maximum acceptable orbit error. See the next section for an explanation of this feature. It is recommended to use the firmware default value that corresponds to a default orbit data validity of approximately three days (for GPS satellites observed once) and up to six days (for GPS and GLONASS satellites observed multiple times over a period of at least half a day).
- Note that disabling the *AssistNow Autonomous* feature will delete all previously collected satellite observation data from the flash memory.
- The UBX-NAV-AOPSTATUS message provides information on the current state of the AssistNow Autonomous subsystem. The status indicates whether the AssistNow Autonomous subsystem is currently idle (or not enabled) or busy generating data or orbits. Hosts should monitor this information and only power-off the receiver when the subsystem is idle (that is, when the status field shows a steady zero).
- The UBX-NAV-SAT message indicates the use of AssistNow Autonomous orbits for individual satellites.
- The UBX-NAV-ORB message indicates the availability of *AssistNow Autonomous* orbits for individual satellites.
- The UBX-MGA-DBD message provides a means to retrieve the AssistNow Autonomous data from the receiver



in order to preserve the data in power-off mode where no battery backup is available. Note that the receiver requires the absolute time (i.e. full date and time) to calculate *AssistNow Autonomous* orbits. For best performance it is, therefore, recommended to supply this information to the receiver using the UBX-MGA-INI-TIME_UTC message in this scenario.

9.6.4 Benefits and Drawbacks

AssistNow Autonomous can provide quicker start-up times (lower the TTFF) provided that data is available for enough visible satellites. This is particularly true under weak signal conditions where it might not be possible to download broadcast ephemerides at all, and, therefore, no fix at all would be possible without AssistNow Autonomous (or A-GNSS). It is, however, required that the receiver roughly know the absolute time, either from an RTC or from time-aiding (see the Interface section above), and that it knows which satellites are visible, either from the almanac or from tracking the respective signals.

The *AssistNow Autonomous* orbit (satellite position) accuracy depends on various factors, such as the particular type of satellite, the accuracy of the underlying broadcast ephemeris, or the orbital phase of the satellite and Earth, and the age of the data (errors add up over time).

AssistNow Autonomous will typically extend a broadcast ephemeris for up to three to six days. The UBX-CFG-NAVX5 (see above) message allows changing this threshold by setting the «maximum acceptable modelled orbit error» (in meters). Note that this number does not reflect the true orbit error introduced by extending the ephemeris. It is a statistical value that represents a certain expected upper limit based on a number of parameters. A rough approximation that relates the maximum extension time to this setting is: maxError [m] = maxAge [d] * f, where the factor f is 30 for data derived from satellites seen once and and 16 for data derived for satellites seen multiple time during a long enough time period (see the *Concept* section above).

There is no direct relation between (true and statistical) orbit accuracy and positioning accuracy. The positioning accuracy depends on various factors, such as the satellite position accuracy, the number of visible satellites, and the geometry (DOP) of the visible satellites. Position fixes that include *AssistNow Autonomous* orbit information may be significantly worse than fixes using only broadcast ephemerides. It might be necessary to adjust the limits of the Navigation Output Filters.

A fundamental deficiency of any system to predict satellite orbits precisely is unknown future events. Hence, the receiver will not be able to know about satellites that will have become unhealthy, have undergone a clock swap, or have had a manoeuvre. This means that the navigation engine might rarely mistake a wrong satellite position as the true satellite position. However, provided that there are enough other good satellites, the navigation algorithms will eventually eliminate a defective orbit from the navigation solution.

The repeatability of the satellite constellation is a potential pitfall for the use of the *AssistNow Autonomous* feature. For a given location on Earth the (GPS) constellation (geometry of visible satellites) repeats every 24 hours. Hence, when the receiver «learned» about a number of satellites at some point in time the same satellites will in most places *not* be visible 12 hours later, and the available *AssistNow Autonomous* data will not be of any help. Again 12 hours later, however, usable data would be available because it had been generated 24 hours ago.

The longer a receiver observes the sky the more satellites it will have seen. At the equator, and with full sky view, approximately ten (GPS) satellites will show up in a one hour window. After four hours of observation approx. 16 satellites (i.e. half the constellation), after 10 hours approx. 24 satellites (2/3rd of the constellation), and after approx. 16 hours the full constellation will have been observed (and *AssistNow Autonomous* data generated for). Lower sky visibility reduces these figures. Further away from the equator the numbers improve because the satellites can be seen twice a day. E.g. at 47 degrees north the full constellation can be observed in approx. 12 hours with full sky view.



The calculations required for *AssistNow Autonomous* are carried out on the receiver. This requires energy and users may therefore occasionally see increased power consumption during short periods (several seconds, rarely more than 60 seconds) when such calculations are running. Ongoing calculations will automatically prevent the power save mode from entering the power-off state. The power-down will be delayed until all calculations are done.



The AssistNow Offline and AssistNow Autonomous features are exclusive and should not be used at the same time. Every satellite will be ignored by AssistNow Autonomous if there is AssistNow Offline data available for it.

10 Power Management


u-blox receivers support different power modes. These modes represent strategies of how to control the acquisition and tracking engines in order to achieve either the best possible performance or good performance with reduced power consumption.

Receiver power management can split into two categories:

- Externally Controlled Power Management: This includes various modes of power management that are directly operated by the user or host device. These modes are: 1. External cycling of the receiver main power supply. 2. Instruct the receiver to turn On/Off via the UBX-RXM-PMREQ message. 3. Instruct the receiver to turn On/Off via external pins (EXTINT0 or EXTINT1)
- Internally Controlled Power Management: Here the receiver makes the decision when to power down/up some/all of its internal components according to predefined parameters. It is also referred to as Power Save Modes (PSM). It has two modes of operations: 1. ON/OFF Operation (PSMOO) 2. Cyclic Tracking (PSMCT).

The following figure illustrates u-blox power management modes.

u-blox Power Management



The majority of the Power Management section is detailing the Power Save Mode (Internally Controlled Power Management). However, some the concepts relevant to the Externally Controlled Power Management are detailed, such as the EXTINT Control, Wake-up and Power On/Off Command.

Externally controlled power management operations can be used on top of the Internally Controlled Power Management and they do override their operation.

Power Save Mode is selected using the message UBX-CFG-RXM and configured using UBX-CFG-PM2.



10.1 Continuous Mode

u-blox GNSS receivers make use of dedicated signal processing engines optimized for signal acquisition and tracking. The acquisition engine delivers rapid signal searches during cold starts or when insufficient signals are available for navigation. The tracking engine delivers signal measurements for navigation and acquires new signals as they become available during navigation. The resources of both engines are deployed adaptively to minimize overall power consumption.

Note that even if the acquisition engine is powered off, satellites continue to be acquired.

10.2 Power Save Mode

Power Save Mode (PSM) allows a reduction in system power consumption by selectively switching parts of the receiver on and off.



Note: Power Save Mode can only be selected with GPS signals.

Note: Power Save Mode is not supported in conjunction with the ADR or FTS product variants.

10.2.1 Operation

Power Save Mode has two modes of operation:

- *Power Save Mode Cyclic Tracking (PSMCT) Operation* is used when position fixes are required in short periods of 1 to 10s
- *Power Save Mode ON/OFF (PSMOO) Operation* is used for periods longer than 10s, and can be in the order of minutes, hours or days.

The mode of operation can be configured, and depending on the setting, the receiver demonstrates different behavior: In ON/OFF operation the receiver switches between phases of start-up/navigation and phases with low or almost no system activity (backup/sleep). In cyclic tracking the receiver does not shut down completely between fixes, but uses low power tracking instead.

Currently PSMCT is restricted to update period between 1 and 10 seconds and PSMOO is restricted to update period over 10 seconds. However, this may change in future firmware releases.


PSM is based on a state machine with five different states: (Inactive) Awaiting Next Fix and (Inactive) Awaiting Next Search states, Acquisition state, Tracking state and Power Optimized Tracking (POT) state.

- Inactive states: Most parts of the receiver are switched off.
- Acquisition state: The receiver actively searches for and acquires signals. Maximum power consumption.
- *Tracking* state: The receiver continuously tracks and downloads data. Less power consumption than in *Acquisition* state.
- *POT* state: The receiver repeatedly loops through a sequence of tracking (Track), calculating the position fix (Fix), and entering an idle period (Idle). No new signals are acquired and no data is downloaded. Much less power consumption than in *Tracking* state.

The following figure illustrates the PSM state machine:



State machine



10.2.1.1 Acquisition Timeout Logic

The receiver has internal, external and user configurable mechanisms that determine the time to be spent in acquisition state. This logic is put in place to ensure good performance and low power consumption in different environments and scenarios. This collective logic is referred to as Acquisition Timeout.

Internal mechanisms:

- If the receiver is able to acquire weak signals but not of the quality needed to get a fix, it will transition to *(Inactive) Awaiting Next Search* state after the timeout configured in *maxStartupStateDur* or earlier if too few signals are acquired.
- If the receiver is unable to acquire any signals or it acquires a small number of extremely bad signals (e.g., no sky view), it will transition to *(Inactive) Awaiting Next search* state after 15 seconds or the timeout configured in maxStartupStateDur if shorter.

User configurable mechanisms:

- *minAcqTime* is the minimum time that the receiver will spend in *Acquisition* state (see minAcqTime for details.)
- *maxStartupStateDur* is the maximum time that the receiver will spend in *Acquisition* state (see maxStartupStateDur for details).



• *doNotEnterOff* forces the receiver to stay awake and in *Acquisition* state even when a fix is not possible (see doNotEnterOff for details).

External mechanisms:

• The receiver will be forced to stay awake if *extintWake* is enabled and the configured EXTINT pin is set to "high" and it will be forced to stay in *(Inactive) Awaiting Next Search/Fix* states if *extintBackup* is enabled and the configured EXTINT pin is set to "low" (see EXTINT pin control for details).

10.2.1.2 ON/OFF operation - long update period

When the receiver is switched on, it first enters *Acquisition* state. If it is able to obtain a valid position fix within the time given by the Acquisition Timeout, it switches to *Tracking* state. Otherwise it enters *(Inactive)* Awaiting Next Search state and re-starts after the configured search period (minus a start-up margin). As soon as the receiver gets a valid position fix (one passing the navigation output filters), it enters *Tracking* state. Upon entering *Tracking* state, the onTime starts. Once the onTime is over, *(Inactive)* Awaiting Next Fix state is entered and the receiver re-starts according to the configured update grid (see section Grid offset for an explanation). If the signal is lost while in *Tracking* state, *Acquisition* state is entered. If the signal is not found within the acquisition timeout, the receiver enters *(Inactive)* Awaiting Next Search state. Otherwise the receiver will re-enter *Tracking* state and stay there until the newly started onTime is over.

The diagram below illustrates how ON/OFF operation works:




Diagram of ON/OFF operation


10.2.1.3 Cyclic tracking operation - short update period

When the receiver is switched on, it first enters *Acquisition* state. If it is able to obtain a position fix within the time given by the acquisition timeout, it switches to *Tracking* state. Otherwise, it will enter *(Inactive) Awaiting Next Search* state and re-start within the configured search grid. After a valid position fix, *Tracking* state is entered and the *onTime* starts. In other words the *onTime* starts with the first valid position fix. Once the *onTime* is over, *POT* state is entered. In *POT* state the receiver continues to output position fixes according to the updatePeriod. To have maximum power savings, set the *onTime* to zero. This causes the receiver to enter *POT* state as soon as possible. If the signal becomes weak or is lost during *POT* state, *Tracking* state. If the receiver can't get a position fix in the *Tracking* state, it enters *Acquisition* state. Should the acquisition fail as well, *(Inactive) Awaiting Next Search* state until a fix is possible and it will never enter *(Inactive) Awaiting Next Search* state.

The diagram below illustrates how cyclic tracking operation works:



Diagram of cyclic tracking operation



10.2.1.4 User controlled operation - update and search period of zero

Setting the updatePeriod to zero causes the receiver to wait in the *(Inactive) Awaiting Next Fix* state until woken up by the user. Setting the search period to zero causes the receiver to wait in the *(Inactive) Awaiting Next Search* state indefinitely after an unsuccessful start-up. Any wake-up event will re-start the receiver. See section Wake-up for more information on wake-up events.



External wake-up is required when setting update or search period to zero.

10.2.1.5 Satellite data download

The receiver is not able to download satellite data (e.g. the ephemeris) while it is working in ON/OFF or cyclic tracking operation. Therefore it has to temporarily switch to continuous operation for the time the satellites transmit the desired data. To save power the receiver schedules the downloads according to an internal timetable and only switches to continuous operation while data of interest is being transmitted by the satellites.

Each SV transmits its own ephemeris data. Ephemeris data download is feasible when the corresponding satellite has been tracked with a sufficient C/No over a certain period of time. The download is scheduled in a 30 minute grid or immediately when fewer than a certain number of visible satellites have valid ephemeris data.

Almanac, ionosphere, UTC correction and SV health data are transmitted by all SVs simultaneously. Therefore these parameters can be downloaded when a single SV is tracked with a high enough C/No.

10.2.2 Configuration

Power Save Mode is enabled and disabled with the UBX-CFG-RXM message and configured with the UBX-CFG-PM2 message.



When enabling Power Save Mode, SBAS support can be disabled (UBX-CFG-SBAS) since the receiver will be unable to download any SBAS data in this mode.

A number of parameters can be used to customize PSM to your specific needs. These parameters are listed in the following table:

Parameter	Description
mode	Receiver mode of operation
updatePeriod	Time between two position fix attempts
searchPeriod	Time between two acquisition attempts if the receiver is unable to get a position fix
minAcqTime	Minimum time the receiver spends in Acquisition state
onTime	Time the receiver remains in Tracking state and produces position fixes
waitTimeFix	Wait for time fix before entering Tracking state

Power Save Mode configuration options on UBX-CFG-PM2





Parameter	Description
doNotEnterOff	Receiver does not enter (Inactive) Awaiting Next Search state if it can't get a position
	fix but keeps indefinitely attempting a position fix instead
updateRTC	Enables periodic Real Time Clock (RTC) update
updateEPH	Enables periodic ephemeris update
extintSelect	Selects EXTINT pin used with pin control feature
extintWake	Enables force-ON pin control feature
extintBackup	Enables force-OFF pin control feature
gridOffset	Time offset of update grid with respect to GPS start of week
maxStartupStateDur	Maximum time in Acquisition state

Power Save Mode configuration options on UBX-CFG-PM2 continued

10.2.2.1 Mode of operation (mode)

The mode of operation to use mainly depends on the update period: For short update periods (in the range of a few seconds), cyclic tracking should be configured. For long update periods (in the range of minutes or longer), only use ON/OFF operation.

See section ON/OFF operation - long update period and Cyclic tracking operation - short update period for more information on the two modes of operation.

10.2.2.2 Update period (updatePeriod) and search period (searchPeriod)

The update period specifies the time between successive position fixes. If no position fix can be obtained within the acquisition timeout, the receiver will retry after the time specified by the search period. Update and search periods are fixed with respect to an absolute time grid based on GPS time. They do not refer to the time of the last valid position fix or last position fix attempt.



New settings are ignored if the update period or the search period exceeds the maximum number of milliseconds in a week. In that case the previously stored values remain effective.

10.2.2.3 Minimum Acquisition Time (minAcqTime)

The receiver tries to obtain a position fix for at least the time given in minAcqTime. If the receiver determines that it needs more time for the given starting conditions then it will automatically prolong this time. If minAcqTime is set to zero then the minimum acquisition time is exclusively determined by the receiver. Once the minAcqTime has expired, the receiver will terminate the acquisition state if either a fix is achieved or if the receiver estimates that any signals received are insufficient (too weak or too few) for a fix to be possible.

10.2.2.4 On time (onTime)

The *onTime* parameter specifies how long the receiver stays in *Tracking* state before switching to the *POT* state (in PSMCT) or *(Inactive) Awaiting Next Fix* state (in PSMOO).

10.2.2.5 Wait for time fix (waitTimeFix)

A time fix is a fix type in which the receiver will ensure that the GPS time is accurate and confirmed to within the limits set in UBX-CFG-NAV5. Enabling the *waitTimeFix* option will force the receiver to stay in *Acquisition* state until the GPS time is known to within the configured limits then it will transition to *Tracking* state. Enabling *waitTimeFix* will delay the transition from *Acquisition* state to *Tracking* state by at least two extra seconds, thus, this should be taken into account (see Acquisition Timeout). It is necessary to enable *waitTimeFix* in timing products.

The quality of the position fixes can also be configured by setting the limits in the message UBX-CFG-NAV5.



Setting harder limits in UBX-CFG-NAV5 will typically prolong the time in *Acquisition* state. Thus, ensuring sufficient time is given to the receiver at start-up (when externally controlled) is necessary (see Acquisition Timeout Logic). When internally controlled, the receiver can make good judgement on the time needed in *Acquisition* state and no further adjustments will be needed.

10.2.2.6 Maximum Startup State Duration (maxStartupStateDur)

(only supported in protocol versions 17+).

The *maxStartupStateDur* is the maximum time that the receiver will spend in *Startup* state (i.e., *Acquisition* state). If the receiver is unable to acquire a valid position fix within this maximum time, it will transition to *(Inactive) Awaiting Next Search* state (if *doNotEnterOff* is disabled). Subsequently, the receiver will attempt to acquire another position fix according to the search period (see Update period (updatePeriod) and search period (searchPeriod)). If *maxStartupStateDur* is set to zero, the receiver will autonomously determine the maximum time to spend in *Acquisition* state. Note that shorter settings (below about 45s) will degrade an unaided receiver's ability to collect new Ephemeris data at low signal levels (see section Satellite data download).

10.2.2.7 Do not enter '(Inactive) Awaiting Next Search' state when no fix (doNotEnterOff)

If this option is enabled, the receiver acts differently in case it can't get a fix: instead of entering *(Inactive) Awaiting Next Search* state, it keeps attempting to acquire a position fix. In other words, the receiver will never be in *(Inactive) Awaiting Next Search* state and therefore searchPeriod and minAcqTime will be ignored.

10.2.2.8 Update RTC (updateRTC) and Ephemeris (updateEPH)

To maintain the ability of a fast start-up, the receiver needs to calibrate its RTC and update its ephemeris data on a regular basis. This can be ensured by activating the update RTC and update Ephemeris option. The RTC is calibrated every 5 minutes and the ephemeris data is updated approximately every 30 minutes. See section Satellite data download for more information.

10.2.2.9 EXTINT pin control

The operation of PSM can be externally controlled using either EXTINTO or EXTINT1 pin. This external control allows the user to decide when to wake up the receiver to obtain a fix and when to force the receiver into sleep/backup mode to save power. Operating the receiver externally through the EXTINT pins will override internal functions that coincide with that specific operation.

The choice of which pin to use can be configured through the extintSelect feature in UBX-CFG-PM2. Only one pin can be selected at a time but it is sufficient to perform all the required tasks.

If the Force-ON (*extintWake*) feature in UBX-CFG-PM2 is enabled, the receiver will not enter Inactive states for as long as the configured EXTINT pin (EXTINTO or EXTINT1) is at 'high' level. The receiver will therefore always be in *Acquisition/Tracking* state in PSMOO or in *Acquisition/Tracking/POT* state in PSMCT. When the pin level changes to 'low' the receiver will continue with its configured behavior.

If the Force-OFF (*extintBackup*) feature in UBX-CFG-PM2 is enabled, the receiver will enter Inactive states for as long as the configured EXTINT pin is set to 'low' until the next wake up event. Any wake up event can wake up the receiver even while the EXTINT pin is set to 'low' (see Wake-up). However, if the pin stay at 'low' state, the receiver will only wake up for the time needed to read the configuration pin settings then it will enter the Inactive state again.

If both Force-ON and Force-OFF features are enabled at the same time, the receiver PSM operation will be completely in user control. Setting 'high' on the configured EXTINT pin will wake up the receiver to get a position fix and setting 'low' will put the receiver into sleep/backup mode.



10.2.2.10 Grid offset (gridOffset)

Once the receiver has a valid time, the update grid is aligned to the start of the GPS week (Sunday at 00:00 o'clock). Before having a valid time, the update grid is unaligned. A grid offset now shifts the update grid with respect to the start of the GPS week. An example of usage can be found in section Use grid offset.



The grid offset is not used in cyclic tracking operation.

10.2.3 Features

10.2.3.1 Communication

When PSM is enabled, communication with the receiver (e.g. UBX message to disable PSM) requires particular attention. This is because the receiver may be in *Inactive* state and therefore unable to receive any message through its interfaces. To ensure that the configuration messages are processed by the receiver, even while in *Inactive* state, the following steps need to be taken:

- Send a dummy sequence of 0xFF (one byte is sufficient) to the receiver's UART interface. This will wake up the receiver if it is in *Inactive* state. If the receiver is not in *Inactive* state, the sequence will be ignored.
- Send the configuration message about half a second after the dummy sequence. If the interval between the dummy sequence and the configuration message is too short, the receiver may not yet be ready. If the interval is too long, the receiver may return to *Inactive* state before the configuration message was received. It is therefore important to check for a UBX-ACK-ACK reply from the receiver to confirm that the configuration message was received.
- Send the configuration save message immediately after the configuration message.

Similarly, when configuring the receiver for PSMOO (and PSMCT when doNotEnterOff is disabled), ensure that the configurations are saved. If they are not saved the receiver will enter backup mode and when it wakes up again, it would have lost the configurations and even forgets it was in power save mode. This can be avoided by using the UBX-CFG-CFG message (see Receiver Configuration for details). When operating PSM from u-Center and setting the receiver to Power Save Mode in UBX-CFG-RXM, check the save configuration box. u-Center will then send a UBX-CFG-CFG message after the UBX-CFG-RXM to save the configurations.

10.2.3.2 Wake-up

The receiver can be woken up by generating an edge on one of the following pins:

- rising or falling edge on one of the EXTINT pins
- rising or falling edge on the RXD1 pin
- rising edge on NRESET pin

All wake-up signals are interpreted as a position request, where the receiver wakes up and tries to obtain a position fix. Wake-up signals have no effect if the receiver is already in *Acquisition*, *Tracking* or *POT* state.

10.2.3.3 Behavior while USB host connected

As long as the receiver is connected to a USB host, it will not enter the lowest possible power state. This is because it must retain a small level of CPU activity to avoid breaching requirements of the USB specification. The drawback, however, is that power consumption is higher.



Wake-up by pin/UART is possible even if the receiver is connected to a USB host. In this case the state of the pin must be changed for a duration longer than one millisecond.



10.2.3.4 Cooperation with the AssistNow Autonomous feature

If both PSM and AssistNow Autonomous features are enabled, the receiver won't enter (*Inactive*) Awaiting Next Fix state as long as AssistNow Autonomous carries out calculations. This prevents losing data from unfinished calculations and, in the end, reduces the total extra power needed for AssistNow Autonomous. The delay before entering (*Inactive*) Awaiting Next Fix state, if any, will be in the range of several seconds, rarely more than 20 seconds.

Only entering *(Inactive)* Awaiting Next Fix state is affected by AssistNow Autonomous. In other words: in cyclic tracking operation, AssistNow Autonomous will not interfere with the PSM (apart from the increased power consumption).



Enabling the AssistNow Autonomous feature will lead to increased power consumption while prediction is calculated. The main goal of PSM is to reduce the overall power consumption. Therefore for each application special care must be taken to judge whether AssistNow Autonomous is beneficial to the overall power consumption or not.

10.2.4 Examples

10.2.4.1 Use Grid Offset

Scenario: Get a position fix once a day at a fixed time. If the position fix cannot be obtained try again every two hours.

Solution: First set the update period to 24*3600s and the search period to 2*3600s. Now a position fix is obtained every 24 hours and if the position fix fails retrials are scheduled in two hour intervals. As the update grid is aligned to midnight Saturday/Sunday, the position fixes happen at midnight. By setting the grid offset to 12*3600s the position fixes are shifted to once a day at noon. If the position fix at noon fails, retrials take place every two hours, the first at 14:00. Upon successfully acquiring a position fix the next fix attempt is scheduled for noon the following day.

10.2.4.2 User controlled position fix

Scenario: Get a position fix on request.

Solution: Set updatePeriod and searchPeriod to zero. Set extintSelect to the desired EXTINT pin to be used. Enable the extintWake and extintBackup features.

10.2.4.3 Use update periods of 30 minutes

Scenario: Get a position fix once every 30 minutes and acquire a fix needed for timing products Solution: Set mode of operation to PSMOO. Set updatePeriod to 1800 seconds. Set the search period to 120 seconds. Enable waitTimeFix feature.

10.3 Peak current settings

The peak current during acquisition can be reduced by activating the corresponding option in UBX-CFG-PM2. A peak current reduction will result in longer start-up times of the receiver.



This setting is independent of the activated mode (Continuous or Power Save Mode).

10.4 Power On/Off command

With message UBX-RXM-PMREQ the receiver can be forced to enter *Inactive* state (in Continuous and Power Save Mode). It will stay in *Inactive* state for the time specified in the message or until it is woken up by an EXTINT or activity on the RXD1 line.



i

Sending the message UBX-RXM-PMREQ while the receiver is in Power Save Mode will overrule PSM and force the receiver to enter Inactive state. It will stay in Inactive state until woken up. After wake-up the receiver continues working in Power Save Mode as configured.

10.5 EXTINT pin control when Power Save Mode is not active

The receiver can be forced OFF also when the Power Save Mode is not active. This works the same way as EXTINT pin control in Power Save Mode. Just as in Power Save Mode, this feature has to be enabled and configured using UBX-CFG-PM2

10.6 Measurement and navigation rate with Power Save Mode

In Continuous Mode, measurement and navigation rate is configured using UBX-CFG-RATE. In Power Save Mode however, measurement and navigation rate can differ from the configured rates as follows:

- **Cyclic Operation:** When in state *Power Optimized Tracking*, the measurement and navigation rate is determined by the *updatePeriod* configured in UBX-CFG-PM2. The receiver can however switch to *Tracking* state (e.g. to download data). When in *Tracking* state, the measurement and navigation rate is as configured with UBX-CFG-RATE. Note: When the receiver is no longer able to produce position fixes, it can switch from Cyclic Operation to ON/OFF Operation (if this is not disabled with the *doNotEnterOff* switch in UBX-CFG-PM2). In that case the remarks below are relevant.
- **ON/OFF Operation:** When in state *Acquisition*, the measurement and navigation rate is **fixed to 2Hz**. All NMEA (and UBX) messages that are output upon a navigation fix are also output with a rate of 2Hz. This must be considered when choosing the baud rate of a receiver that uses Power Save Mode! Note that a receiver might stay in *Acquisition* state for quite some time (can be tens of seconds under weak signal conditions). When the receiver eventually switches to *Tracking* state, the measurement and navigation rate will be as configured with UBX-CFG-RATE.



When using Power Save Mode, the baud rate of the receiver must be chosen such that it can handle the amount of data that is output when measurement and navigation rate is 2Hz.

11 Forcing a Receiver Reset

Typically, in GNSS receivers, one distinguishes between cold, warm, and hot starts, depending on the type of valid information the receiver has at the time of the restart.

- **Cold start** In cold start mode, the receiver has **no** information from the last position (e.g. time, velocity, frequency etc.) at startup. Therefore, the receiver must search the full time and frequency space, and all possible satellite numbers. If a satellite signal is found, it is tracked to decode the ephemeris (18-36 seconds under strong signal conditions), whereas the other channels continue to search satellites. Once there is a sufficient number of satellites with valid ephemeris, the receiver can calculate position and velocity data. Please note that some competitors call this startup mode Factory Startup.
- Warm start In warm start mode, the receiver has approximate information for time, position, and coarse satellite position data (Almanac). In this mode, after power-up, the receiver normally needs to download ephemeris before it can calculate position and velocity data. As the ephemeris data usually is outdated after 4 hours, the receiver will typically start with a Warm start if it has been powered down for more than 4 hours. In this scenario, several augmentations are possible. See the section on Multi-GNSS Assistance.
- Hot start In hot start mode, the receiver was powered down only for a short time (4 hours or less), so that its ephemeris is still valid. Since the receiver doesn't need to download ephemeris again, this is the fastest startup method.

In the UBX-CFG-RST message, one can force the receiver to reset and clear data, in order to see the effects of



maintaining/losing such data between restarts. For this, the CFG-RST message offers the navBbrMask field, where hot, warm and cold starts can be initiated, and also other combinations thereof.



Data stored in flash memory is not cleared by any of the options provided by UBX-CFG-RST. So, for example, if valid AssistNow Offline data stored in the flash it is likely to have an impact on a "cold start".

The Reset Type can also be specified. This is not related to GNSS, but to the way the software restarts the system.

- Hardware Reset uses the on-chip Watchdog, in order to electrically reset the chip. This is an immediate, asynchronous reset. No Stop events are generated. This is equivalent to pulling the Reset signal on the receiver.
- **Controlled Software Reset** terminates all running processes in an orderly manner and, once the system is idle, restarts operation, reloads its configuration and starts to acquire and track GNSS satellites.
- **Controlled Software Reset (GNSS only)** only restarts the GNSS tasks, without reinitializing the full system or reloading any stored configuration.
- **Controlled GNSS Stop** stops all GNSS tasks. The receiver will not be restarted, but will stop any GNSS related processing.
- Controlled GNSS Start starts all GNSS tasks.

12 Receiver Status Monitoring

Messages in the UBX class MON are used to report the status of the parts of the embedded computer system that are not GNSS-specific.

The main purposes are

- Hardware and Software Versions, using MON-VER
- Status of the Communications Input/Output system
- Status of various Hardware Sections with MON-HW

12.1 Input/Output system

The I/O system is a GNSS-internal layer where all data input- and output capabilities (such as UART, DDC, SPI, USB) of the GNSS receiver are combined. Each communications task has buffers assigned, where data is queued. For data originating at the receiver, to be communicated over one or multiple communications queues, the message MON-TXBUF can be used. This message shows the current and maximum buffer usage, as well as error conditions.



If the amount of data configured is too much for a certain port's bandwidth (e.g. all UBX messages output on a UART port with a baud rate of 9600), the buffer will fill up. Once the buffer space is exceeded, new messages to be sent will be dropped. For details see section Serial Communication Ports Description

Inbound data to the GNSS receiver is placed in buffers. Usage of these buffers is shown with the message MON-RXBUF. Further, as data is then decoded within the receiver (e.g. to separate UBX and NMEA data), the MON-MSGPP can be used. This message shows (for each port and protocol) how many messages were successfully received. It also shows (for each port) how many bytes were discarded because they were not in any of the supported protocol framings.

The following table shows the port numbers used. Note that any numbers not listed are reserved for future use.



Port Number assignment

Port #	Electrical Interface
0	DDC (I ² C compatible)
1	UART 1
3	USB
4	SPI

Protocol numbers range from 0-7. All numbers not listed are reserved.

Protocol Number assignment

Protocol #	Protocol Name
0	UBX Protocol
1	NMEA Protocol

12.2 Jamming/Interference Indicator

The field jamInd of the UBX-MON-HW message can be used as an indicator for continuous wave (narrowband) jammers/interference only. The interpretation of the value depends on the application. It is necessary to run the receiver in an unjammed environment to determine an appropriate value for the unjammed case. If the value rises significantly above this threshold, this indicates that a continuous wave jammer is present.

This indicator is always enabled.

The indicator is reporting any currently detected narrowband interference over all currently configured signal bands

12.3 Jamming/Interference Monitor (ITFM)

The field jammingState of the MON-HW message can be used as an indicator for both broadband and continuous wave (CW) jammers/interference. It is independent of the (CW only) jamming indicator described in Jamming/Interference Indicator above.

This monitor reports whether jamming has been detected or suspected by the receiver. The receiver monitors the background noise and looks for significant changes. Normally, with no interference detected, it will report 'OK'. If the receiver detects that the noise has risen above a preset threshold, the receiver reports 'Warning'. If in addition, there is no current valid fix, the receiver reports 'Critical'.

The monitor has four states as shown in the following table:

Jamming/Interference monitor reported states

Value	Reported state	Description
0	Unknown	Jamming/interference monitor not enabled, uninitialized or
		antenna disconnected
1	OK	no interference detected
2	Warning	position ok but interference is visible (above the thresholds)
3	Critical	no reliable position fix and interference is visible (above the
		thresholds); interference is probable reason why there is no fix

The monitor is disabled by default. The monitor is enabled by sending an appropriate UBX-CFG-ITFM message with the enable bit set. In this message it is also possible to specify the thresholds at which broadband and CW jamming are reported. These thresholds should be interpreted as the dB level above 'normal'. It is also possible to specify whether the receiver expects an active or passive antenna.



The monitor algorithm relies on comparing the currently measured spectrum with a reference from



when a good fix was obtained. Thus the monitor will only function when the receiver has had at least one (good) first fix, and will report 'Unknown' before this time.

i

Jamming/Interference monitor is not supported in Power Save Mode (PSM) ON/OFF mode.

The monitor is reporting any currently detected interference over all currently configured signal bands

13 Remote Inventory

13.1 Description

The *Remote Inventory* enables storing user-defined data in the non-volatile memory of the receiver. The data can be either binary or a string of ASCII characters. In the second case, it is possible to dump the data at startup.

13.2 Usage

- The contents of the *Remote Inventory* can be set and polled with the message UBX-CFG-RINV. Refer to the message specification for a detailed description.
- If the contents of the *Remote Inventory* are polled without having been set before, the default configuration (see table below) is output.

Default configuration

Parameter	Value
flags	0x00
data	"Notice: no data saved!"



As with all configuration changes, these must be saved in order to be made permanent. Make sure to save the section RINV before resetting or switching off the receiver. For more information about saving a configuration, see section Configuration Concept.

14 Time pulse


There is only limited support for the generation of time pulses when running in BeiDou mode. In particular the accuracy of the time pulse in BeiDou mode has not been calibrated.

14.1 Introduction

u-blox GNSS receivers include a time pulse function providing clock pulses with configurable duration and frequency. The time pulse function can be configured using the CFG-TP5 message. The TIM-TP message provides time information for the next pulse, time source and the quantization error of the output pin.



Pulse Mode: Rising




14.2 Recommendations

- For best time pulse performance it is recommended to disable the SBAS subsystem.
- When using time pulse for precision timing applications it is recommended to calibrate the antenna cable delay against a reference-timing source.
- Care needs to be given to the cable delay settings in the receiver configuration.
- In order to get the best timing accuracy with the antenna, a fixed and accurate position is needed.
- If relative time accuracy between multiple receivers is required, do not mix receivers of different product families. If this is required, the receivers must be calibrated accordingly, by setting cable delay and user delay.
- The recommended configuration when using the TIM-TP message is to set both the measurement rate (CF G-RATE) and the time pulse frequency (CFG-TP5) to 1Hz.

Since the rate of TIM-TP is bound to the measurement rate, more than one TIM-TP message can appear between two pulses if the measurement rate is set larger than the time pulse frequency. In this case all TIM-TP messages in between a time pulse T1 and T2 belong to T2 and the last TIM-TP before T2 reports the most accurate quantization error. In general, if the navigation solution rate and time pulse rate are configured to different values, there will not be a single TIM-TP message for each time pulse.

The sequential order of the signal present at the TIMEPULSE pin and the respective output message for the simple case of 1 pulse per second (1PPS) and a one second navigation update rate is shown in the following figure.





14.3 GNSS time bases

GNSS receivers must handle a variety of different time bases as each GNSS has its own reference system time. What is more, although each GNSS provides a model for converting their system time into UTC, they all support a slightly different variant of UTC. So, for example, GPS supports a variant of UTC as defined by the US National Observatory, whilst BeiDou uses UTC from the National Time Service Center, China (NTSC). Whilst the different UTC variants are normally closely aligned, they can differ by as much as a few hundreds of nanoseconds.

Although u-blox GNSS receivers can combine a variety of different GNSS times internally, the user must choose a single type of GNSS time and, separately, a single type of UTC for input (on EXTINTs) and output (via the Time Pulse) and the parameters reported in corresponding messages.

For protocol versions less than 16, the UBX-CFG-TP5 message allows the user to choose between GPS and UTC as the time system the generated time pulse will be aligned to.

For protocol versions 16 or higher, the UBX-CFG-TP5 message allows the user to choose between GPS, GLONASS, BeiDou and UTC. Additionally, the UBX-CFG-NAV5 message allows the user to configure the variant of UTC.

The receiver will assume that the input time pulse uses the same GNSS time base as specified for the output using UBX-CFG-TP5. So if the user selects GLONASS time for time pulse output, any time pulse input must also be aligned to GLONASS time (or to the separately chosen variant of UTC). Where UTC is selected for time pulse output, any GNSS time pulse input will be assumed to be aligned to GPS time.



u-blox GNSS receivers allow users to choose independently GNSS signals used in the receiver (using UBX-CFG-GNSS) and the input/output time base (using UBX-CFG-TP5). For example it is possible to instruct the receiver to use GPS and GLONASS satellite signals to generate BeiDou time. This practice may compromise time-pulse accuracy if the receiver cannot measure the timing difference between the constellations directly.

14.4 Time pulse configuration

u-blox GNSS receivers provide one or two TIMEPULSE pins (dependent on product variant) delivering a time pulse (TP) signal with a configurable pulse period, pulse length and polarity (rising or falling edge). Check the product data sheet for detailed specification of configurable values.

It is possible to define different signal behavior (i.e. output frequency and pulse length) depending on whether or not the receiver is locked to a reliable time source. Time pulse signals can be configured using the UBX proprietary message CFG-TP5.



14.5 Configuring time pulse with UBX-CFG-TP5

The UBX message CFG-TP5 can be used to change the time pulse settings, and includes the following parameters defining the pulse:

- time pulse index Index of time pulse output pin to be configured.
- antenna cable delay Signal delay due to the cable between antenna and receiver.
- RF group delay Signal delay in the RF module of the receiver (read-only).
- **pulse frequency/period** Frequency or period time of the pulse when locked mode is not configured or active.
- **pulse frequency/period lock** Frequency or period time of the pulse, as soon as receiver has calculated a valid time from a received signal. Only used if the corresponding flag is set to use another setting in locked mode.
- **pulse length/ratio** Length or duty cycle of the generated pulse, either specifies a time or ratio for the pulse to be on/off.
- **pulse length/ratio lock** Length or duty cycle of the generated pulse, as soon as receiver has calculated a valid time from a received signal. Only used if the corresponding flag is set to use another setting in locked mode.
- **user delay** The cable delay from the receiver to the user device plus signal delay of any user application.
- **active** time pulse will be active if this bit is set.
- **lock to gps freq** Use frequency gained from GPS signal information rather than local oscillator's frequency if flag is set.
- **lock to gnss freq** Use frequency gained from GNSS signal information rather than local oscillator's frequency if flag is set.
- **locked other setting** If this bit is set, as soon as the receiver can calculate a valid time, the alternative setting is used. This mode can be used for example to disable time pulse if time is not locked, or indicate lock with different duty cycles.
- is frequency Interpret the 'Frequency/Period' field as frequency rather than period if flag is set.
- is length Interpret the 'Length/Ratio' field as length rather than ratio if flag is set.
- align to TOW If this bit is set, pulses are aligned to the top of a second.
- **polarity** If set, the first edge of the pulse is a rising edge (Pulse Mode: Rising).
- grid UTC/GPS Selection between UTC (0) or GPS (1) timegrid. Also effects the time output by TIM-TP message.
- grid UTC/GNSS Selection between UTC (0), GPS (1), GLONASS (2) and Beidou (3) timegrid. Also effects the time output by TIM-TP message.



The maximum pulse length can't exceed the pulse period.



time pulse settings shall be chosen in such a way, that neither the high nor the low period of the output is less than 50 ns (except when disabling it completely), otherwise pulses can be lost.

14.5.1 Example 1


The example below shows the 1PPS TP signal generated on the time pulse output according to the specific parameters of the CFG-TP5 message:

• **tpldx** = 0



- freqPeriod = 1 s
- pulseLenRatio = 100 ms
- **active** = 1
- lockGpsFreq = lockGnssFreq = 1
- isLength = 1
- alignToTow = 1
- polarity = 1
- gridUtcGps = gridUtcGnss = 1

The 1 Hz output is maintained whether or not the receiver is locked to GPS time. The alignment to TOW can only be maintained when GPS time is locked.



14.5.2 Example 2

The following example shows a 10 MHz TP signal generated on the TIMEPULSE2 output when the receiver is locked to GPS time. Without the lock to GPS time no frequency is output.

10 MHz



GPS time not locked GPS time locked

- **tpldx** = 1
- freqPeriod = 1 Hz
- pulseLenRatio = 0
- freqPeriodLock = 10 MHz
- pulseLenRatioLock = 50%
- **active** = 1
- lockGpsFreq = lockGnssFreq = 1
- IockedOtherSet = 1
- isFreq = 1
- alignToTow = 1
- polarity = 1
- gridUtcGps = gridUtcGnss = 1



15 Timemark

The receiver can be used to provide an accurate measurement of the time at which a pulse was detected on the external interrupt pin. The reference time can be chosen by setting the time source parameter to UTC, GPS, GLONASS, Beidou or local time in the UBX-CFG-TP5 configuration message. The UTC standard can be set in the UBX-CFG-NAV5 configuration message. The delay figures defined with UBX-CFG-TP5 are also applied to the results output in the UBX-TIM-TM2 message.


A UBX-TIM-TM2 message is output at the next epoch if

- the UBX-TIM-TM2 message is enabled
- a rising or falling edge was triggered since last epoch on one of the EXTINT channels

The UBX-TIM-TM2 messages include time of the last timemark, new rising/falling edge indicator, time source, validity, number of marks and a quantization error. The timemark is triggered continuously.



Only the last rising and falling edge detected between two epochs is reported since the output rate of the UBX-TIM-TM2 message corresponds to the measurement rate configured with UBX-CFG-RATE (see Figure below).



16 Odometer

16.1 Introduction

The odometer provides information on travelled ground distance (in meter) using solely the position and Doppler-based velocity of the navigation solution. For each computed travelled distance since the last odometer reset, the odometer estimates a 1-sigma accuracy value. The total cumulative ground distance is maintained and saved in the BBR memory.



i

The odometer feature is disabled by default. It can be enabled using the UBX-CFG-ODO message.

16.2 Odometer Output

The odometer output is published in the UBX-NAV-ODO message. This message contains the following elements:

- *Ground distance since last reset (distance* field): this distance is defined as the total cumulated distance in meters since the last time the odometer was reset (see section Resetting the Odometer);
- *Ground distance accuracy (distanceStd* field): this quantity is defined as the 1-sigma accuracy estimate (in meters) associated to the *Ground distance since last reset* value;
- *Total cumulative ground distance (totalDistance* field): this quantity is defined as the total cumulated distance in meters since the last time the receiver was cold started (see section Resetting the Odometer).

If logging is enabled, then the odometer ground distance value will be included in logged position data (see section Logging).

16.3 Odometer Configuration

The odometer can be enabled/disabled by setting the appropriate flag in UBX-CFG-ODO (*flags* field). The algorithm behaviour can be optimized by setting up a profile (*odoCfg* field) representative of the context in which the receiver is operated. The implemented profiles together with their meanings are listed below:

- *Running*: the algorithm is optimized for typical dynamics encountered while running, i.e the Doppler-based velocity solution is assumed to be of lower quality;
- Cycling: the algorithm is optimized for typical dynamics encountered while cycling;
- *Swimming*: the algorithm is optimized for very slow and smooth trajectories typically encountered while swimming;
- *Car*: the algorithm assumes that good Doppler measurements are available (i.e. the antenna is subject to low vibrations) and is optimized for typical dynamics encountered by cars.



The odometer can only be reliably operated in a swimming context if satellite signals are available and the antenna is not immersed.

16.4 Resetting the Odometer

The odometer outputs (see UBX-NAV-ODO message) can be reset by the following means:

- Ground distance since last reset (distance field): by sending a UBX-NAV-RESETODO message;
- Ground distance accuracy (distanceStd field): by sending a UBX-NAV-RESETODO message;
- Total cumulative ground distance (totalDistance): by a cold start of the receiver (this erases the BBR memory);

17 Logging

17.1 Introduction

The logging feature allows position fixes and arbitrary byte strings from the host to be logged in flash memory attached to the receiver. Logging of position fixes happens independently of the host system, and can continue while the host is powered down.

The following tables list all the logging related messages:





	-
Message	Description
UBX-LOG-CREATE	Creates a log file and activates the logging subsystem
UBX-LOG-ERASE	Erases a log file and deactivates the logging subsystem
UBX-CFG-LOGFILTER	Used to start/stop recording and set/get the logging configuration
UBX-LOG-INFO	Provides information about the logging system
UBX-LOG-STRING	Enables a host process to write a string of bytes to the log file

Logging control and configuration messages

Logging retrieval messages

Message	Description
UBX-LOG-RETRIEVE	Starts the log retrieval process
UBX-LOG-RETRIEVEPOS	A position log entry returned by the receiver
UBX-LOG-RETRIEVEPOSEXT	Odometer position data
RA	
UBX-LOG-RETRIEVESTRING	A byte string log entry returned by the receiver
UBX-LOG-FINDTIME	Finds the index of the first entry <= given time


17.2 Setting the logging system up

An empty log can be created using the UBX-LOG-CREATE message and a log can be deleted with the UBX-LOG-ERASE message. The logging system will only be running if a log is in existence, so most logging messages will be rejected with an UBX-ACK-NAK message if there is no log present. Only one log can be created at any one time so an UBX-ACK-NAK message will be returned if a log already exists. The message specifies the maximum size of the log in bytes (with some pre-set values provided). Both the logging subsystem and the receiver file-store have implementation overheads, so total space available for log entries will be somewhat smaller than the size specified.

UBX-LOG-CREATE also allows the log to be specified as a circular log. If the log is circular, then when it fills up, a set of older log entries will be deleted and the space freed up used for new log entries. By contrast, if a non-circular log becomes full then new entries which don't fit will be rejected. UBX-LOG-CREATE also causes the logging system to start up so that further logging messages can be processed. The logging system will start up automatically on power-up if there is a log in existence. The log will remain in the receiver until specifically erased using the UBX-LOG-ERASE message.

UBX-CFG-LOGFILTER controls whether logging of entries is currently enabled and selects position fix messages for logging. These configuration settings will be saved if the configuration is saved to flash. If this is done, then entry logging will continue on power-up in the same manner that it did before power-down.

The top level active/inactive states of the logging subsystem.





17.3 Information about the log

The receiver can be polled for a UBX-LOG-INFO message which will give information about the log. This will include the maximum size that the log can grow to (which, due to overheads, will be smaller than that requested in UBX-LOG-CREATE) and the amount of log space currently occupied. It will also report the number of entries currently in the log together with the time and date of the newest and oldest messages which have a valid time stamp.

Log entries are compressed and have housekeeping information associated with them, so the actual space occupied by log messages may be difficult to predict. The minimum size for a position fix entry is 9 bytes and the maximum 24 bytes, the typical size is 10 or 11 bytes. If the odometer is enabled then this will use at least another three bytes per fix.

Each log also has a fixed overhead which is dependent on the log type. The approximate size of this overhead is shown in the following table.

Log overhead size

Log type	Overhead
circular	Up to 40 kB
non-circular	Up to 8 kB

The number of entries that can be logged in any given flash size can be estimated as follows:

Approx. number of entries = (flash size available for logging - log overhead)/typical entry size

For example, if 1500 kB of flash is available for logging (after other flash usage such as the firmware image is taken into account) a non-circular log would be able to contain approximately 139000 entries ((1500*1024)-(8*1024))/11 = 138891.

17.4 Recording

The UBX-CFG-LOGFILTER message specifies the conditions under which entries are recorded. Nothing will be recorded if recording is disabled, otherwise position fix and UBX-LOG-STRING entries can be recorded. When recording is enabled an entry will also be created from each UBX-LOG-STRING message. These will be timestamped if the receiver has current knowledge of time.

The UBX-CFG-LOGFILTER message has several values which can be used to select position fix entries for logging. If all of these values are zero, then all position fixes will be logged (subject to a maximum rate of 1Hz). A position is logged if any of the thresholds are exceeded. If a threshold is set to zero it is ignored. In addition the position difference and current speed thresholds also have a minimum time threshold.

Position fixes are only recorded if a valid fix is obtained - failed and invalid fixes are not recorded.

Position fixes are compressed to economise on the amount of flash space used. In order to improve the compression, the fix values are rounded to improve their compression. This means that the values returned by the logging system may differ slightly from any which are gathered in real time.

In On/Off Power Save Mode it is possible to configure the logging system so that only one fix is recorded for each on period. This will be recorded immediately before the receiver powers off and will be the best fix seen during the on period (in this case, "best" is defined as being the fix with the lowest horizontal accuracy figure).


The recorded data for a fix comprises :

- The time and date of the fix recorded to a precision of one second
- Latitude and longitude to a precision of one millionth of a degree. Depending on position on Earth this is a precision in the order of 0.1m



- Altitude (height above mean sea level) to a precision of 1m
- Ground speed to a precision of 1cm/s
- The fix type (only successful fix types, since these are the only ones recorded)
- The number of satellites used in the fix is recorded, but no value greater than 19 is logged; a value of 19 means 19 or more satellites
- A horizontal accuracy estimate is recorded to give an indication of fix quality
- Heading to a precision of one degree
- Odometer distance data (if odometer is enabled)

The states of the active logging subsystem



17.5 Retrieval

UBX-LOG-RETRIEVE starts the process which allows the receiver to output log entries. Log recording must be stopped using UBX-CFG-LOGFILTER before this can be done. UBX-LOG-INFO may be helpful to a host system in order to understand the current log status before retrieval is started.

Once retrieval has started, one message will be output from the receiver for each log entry requested. Sending any logging message to the receiver during retrieval will cause the retrieval to stop before the message is processed.

To maximise the speed of transfer it is recommended that a high communications data rate is used and GNSS processing is stopped during the transfer (see UBX-CFG-RST)

UBX-LOG-RETRIEVE can specify a start-entry index and entry-count. The maximum number of entries that can be returned in response to a single **UBX-LOG-RETRIEVE** message is 256. If more entries than this are required the message will need to be sent multiple times with different startEntry indices.

The receiver will send a UBX-LOG-RETRIEVEPOS message for each position fix log entry and a UBX-LOG-RETRIEVESTRING message for each string log entry. If the odometer was enabled at the time a position was logged, then a UBX-LOG-RETRIEVEPOSEXTRA will also be sent. Messages will be sent in the order in which they were logged, so UBX-LOG-RETRIEVEPOS and UBX-LOG-RETRIEVESTRING messages may be interspersed in the message stream.

The UBX-LOG-FINDTIME message can be used to search a log for the index of the first entry less than or



equal to the given time. This index can then be used with the UBX-LOG-RETRIEVE message to provide time-based retrieval of log entries.

17.6 Command message acknowledgement

Some log operations make take a long time to execute because of the time taken to write to flash memory. The time for some operations may be unpredictable since the number and timing of flash operations may vary. In order to allow host software to synchronise to these delays logging messages will always produce a response. This will be UBX-ACK-NAK in case of error, otherwise UBX-ACK-ACK unless there is some other defined response to the message.

It is possible to send a small number of logging commands without waiting for acknowledgement, since there is a command queue, but this risks confusion between the acknowledgements for the commands. Also a command queue overflow would result in commands being lost.

18 Time Mode Configuration

This feature is only available with the Timing or FTS product variants

This section relates to the configuration message UBX-CFG-TMODE2.

18.1 Introduction

Time Mode is a special receiver mode where the position of the receiver is known and fixed and only the time is calculated using all available satellites. This mode allows for maximum time accuracy as well as for single-SV solutions.

18.2 Fixed Position

In order to use the *Time Mode*, the receiver's position must be known as exactly as possible. Either the user already knows and enters the position, or it is determined using Survey-in. Errors in the fixed position will translate into time errors depending on the satellite constellation. Using the TDOP value (see UBX-NAV-DOP) and assuming a symmetrical 3D position error, the expected time error can be estimated as

time error = tdop * position error

As a rule of thumb the position should be known with an accuracy of better than 1 m for a timing accuracy in the order of nanoseconds. If an accuracy is required only in the order of microseconds, a position accuracy of roughly 300 m is sufficient.

18.3 Survey-in

Survey-in is the procedure that is carried out prior to using *Time Mode*. It determines a stationary receiver's position by building a weighted mean of all valid 3D position solutions.

Two requirements for stopping the procedure must be specified:

- The **minimum observation time** defines a minimum amount of observation time regardless of the actual number of valid fixes that were used for the position calculation. Reasonable values range from one day for high accuracy requirements to a few minutes for coarse position determination.
- The **required 3D position standard deviation** forces the calculated position to be of at least the given accuracy. As the position error translates into a time error when using *Time Mode* (see above), one should carefully evaluate the time accuracy requirements and the choose an appropriate position accuracy requirement.



Survey-in ends, when **both** requirements are met. After Survey-in has finished successfully, the receiver will automatically enter fixed position *Time Mode*. The Survey-in status can queried using the UBX-TIM-SVIN message.

1

The "Standard Deviation" parameter defines uncertainty of the manually provided "True Position" set of parameters. This uncertainty directly affects the accuracy of the timepulse. This is to prevent an error that would otherwise be present in the timepulse because of the initially inaccurate position (assumed to be correct by the receiver) without users being aware of it. The "3D accuracy" parameter in "Fixed Position" as well as the "Position accuracy limit" in "Survey-in" affect the produced time information and the timepulse in the same way. Please note that the availability of the position accuracy does not mitigate the error in the timepulse but only accounts for it when calculating the resulting time accuracy.

19 Frequency and Timing Synchronization (FTS)

The features described in this section are only available with the FTS product variant

19.1 Introduction

An FTS configured receiver provides an accurate, low phase-noise reference frequency as well as phase reference pulse (typically at one pulse per second). An FTS receiver also implements automatic hold-over capability based on a stable VCTCXO in modules and the customer's choice of reference oscillator in chip-based designs. It offers generic interfaces for external sources of synchronization (suitable for external OCXOs, IEEE1588 or Synchronous Ethernet). The receiver is optimized for stationary applications and delivers excellent GNSS sensitivity in conjunction with assistance data.

In the rest of this description the following terminology will be used:

- Disciplined oscillator: an oscillator whose frequency is corrected by a more stable frequency reference, such as a GNSS system.
- Internal oscillator: the mandatory disciplined oscillator which is used as the reference frequency for the GNSS receiver subsystem. The output from this oscillator is also available to the application as an output from the module.
- External oscillator: an optional oscillator, disciplined by the receiver, either via I2C DAC or via UBX messages handle by a host.
- Source: a source of frequency and/or phase synchronization either measured by the receiver based on direct hardware input or an offset estimated by an external timing sub-system with respect to the receiver output. Sources are handled according to related estimates of uncertainty delivered by the application or (for oscillators) configurable models provided by the receiver.
- Holdover: periods when GNSS measurements of sufficient quality to maintain time/frequency are not available.

In all FTS related messages the above sources are indexed as follows:

Synchronization source indexing

Source	Index
Internal oscillator	0
GNSS	1
EXTINTO (external input)	2
EXTINT1 (external input)	3
Internal oscillator measured by the host	4



Synchronization source indexing continued

Source	Index
External oscillator measured by the host	5

The following table lists FTS related messages:

FTS message summary


Message	Description
UBX-CFG-SMGR	Synchronization manager configuration
UBX-CFG-ESRC	External source configuration
UBX-CFG-DOSC	Disciplined oscillator configuration
UBX-CFG-TP5	Configures the output pulse parameters
UBX-CFG-NAV5	Configures which variant of UTC is used by the receiver
UBX-MON-SMGR	SMGR monitoring message
UBX-TIM-DOSC	Message containing disciplining command for external oscillators controlled
	through the host
UBX-TIM-HOC	Message allowing the host to directly control the module's oscillators
UBX-TIM-TOS	Message containing information about the preceding time-pulse output by
	the receiver
UBX-TIM-SMEAS	Message containing measurements of phase/frequency inputs
UBX-TIM-VCOCAL	Oscillator calibration command and result report
UBX-TIM-FCHG	Information about latest frequency change to an oscillator

The remainder of this chapter describes some typical use cases, introduces the Synchronization Manager (SMGR) functionality unique to FTS products and describes the use of related messages.

19.2 Example use cases

In this section some typical use cases are described.


19.2.1 Stand-alone synchronization system



In this example, the FTS device provides a stand-alone synchronization sub-system in the context of, say, a small cell. The module's internal 30.72MHz VCTCXO is disciplined by the module and provides the frequency



reference to the platform. The module provides a PPS signal to synchronize the platform's physical layer. A 1PPS (or frequency) input to the module provides frequency and/or phase information from host timing sub-systems such as PTP or Sync-E. In the absence of phase information from GNSS or any other source, the module relies on the VCTCXO for synchronization holdover, augmented by any reliable source of frequency control. In the absence of frequency control, the holdover performance is determined entirely by the VCTCXO. In some applications holdover performance will be enhanced by using an external stable (but not necessarily accurate) frequency reference.




19.2.2 Oscillator control via host


The frequency offset of the external oscillator is measured by the FTS device and communicated to the host which can then make any corrections necessary. The FTS device also generates a PPS phase reference internally (with no guarantee of coherence with the external oscillator). During holdover, the phase of 1PPS signal is maintained using either the primary reference oscillator or the 1PPS_In signal, according to their respective uncertainty.

19.2.3 Oscillator control via directly-connected DAC





In this use case, the FTS device disciplines an external oscillator via an external DAC. During holdover the input to the external DAC is frozen and the phase of the time pulse output is maintained by the primary reference oscillator, but only guaranteed to be fully coherent with the internal oscillator. The FTS receiver can also be commanded to perform a one-off calibration of the tuning slope of external oscillator if necessary.



19.2.4 External (coherent) PPS

In this use case, the system PPS is generated by an external device from the output of the primary reference oscillator. The FTS receiver measures the phase of this PPS input against GNSS time or the best available source. Any small phase corrections necessary can be made by the receiver via adjustments to the oscillator frequency or directly by the host to the PPS generator (e.g. to accelerate removal of large phase errors). During holdover




the DAC input is frozen.

19.3 Synchronization Manager Concept

The Synchronization Manager (SMGR) assumes the frequency and phase control functions in FTS configured devices. The SMGR uses internal and external phase and frequency measurements to derive the disciplining values (necessary frequency changes) and to assess the quality (uncertainty) of the time pulse signal and the frequency outputs. The SMGR considers the following synchronization sources:

- The GNSS solutions
- Internal oscillator
- Up to two external signals: frequency or time pulse (e.g. 1PPS) reference signals on EXTINT0 and/or EXTINT1
- Externally conducted measurements, from which the results are sent to the receiver through one of the host interfaces

Each measurement provides frequency offset and/or phase information along with an estimate of the uncertainty of each. The SMGR functional block diagram is given below:



The user has the option to configure how the SMGR considers the external signals, e.g. time or frequency source, disciplined or not, etc... The user must also configure the uncertainty of the signals along with their nominal characteristics. One of the external signals may be configured as the feedback path of a disciplined external oscillator.

The SMGR can operate in frequency locked or in phase locked mode. In frequency locked mode the target of the SMGR is to eliminate frequency error. In phase locked mode the elimination of time error is the goal; this may lead to intentional deviation from the correct oscillator frequency. The correction rate in both of these modes is subject to configurable limits (see UBX-CFG-SMGR). The SMGR runs periodically (typically once a second). Its operation consists of the following stages each time it is executed:

- Choose the best source to be the reference, given the characteristics (phase noise and stability) of each of the sources and the uncertainty of their measurements.
- Calculate the phase and/or frequency errors as well as their uncertainty for each of the disciplined oscillators with respect to the reference source.



- Calculate correction for disciplined oscillators; time and/or frequency corrections are limited to the configured limits.
- Map frequency adjustment to physical output.

The SMGR runs periodically and retrieves the most recent measurements for each source along with the estimates about their respective uncertainty. The relative phase and/or frequency errors of disciplined oscillators with respect to the reference are calculated from incoming measurements and used to discipline them. The decision-making process as such does not depend on decisions made previously, however it does rely on the estimated uncertainty for each source, which is determined by comparing predicted and measured values over some moderate period of time. The SMGR only uses a single reference source at any one time. It does not combine measurements from different sources in any way. If the selected reference provides a time error measurement then a phase locked loop is possible, otherwise the receiver automatically enters frequency lock even if configured to maintain a phase lock.

In some cases the host software might choose to drive an oscillator directly. This may be useful where a large timing error has accumulated (e.g. after a long period of holdover) and normal operation would prevent the error being corrected swiftly. In this case, the host can deliberately steer the oscillator to correct timing in large steps as configured maximum phase and frequency change limits are not applied to adjustments commanded by the host. Another use of the direct host-driven steering may be the calibration of other parts of the system. Use UBX-TIM-HOC message for this functionality.

If the time error is so large that its correction would take prohibitively long even with maximum frequency offset of the oscillator the receiver can be switched to non-coherent time pulse output mode. In this case the sync manager is temporarily reconfigured to allow time pulse intervals that are not coherent with the frequency output, i.e. there are more or less than the nominal number of cycles between two pulses. The user may optionally specify a limit on time adjustments. The output mode can be set to coherent again once the time error is sufficiently small.

A SMGR summary status is provided by UBX-MON-SMGR message.



The SMGR runs at the navigation rate set by UBX-CFG-RATE. For FTS configured devices, it is not recommended to use navigation rates higher than 1Hz.

19.4 Oscillator and source specification

For correct operation, the frequency, phase and stability characteristics of all sources and disciplined oscillators must be described. External synchronization sources are configured with UBX-CFG-ESRC and disciplined oscillators with UBX-CFG-DOSC. The models (short and long term stability behavior) specified by these messages provide the SMGR with the knowledge necessary to its decision making.

The user must also configure the method (coherent or non-coherent) used for frequency adjustment, the maximum frequency adjustment and other parameters contained in UBX-CFG-DOSC.

It is assumed that an external voltage-controlled oscillator has a constant ratio of relative frequency change to control voltage change. The oscillator is therefore characterized by two metrics: an offset (control voltage for nominal frequency) and a gain (relative frequency change per control step). Each of these parameters are known along with their uncertainty. It is assumed that the oscillator control gain is stable over time but its offset may change significantly with aging. Because of the drift of the offset, its saved value is regularly updated in the model. The gain, on the other hand, is only updated on demand by the host application by re-configuration or calibration. For the measurement of the gain a special auto-calibration is available, described in the calibration section.

External oscillator stability (frequency changes) is described by four parameters (see UBX-CFG-DOSC):

• changes with temperature: withTemp is the maximum deviation limit from the nominal frequency at the




reference temperature over the supported temperature range (in ppb) and timeToTemp (in s) which is a period after which the maximum deviation limit is reached.

• aging: maxDevLifeTime is the maximum deviation from the nominal frequency (in ppb) and withAge is the oscillator stability with age (in ppb/year).

19.5 Calibration

Prior to disciplining an oscillator, the SMGR must have an accurate knowledge of the controlled oscillator's frequency control gain and initial frequency offset (oscillator gains may differ significantly from unit to unit and batch to batch, largely as a result of different crystal Q). The receiver provides a slope measurement utility to aid the calibration process.

The calibration utility is a special mode where all disciplining operations are suspended and therefore all disciplined oscillators, internal or external, cease to produce usable outputs. It takes place in response to a specific request (UBX-TIM-VCOCAL message) from the host to do so for a particular oscillator and only one oscillator can be calibrated at a time. During this phase, the SMGR forces large frequency variations by changing the input of the digital to analogue conversion device whose output is driving the oscillator. Several frequency measurements are performed and a gain is estimated.




Calibration parameters must be configured or the calibration utility called before disciplining operation is possible. Once calibrated, the calibStatus flag in UBX-CFG-DOSC is set. The calibration utility can be re-triggered at any time by issuing the appropriate command through the UBX-TIM-VCOCAL message (not recommended during normal operation). An ongoing calibration process can be aborted using the same message with the appropriate flags. It can also be bypassed if the calibStatus flag in the UBX-CFG-DOSC message is set to 1 (oscillator is calibrated independently with results saved using the UBX-CFG-DOSC message).

In order to enter the calibration mode it is required that:

- A stable frequency source is available for the duration of the calibration. This source may be a GNSS solution or a frequency signal on an EXTINT pin.
- The oscillator subject to calibration is configured through the UBX-CFG-DOSC message (including an initial estimate of gain) and available for the duration of the process.

For an external oscillator it is also assumed that the useful range of the input is covered by the output of the DAC and that the relation frequency versus DAC input is linear. Once the calibration operation is complete the receiver will issue a UBX message to indicate that the SMGR is reverting to normal operation and to report the results of the calibration. A default for the internal oscillator is available in the firmware.

Note that it is important that only the chosen frequency source is enabled during the calibration process and that it remains stable throughout the calibration period; otherwise incorrect oscillator measurements will be





made and this will lead to miscalibration and poor subsequent operation of the receiver.

19.6 FTS device Output and Top Of Second (TOS) message

The outputs available from an FTS device can be one or all of the following:

- A disciplined frequency source at the same frequency as the internal oscillator.
- A 1PPS or an even second signal (other similar rates are possible) coherent with the internal oscillator, configured by UBX-CFG-TP5.
- Messages reporting measurement results (for example for a host disciplined external oscillator).
- A UBX-TIM-TOS message which describes the current condition (accuracy, coherent or non-coherent, etc...) of the frequency and PPS outputs.
- DAC command for disciplined external oscillators.

The top of second (TOS) message is a summary of the FTS device's status. It is output shortly after each time pulse and so will normally be aligned to the second of the reference time (if available). To guarantee that this message is output as the first message after the time pulse a system of time slot reservation is provided for all communication interfaces towards the host. For more information on this mechanism please refer to the description of TX time slots

Users of the FTS variant are expected to use the UBX-TIM-TOS message to obtain key parameters for each time pulse. The UBX-TIM-TP message is only supported for compatibility with timing receivers and is not guaranteed to provide the most appropriate information in all FTS use cases.

The time pulse of an FTS device is generated differently from that of other u-blox receivers.

FTS products support two modes of time pulse generation: "coherent" and "non-coherent" pulses. "Coherent" pulse generation means that the number of clock cycles between two pulses is always the same. When in "non-coherent" pulse mode the receiver may change the number of clock cycles between two pulses if it can thus reduce the phase error of the time pulse. The receiver can be configured (using UBX-CFG-SMGR) to operate in either of these modes or to switch from "non-coherent" to coherent mode after initial frequency and phase error has been eliminated.

It can be useful to instruct the receiver to enter the "non-coherent" pulse mode during startup or while recovering from holdover; it reduces the time necessary for phase convergence. After the phase error is reduced the host can instruct the FTS receiver to switch back to "coherent" mode again.

The UBX-TIM-TOS message, when enabled, indicates the actual mode of pulse generation.

Depending on the time pulse generation mode, the time pulse can be forced to be phase aligned to the oscillators. In coherent output mode the phase offset of the oscillator at the rising edge of the time pulse is defined by the phaseOffset field of UBX-CFG-DOSC. In "non-coherent" mode this constraint is ignored.

The phase offset is handled differently for both oscillators. Whereas phase lock between the internal oscillator and the time pulse is guaranteed by hardware, in the case of the external oscillator the lock is achieved by software and that lock is therefore the lock behavior is expected to be different.

The frequency, shape and offset of the time pulse can be configured with the UBX-CFG-TP5 message. Some of the fields are interpreted differently by FTS devices compared to other u-blox receivers. Among others the lockGnssFreq flag is ignored and the time pulse is always aligned to the best synchronization source. Furthermore, switching between the two time pulse frequency and length parameters is not governed by GNSS alone but by the condition selected in the syncMode field.



Two delay parameters can be configured using UBX-CFG-TP5, antCableDelay and userConfigDelay. In an FTS product care should be taken what delays are attributed to which



of the delay terms. The antenna cable delay is only relevant when the receiver is following GNSS as reference; the user configurable delay is applied regardless of the active reference signal.



In current FTS products only TIMEPULSE 2 can be used for pulse generation. Additionally, just 0.5 Hz, 1 Hz and 2 Hz time pulse output is supported by current FTS products. Other output frequencies may be configured with UBX-CFG-TP5 but are not guaranteed to work properly.

19.7 Message transmission time slot reservations on host interfaces

The firmware provides three message transmission time slots that are aligned to the time pulse output of the receiver. No message is scheduled for transmission in the first slot after the leading edge of the time pulse. The second slot is reserved for the UBX-TIM-TOS message and the third slot is used for outputting other messages. However, any message transmission that was started will be finished before a new message is started.

The time slots can be enabled and configured using UBX-CFG-TXSLOT.

When the reference time pulse is disabled or runs at a high frequency it may happen that many or all outgoing messages are lost. Therefore the time slot mechanism should be configured to match the time pulse behavior or disabled altogether.

This mechanism only controls when a message transmission may start and does not guarantee that the message transmission will finish before the end of the corresponding slot. Therefore the end of the last slot should be configured such that the longest enabled message can still be transmitted before the period starts when the receiver must not transmit messages.




The timing of the actual message output is also dependent on the communication interface and its clocking. On the slave interfaces (DDC and SPI) the host must provide clock in all time slots for this feature to work.

19.7.1 Example setup

Following is an example scenario. The receiver is set up to output a time pulse at a 1 Hz rate. Suppose that the following requirements are given for system integration:

- The TOS message should be output 10 to 50 ms after the time pulse.
- No other message should be output from the leading edge of the time pulse until 50 ms after the time pulse.
- The longest enabled message takes up to 100 ms to transmit through the chosen interface with the configured speed.

Then the time slots are enabled and the three slots are configured to end 10, 50 and 900 ms after the pulse respectively. The following figure indicates time pulses with upwards pointing arrows. Slot 0 (the first one active immediately after the time pulse) is active and thus blocks the transmission of new messages from 100 ms before the time pulse until 10 ms after it. Time slot 1, i.e. the time between 10 and 50 ms after the pulse, is reserved for the top-of-second message. All other messages are output in slot 2.







Protocol Specification

20 NMEA Protocol

20.1 Protocol Overview

20.1.1 Message Format

NMEA messages sent by the GNSS receiver are based on NMEA 0183 Version 4.0. The following picture shows the structure of a NMEA protocol message.

IMEA Protocol Frame						
	4	Ch	ecksum range			
\$	<adi< th=""><th>dress></th><th>{,<value>}</value></th><th>*<checksum></checksum></th><th><cr><lf></lf></cr></th></adi<>	dress>	{, <value>}</value>	* <checksum></checksum>	<cr><lf></lf></cr>	
Start character	Address fi	eld.	Data field(s)	Checksum field	End sequence	
Always '\$'	Only digits and uppercase letters, cannot be null. This field is subdivided into 2 fields:		Delimited by a ','. Length can vary, even for a certain field.	Starts with a ^{**} and consists of 2 chara representing a hex number. The check is the exclusive OR all characters	um	
alway	r Identifier, s GP for a iver, P for Messages	Defines the		between '\$' and '*'.		
\$	GP	ZDA	,141644.00,22,03,2002,00,00	*67	<cr><lf></lf></cr>	

For further information on the NMEA Standard, refer to *NMEA 0183 Standard For Interfacing Marine Electronic Devices*, Version 4.00, November 1, 2008. See <u>http://www.nmea.org/</u> for ordering instructions.

The NMEA standard allows for proprietary, manufacturer-specific messages to be added. These shall be marked with a manufacturer mnemonic. The mnemonic assigned to u-blox is UBX and is used for all non-standard messages. These proprietary NMEA messages therefore have the address field set to PUBX. The first data field in a PUBX message identifies the message number with two digits.

20.1.2 Talker ID

One of the ways the NMEA standard differentiates between GNSS is by using a two-letter message identifier, the 'Talker ID'. The specific Talker ID used by a u-blox receiver will depend on the device model and system configuration. The table below shows the Talker ID that will be used for various GNSS configurations.

NMEA Talker IDs

Configured GNSS	Talker ID
GPS, SBAS, QZSS	GP
GLONASS	GL
Galileo	GA



NMEA Talker IDs continued

Configured GNSS	Talker ID
BeiDou	GB
Any combination of GNSS	GN

20.1.3 Protocol Configuration

The NMEA protocol on u-blox receivers can be configured to the need of customer applications using CFG-NMEA. For backwards compatibility various versions of this message are supported, however, any new users should use the version that is not marked as deprecated.

There are four NMEA standards supported. The default NMEA version is 4.0. Alternatively versions 4.1, 2.3, and 2.1 can be enabled (for details on how this affects the output refer to section Position Fix Flags in NMEA Mode).

NMEA defines satellite numbering systems for some, but not all GNSS (this is partly dependent on the NMEA version). Satellite numbers for unsupported GNSS can be configured using CFG-NMEA. Unknown satellite numbers are always reported as a null NMEA field (i.e. an empty string)

The NMEA specification indicates that the GGA message is GPS specific. However, u-blox receivers support the output of a GGA message for each of the Talker IDs.

Parameter	Description	
Position filtering	Enable to permit positions from failed or invalid fixes to be reported (with the "V"	
	status flag to indicate that the data is not valid).	
Valid position filtering	Enable to permit positions from invalid fixes to be reported (with the "V" status flag to	
	indicate that the data is not valid).	
Time filtering	Enable to permit the receiver's best knowledge of time to be output, even though it	
	might be wrong.	
Date filtering	Enable to permit the receiver's best knowledge of date to be output, even though	
	might be wrong.	
GPS-only filtering	Enable to restrict output to only report GPS satellites.	
Track filtering	Enable to permit course over ground (COG) to be reported even when it would	
	otherwise be frozen.	

NMEA flags

Parameter	Description	
Compatibility Mode	Some older NMEA applications expect the NMEA output to be formatted in a specific	
	way, for example, they will only work if the latitude and longitude have exactly four	
	digits behind the decimal point. u-blox receivers offer a compatibility mode to support	
	these legacy applications.	
Consideration Mode	u-blox receivers use a sophisticated signal quality detection scheme, in order to produce	
	the best possible position output. This algorithm considers all SV measurements, and	
	may eventually decide to only use a subset thereof, if it improves the overall position	
	accuracy. If Consideration mode is enabled, all satellites, which were considered for	
	navigation, are communicated as being used for the position determination. If	
	Consideration Mode is disabled, only those satellites which after the consideration step	
	remained in the position output are marked as being used.	
Limit82 Mode	Enabling this mode will limit the NMEA sentance length to a maximum of 82 characters.	



Extended configuration

Option	Description	
GNSS to filter	Filters satellites based on their GNSS	
Satellite numbering	This field configures the display of satellites that do not have an NMEA-defined value.	
	Note: this does not apply to satellites with an unknown ID.	
Main Talker ID	By default the main Talker ID (i.e. the Talker ID used for all messages other than GSV) is	
	determined by the GNSS assignment of the receiver's channels (see UBX-CFG-GNSS).	
	This field enables the main Talker ID to be overridden.	
GSV Talker ID	By default the Talker ID for GSV messages is GNSS specific (as defined by NMEA). This	
	field enables the GSV Talker ID to be overridden.	
BDS Talker ID	By default the Talker ID for BeiDou is 'GB'. This field enableds the BeiDou Talker ID to be	
	overridden.	

20.1.4 Satellite Numbering

The NMEA protocol (V4.0) identifies satellites with a two digit number, reserving the numbers 1 to 32 for GPS, 33-64 for SBAS and 65-96 for GLONASS. So, for example, GLONASS SV4 is reported using number 68. u-blox receivers support this method in their NMEA output when "strict" SV numbering is selected. In most cases this is the default setting, but can be checked or set using UBX-CFG-NMEA.

Unfortunately there is currently no standard way of identifying satellites from any other GNSS within the NMEA protocol. In order to support QZSS within current receivers and prepare for support of other systems (e.g. Galileo) in future receivers, an "extended" SV numbering scheme can be enabled (using UBX-CFG-NMEA). This uses the NMEA-defined numbers where possible, but adds other number ranges to support other GNSS. Note however that these non-standard extensions require 3 digit numbers, which may not be supported by some NMEA parsing software. For example QZSS satellites are reported using numbers in the range 193 to 197.

See Satellite Numbering Summary for a complete list of satellite numbers.



GLONASS satellites can be tracked before they have been identified. In NMEA output, such unknown satellite numbers are always reported as a null field (i.e. an empty string).

20.1.5 Latitude and Longitude Format

According to the NMEA Standard, Latitude and Longitude are output in the format Degrees, Minutes and (Decimal) Fractions of Minutes. To convert to Degrees and Fractions of Degrees, or Degrees, Minutes, Seconds and Fractions of seconds, the 'Minutes' and 'Fractional Minutes' parts need to be converted. In other words: If the GPS Receiver reports a Latitude of 4717.112671 North and Longitude of 00833.914843 East, this is

Latitude 47 Degrees, 17.112671 Minutes

Longitude 8 Degrees, 33.914843 Minutes

or

Latitude 47 Degrees, 17 Minutes, 6.76026 Seconds

Longitude 8 Degrees, 33 Minutes, 54.89058 Seconds

or

Latitude 47.28521118 Degrees Longitude 8.56524738 Degrees





20.1.6 Position Fix Flags

This section shows how u-blox implements the NMEA protocol and the conditions determining how flags are set.

Flags in NMEA 2.3 and above

NMEA Message: Field	No position fix	GNSS fix, but	Dead	Dead reckoning	2D GNSS	3D GNSS	Combined
	(at power-up,	user limits	reckoning fix,	fix	fix	fix	GNSS/dead
	after losing	exceeded	but user limits				reckoning fix
	satellite lock)		exceeded				
GLL, RMC: status	V	V	V	A	А	А	А
	V=Data Invalid,	A=Data Valid					
GGA: quality	0	0	6	6	1/2	1/2	1/2
	0=No Fix, 1=Au	tonomous GNSS	Fix, 2=Differenti	al GNSS Fix, 6=Est	imated/Dea	nd Reckonir	ng Fix
GSA: navMode	1	1	2	2	2	3	3
	1=No Fix, 2=2D Fix, 3=3D Fix						
GLL, RMC, VTG, GNS: posMode	Ν	Ν	E	E	A/D	A/D	A/D
	N=No Fix, E=Estimated/Dead Reckoning Fix, A=Autonomous GNSS Fix, D=Differential GNSS Fix						

Flags in NMEA 2.1 and below

The flags in NMEA 2.1 and below are the same as NMEA 2.3 and above but with the following differences:

- The posMode field is not output for GLL, RMC and VTG messages (each message has one field less).
- The GGA quality field is set to 1 (instead of 6) For both types of dead reckoning fix.

Extra fields in NMEA 4.1 and above

Message	Extra fields	
GBS	systemId, signalId	
GNS	navStatus	
GRS	systemId, signalId	
GSA	systemId	
GSV	signalld	
RMC	navStatus	

20.1.7 Multi-GNSS considerations

Many applications which process NMEA messages assume that only a single GNSS is active. However, when multiple GNSS are configured, the NMEA specification requires the output to change in the following ways:

NMEA output for Multi-GNSS

Change	Description	
Main Talker ID	The main Talker ID will be 'GN' (e.g. instead of 'GP' for a GPS receiver)	
GSV Talker IDs	The GSV message reports the signal strength of the visible satellites. However,	
	the Talker ID it uses is specific to the GNSS it is reporting information for, so	
	for a multi-GNSS receiver it will not be the same as the main Talker ID. (e.g.	
	other messages will be using the 'GN' Talker ID but the GSV message will use	
	GNSS-sepcific Talker IDs)	
Multiple GSA and GRS	Multiple GSA and GRS messages are output for each fix, one for each GNSS.	
Messages	This may confuse applications which assume they are output only once per	
	position fix (as is the case for a single GNSS receiver).	



20.1.8 Output of Invalid/Unknown Data

By default the receiver will not output invalid data. In such cases, it will output empty fields.

A valid position fix is reported as follows:

\$GPGLL,4717.11634,N,00833.91297,E,124923.00,A,A*6E

An invalid position fix (but time valid) is reported as follows:

\$GPGLL,,,,,124924.00,V,N*42

If Time is unknown (e.g. during a cold-start):

\$GPGLL,,,,,,V,N*64

Note:



An exception from the above default are dead reckoning fixes, which are also output when invalid (user limits exceeded).



Output of invalid data marked with the 'Invalid/Valid' Flags can be enabled using the UBX protocol message CFG-NMEA.

i

Differing from the NMEA standard, u-blox reports valid dead reckoning fixes with user limits met (not exceeded) as valid (A) instead of invalid (V).

20.1.9 Messages Overview

When configuring NMEA messages using the UBX protocol message CFG-MSG, the Class/lds shown in the table shall be used.

Page	Mnemonic	Cls/ID	Description
	NMEA Standard Messages		Standard Messages
74	DTM	0xF0 0x0A	Datum Reference
75	GBQ	0xF0 0x44	Poll a standard message (if the current Talker ID is GB)
75	GBS	0xF0 0x09	GNSS Satellite Fault Detection
76	GGA	0xF0 0x00	Global positioning system fix data
78	GLL	0xF0 0x01	Latitude and longitude, with time of position fix and status
79	GLQ	0xF0 0x43	Poll a standard message (if the current Talker ID is GL)
79	GNQ	0xF0 0x42	Poll a standard message (if the current Talker ID is GN)
80	GNS	0xF0 0x0D	GNSS fix data
81	GPQ	0xF0 0x40	Poll a standard message (if the current Talker ID is GP)
81	GRS	0xF0 0x06	GNSS Range Residuals
82	GSA	0xF0 0x02	GNSS DOP and Active Satellites
83	GST	0xF0 0x07	GNSS Pseudo Range Error Statistics
84	GSV	0xF0 0x03	GNSS Satellites in View
85	RMC	0xF0 0x04	Recommended Minimum data
86	тхт	0xF0 0x41	Text Transmission
87	VLW	0xF0 0x0F	Dual ground/water distance
88	VTG	0xF0 0x05	Course over ground and Ground speed
89	ZDA	0xF0 0x08	Time and Date
	NMEA PUBX Messa	ages	Proprietary Messages
90	CONFIG	0xF1 0x41	Set Protocols and Baudrate



NMEA Messages Overview continued

Page	Mnemonic	Cls/ID	Description
91	POSITION	0xF1 0x00	Lat/Long Position Data
92	RATE	0xF1 0x40	Set NMEA message output rate
93	SVSTATUS	0xF1 0x03	Satellite Status
94	ТІМЕ	0xF1 0x04	Time of Day and Clock Information



20.2 Standard Messages

Standard Messages: i.e. Messages as defined in the NMEA Standard.

20.2.1 DTM

20.2.1.1 Datum Reference

Message	DTM	DTM			
Description	Datum Reference	Datum Reference			
Firmware	Supported on:				
 u-blox M8 from firmware version 2.00 up to version 2.30 					
Type	Output Message	Output Message			
Comment	This message gives the difference between the current datum and the reference da The current datum defaults to WGS84				
	The reference datum cannot be changed and is always set to WGS84.				
	ID for CFG-MSG Number of fields				
Message Info	0xF0 0x0A 11				

Message Structure:

\$xxDTM,datum,subDatum,lat,NS,lon,EW,alt,refDatum*cs<CR><LF>

Example:

\$GPDTM,W84,,0.0,N,0.0,E,0.0,W84*6F

\$GPDTM,999,,0.08,N,0.07,E,-47.7,W84*1C

	,,	,	, , , ,		
Field	Name	Unit	Format	Example	Description
No.					
0	XXDTM	-	string	\$GPDTM	DTM Message ID (xx = current Talker ID)
1	datum	-	string	W84	Local datum code: W84 = WGS84, 999 = user
					defined
2	subDatum	-	string	-	A null field
3	lat	min	numeric	0.08	Offset in Latitude
4	NS	-	character	S	North/South indicator
5	lon	min	numeric	0.07	Offset in Longitude
6	EW	-	character	E	East/West indicator
7	alt	m	numeric	-2.8	Offset in altitude
8	refDatum	-	string	W84	Reference datum code (always W84 = WGS 84)
9	CS	-	hexadecimal	*67	Checksum
10	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed



20.2.2 GBQ

20.2.2.1 Poll a standard message (if the current Talker ID is GB)

GBQ	GBQ				
Poll a standar	Poll a standard message (if the current Talker ID is GB)				
Supported on:					
• u-blox M8 fr	• u-blox M8 from firmware version 2.00 up to version 2.30				
Input Message	Input Message				
Polls a standard	Polls a standard NMEA message if the current Talker ID is GB				
ID for CFG-MSG	Number of fields				
0xF0 0x44	0xF0 0x44 4				
	Poll a standar Supported on: • u-blox M8 fr Input Message Polls a standard ID for CFG-MSG	Poll a standard message (if the Supported on: • u-blox M8 from firmware verse Input Message Polls a standard NMEA message ID for CFG-MSG			

Message Structure:

\$xxGLQ,msgId*cs<CR><LF>

Example:

\$EIGBQ,RMC*28

Field	Name	Unit	Format	Example	Description
No.					
0	xxGBQ	-	string	\$EIGBQ	GBQ Message ID (xx = Talker ID of the device
					requesting the poll)
1	msgId	-	string	RMC	Message ID of the message to be polled
2	CS	-	hexadecimal	*28	Checksum
3	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

20.2.3 GBS

20.2.3.1 GNSS Satellite Fault Detection

Message	GBS	GBS		
Description	GNSS Satellite F	GNSS Satellite Fault Detection		
Firmware	Supported on:			
	• u-blox M8 from	n firmware vers	ion 2.00 up to version 2.30	
Туре	Output Message			
Comment	of the Receiver Autonomous Integrity Monitoring errAlt output the standard deviation of the position which pass the RAIM test successfully. errAlt are only output if the RAIM process passed ful edits happened). These fields are never output if 4 or the navigation calculation (because, in such cases, integrity			
	 can not be determined by the receiver autonomously). The fields prob, bias and stdev are only output if at least one satellite failed in the 			
	RAIM test. If m		atellites fail the RAIM test, only the information for the	
	ID for CFG-MSG	Number of fields		
Message Info	0xF0 0x09	13		

Message Structure:

\$xxGBS,time,errLat,errLon,errAlt,svid,prob,bias,stddev,systemId,signalId*cs<CR><LF>



Example:

\$GPGI	BS,235503.00,	1.6,1	.4,3.2,,,,,*4	0	
\$GPGI	BS,235458.00,	1.4,1	.3,3.1,03,,-21	.4,3.8,1,0*5B	
Field	Name	Unit	Format	Example	Description
No.					
0	XXGBS	-	string	\$GPGBS	GBS Message ID (xx = current Talker ID)
1	time	-	hhmmss.ss	235503.00	UTC time to which this RAIM sentence belongs, see
					note on UTC representation
2	errLat	m	numeric	1.6	Expected error in latitude
3	errLon	m	numeric	1.4	Expected error in longitude
4	errAlt	m	numeric	3.2	Expected error in altitude
5	svid	-	numeric	03	Satellite ID of most likely failed satellite
6	prob	-	numeric	-	Probability of missed detection, not supported
					(empty)
7	bias	m	numeric	-21.4	Estimate on most likely failed satellite (a priori
					residual)
8	stddev	m	numeric	3.8	Standard deviation of estimated bias
9	systemId	-	numeric	1	NMEA defined GNSS System ID
					NMEA v4.1 and above only
10	signalId	-	numeric	0	NMEA defined GNSS Signal ID (0 = All signals)
					NMEA v4.1 and above only
11	CS	-	hexadecimal	*5B	Checksum
12	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

20.2.4 GGA

20.2.4.1 Global positioning system fix data

Message	GGA				
Description	Global positioning system fix data				
Firmware	Supported on:				
	• u-blox M8 fro	om firmware vers	ion 2.00 up to version 2.30		
Туре	Output Message	e			
Comment	The output of this message is dependent on the currently selected datum (default:				
	WGS84). The NMEA specification indicates that the GGA message is GPS specific.				
	However, when the receiver is configured for multi-GNSS, the GGA message				
	contents will be generated from the multi-GNSS solution. For multi-GNSS use, it is				
	recommended that the NMEA-GNS message is used instead.				
	n GPS fixing related data (number of satellites in use, and				
	rential data if in use, etc.).				
	ID for CFG-MSG	Number of fields			
Message Info	0xF0 0x00	17			

Message Structure:

\$xxGGA,time,lat,NS,long,EW,quality,numSV,HDOP,alt,M,sep,M,diffAge,diffStation*cs<CR><LF>

Example:

\$GPGGA,092725.00,4717.11399,N,00833.91590,E,1,08,1.01,499.6,M,48.0,M,,*5B



Field Name Unit Format Example Description No. Field Name Unit Format Description Example No. 0 \$GPGGA GGA Message ID (xx = current Talker ID) XXGGA string 092725.00 UTC time, see note on UTC representation 1 hhmmss.ss time 2 ddmm. 4717.11399 Latitude (degrees & minutes), see format description lat mmmmm 3 character Ν North/South indicator NS _ 4 dddmm. 00833.91590 Longitude (degrees & minutes), see format long mmmmm description 5 ΕW character Е East/West indicator 6 1 Quality indicator for position fix, see table below quality digit and position fix flags description Number of satellites used (range: 0-12) 7 numeric 08 numSV _ 8 HDOP numeric 1.01 Horizontal Dilution of Precision _ 9 alt numeric 499.6 Altitude above mean sea level m 10 Altitude units: meters (fixed field) Μ uAlt character 48.0 Geoid separation: difference between ellipsoid and 11 m numeric sep mean sea level 12 Μ Separation units: meters (fixed field) uSep _ character 13 Age of differential corrections (blank when DGPS is diffAge S numeric _ not used) 14 diffStat ID of station providing differential corrections (blank numeric -_ when DGPS is not used) ion 15 hexadecimal *5B Checksum cs Carriage return and line feed 16 <CR><LF> character

GGA continued

Table Quality Indicator

Quality Indicator	Description, see also position fix flags description		
0	No Fix / Invalid		
1	Standard GPS (2D/3D)		
2	Differential GPS		
6	Estimated (DR) Fix		



20.2.5 GLL

20.2.5.1 Latitude and longitude, with time of position fix and status

Message	GLL	GLL			
Description	Latitude and l	Latitude and longitude, with time of position fix and status			
Firmware	Supported on:	Supported on:			
	• u-blox M8 fr	om firmware version 2.00 up to version 2.30			
Туре	Output Messag	Output Message			
Comment	The output of	The output of this message is dependent on the currently selected datum (default:			
	WGS84)				
	-				
	ID for CFG-MSG	Number of fields			
Message Info	0xF0 0x01	10			

Message Structure:

\$xxGLL,lat,NS,long,EW,time,status,posMode*cs<CR><LF>

Example:

SGPGLL, 4717, 11364	N.00833.91565.	E,092321.00,A,A*60
QUI ULLI, 1/1/.11501	, 11, 000000.01000,	, E, 072521.00, A, A 00

Field	Name	Unit	Format	Example	Description	
No.						
0	XXGLL	-	string	\$GPGLL	GLL Message ID (xx = current Talker ID)	
1	lat	-	ddmm.	4717.11364	Latitude (degrees & minutes), see format description	
			mmmmm			
2	NS	-	character	N	North/South indicator	
3	long	-	dddmm.	00833.91565	Longitude (degrees & minutes), see format	
			mmmmm		description	
4	EW	-	character	E	East/West indicator	
5	time	-	hhmmss.ss	092321.00	UTC time, see note on UTC representation	
6	status	-	character	A	V = Data invalid or receiver warning, A = Data valid.	
					See position fix flags description.	
7	posMode	-	character	А	Positioning mode, see position fix flags description.	
					NMEA v2.3 and above only	
8	cs	-	hexadecimal	*60	Checksum	
9	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed	



20.2.6 GLQ

20.2.6.1 Poll a standard message (if the current Talker ID is GL)

GLQ	GLQ				
Poll a standar	Poll a standard message (if the current Talker ID is GL)				
Supported on:					
• u-blox M8 fr	• u-blox M8 from firmware version 2.00 up to version 2.30				
Input Message	Input Message				
Polls a standar	Polls a standard NMEA message if the current Talker ID is GL				
ID for CFG-MSG	Number of fields				
0xF0 0x43	0xF0 0x43 4				
	Poll a standar Supported on: • u-blox M8 fr Input Message Polls a standard ID for CFG-MSG	Poll a standard message (if the Supported on: • u-blox M8 from firmware verse Input Message Polls a standard NMEA message ID for CFG-MSG Number of fields			

Message Structure:

\$xxGLQ,msgId*cs<CR><LF>

Example:

\$EIGLQ,RMC*3A

	~ '				
Field	Name	Unit	Format	Example	Description
No.					
0	xxGLQ	-	string	\$EIGLQ	GLQ Message ID (xx = Talker ID of the device
					requesting the poll)
1	msgId	-	string	RMC	Message ID of the message to be polled
2	CS	-	hexadecimal	*3A	Checksum
3	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

20.2.7 GNQ

20.2.7.1 Poll a standard message (if the current Talker ID is GN)

Message	GNQ	GNQ			
Description	Poll a standard	l message (if th	e current Talker ID is GN)		
Firmware	Supported on:				
	• u-blox M8 fro	 u-blox M8 from firmware version 2.00 up to version 2.30 			
Туре	Input Message				
Comment	Polls a standard	Polls a standard NMEA message if the current Talker ID is GN			
	ID for CFG-MSG Number of fields				
Message Info	0xF0 0x42	4			

Message Structure:

\$xxGNQ,msgId*cs<CR><LF>

Example:

\$EIGN	NQ,RMC*3A				
Field	Name	Unit	Format	Example	Description
No.					
0	xxGNQ	-	string	\$EIGNQ	GNQ Message ID (xx = Talker ID of the device
					requesting the poll)
1	msgId	-	string	RMC	Message ID of the message to be polled
2	CS	-	hexadecimal	*3A	Checksum
3	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed



20.2.8 GNS

20.2.8.1 GNSS fix data

Message	GNS	GNS			
Description	GNSS fix data				
Firmware	Supported on:				
	• u-blox M8 fro	om firmware vers	ion 2.00 up to version 2.30		
Туре	Output Message	Output Message			
Comment	The output of	this message is	dependent on the currently selected datum (default:		
	WGS84)				
	Time and position	on, together with	n GNSS fixing related data (number of satellites in use, and		
	the resulting HD	the resulting HDOP, age of differential data if in use, etc.).			
	ID for CFG-MSG	ID for CFG-MSG Number of fields			
Message Info	0xF0 0x0D	16			

Message Structure:

xxGNS,time,lat,NS,long,EW,posMode,numSV,HDOP,alt,altRef,diffAge,diffStation,navStatus*cs<CR><LF>

Example:

\$GPGNS,091547.00,5114.50897,N,00012.28663,W,AA,10,0.83,111.1,45.6,,,V*71

Field	Name	Unit	Format	Example	Description
No.					
0	XXGNS	-	string	\$GPGNS	GNS Message ID (xx = current Talker ID)
1	time	-	hhmmss.ss	091547.00	UTC time, see note on UTC representation
2	lat	-	ddmm.	5114.50897	Latitude (degrees & minutes), see format description
			mmmmm		
3	NS	-	character	N	North/South indicator
4	long	-	dddmm.	00012.28663	Longitude (degrees & minutes), see format
			mmmmm		description
5	EW	-	character	E	East/West indicator
6	posMode	-	character	AA	Positioning mode, see position fix flags description.
					First character for GPS, second character for
					GLONASS
7	numSV	-	numeric	10	Number of satellites used (range: 0-99)
8	HDOP	-	numeric	0.83	Horizontal Dilution of Precision
9	alt	m	numeric	111.1	Altitude above mean sea level
10	sep	m	numeric	45.6	Geoid separation: difference between ellipsoid and
					mean sea level
11	diffAge	S	numeric	-	Age of differential corrections (blank when DGPS is
					not used)
12	diffStat	-	numeric	-	ID of station providing differential corrections (blank
	ion				when DGPS is not used)
13	navStatu	-	character	V	Navigational status indicator (V = Equipment is not
	s				providing navigational status information)
					NMEA v4.1 and above only
14	cs	-	hexadecimal	*71	Checksum
15	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed



20.2.9 GPQ

20.2.9.1 Poll a standard message (if the current Talker ID is GP)

GPQ	GPQ				
Poll a standar	Poll a standard message (if the current Talker ID is GP)				
Supported on:	upported on:				
• u-blox M8 fr	 u-blox M8 from firmware version 2.00 up to version 2.30 				
Input Message	Input Message				
Polls a standard	Polls a standard NMEA message if the current Talker ID is GP				
ID for CFG-MSG	Number of fields				
0xF0 0x40	4				
	Poll a standar Supported on: • u-blox M8 fr Input Message Polls a standard ID for CFG-MSG	Poll a standard message (if the Supported on: • u-blox M8 from firmware verse Input Message Polls a standard NMEA message ID for CFG-MSG			

Message Structure:

\$xxGPQ,msgId*cs<CR><LF>

Example:

\$EIGPQ,RMC*3A

Field	Name	Unit	Format	Example	Description
No.					
0	xxGPQ	-	string	\$EIGPQ	GPQ Message ID (xx = Talker ID of the device
					requesting the poll)
1	msgId	-	string	RMC	Message ID of the message to be polled
2	CS	-	hexadecimal	*3A	Checksum
3	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

20.2.10 GRS

20.2.10.1 GNSS Range Residuals

Message	GRS	GRS					
Description	GNSS Range	GNSS Range Residuals					
Firmware	Supported on:						
	• u-blox M8 fi	rom firmware ver	sion 2.00 up to version 2.30				
Туре	Output Messag	Output Message					
Comment	This messages relates to associated GGA and GSA messages.						
	If less than 12 SVs are available, the remaining fields are output empty. If more than 12 SVs are used, only the residuals of the first 12 SVs are output, in order to remain consistent with the NMEA standard.						
	In a multi-GNSS system this message will be output multiple times, once for each						
	GNSS.						
	ID for CFG-MSG	Number of fields					
Message Info	0xF0 0x06	19					

Message Structure:

\$xxGRS,time, mode {,residual},systemId,signalId*cs<CR><LF>

Example:

\$GPGRS,082632.00,1,0.54,0.83,1.00,1.02,-2.12,2.64,-0.71,-1.18,0.25,,,1,0*70

Field No.	Name	Unit	Format	Example	Description
0	XXGRS	-	string	\$GPGRS	GRS Message ID (xx = current Talker ID)



GRS continued

Field	Name	Unit	Format	Example	Description
No.					
1	time	-	hhmmss.ss	082632.00	UTC time of associated position fix, see note on
					UTC representation
2	mode	-	digit	1	Mode (see table below), u-blox receivers will always
					output Mode 1 residuals
Start c	of repeated block	(12 time	es)		
3 +	residual	m	numeric	0.54	Range residuals for SVs used in navigation. The SV
1*N					order matches the order from the GSA sentence.
End of	f repeated block	-			
15	systemId	-	numeric	1	NMEA defined GNSS System ID
					NMEA v4.1 and above only
16	signalId	-	numeric	0	NMEA defined GNSS Signal ID (0 = All signals)
					NMEA v4.1 and above only
17	CS	-	hexadecimal	*70	Checksum
18	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

Table Mode

Mode	Description
0	Residuals were used to calculate the position given in the matching GGA sentence.
1	Residuals were recomputed after the GGA position was computed.

20.2.11 GSA

20.2.11.1 GNSS DOP and Active Satellites

Message	GSA						
Description	GNSS DOP and Active Satellites						
Firmware	Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30						
Туре	Output Message						
Comment	 The GNSS receiver operating mode, satellites used for navigation, and DOP values. If less than 12 SVs are used for navigation, the remaining fields are left empty. If more than 12 SVs are used for navigation, only the IDs of the first 12 are output. The SV numbers (fields 'sv') are in the range of 1 to 32 for GPS satellites, and 33 to 64 for SBAS satellites (33 = SBAS PRN 120, 34 = SBAS PRN 121, and so on) In a multi-GNSS system this message will be output multiple times, once for each GNSS. 						
	ID for CFG-MSG Number of fields						
Message Info	0xF0 0x02 21						

Message Structure:

 $xxGSA, opMode, navMode{ , sv} , PDOP, HDOP, VDOP, systemId*cs<CR><LF>$

Example:

\$GPGSA, A, 3, 23, 29, 07, 08, 09, 18, 26, 28, , , , , 1.94, 1.18, 1.54, 1*0D

Field	Name	Unit	Format	Example	Description
No.					
0	xxGSA	-	string	\$GPGSA	GSA Message ID (xx = current Talker ID)



GSA continued

Field	Name	Unit	Format	Example	Description		
No.							
1	opMode	-	character	A	Operation mode, see first table below		
2	navMode	-	digit	3	Navigation mode, see second table below and		
					position fix flags description		
Start c	of repeated block	(12 tim	es)				
3 +	sv	-	numeric	29	Satellite number		
1*N							
End of	f repeated block	•		•			
15	PDOP	-	numeric	1.94	Position dilution of precision		
16	HDOP	-	numeric	1.18	Horizontal dilution of precision		
17	VDOP	-	numeric	1.54	Vertical dilution of precision		
18	systemId	-	numeric	1	NMEA defined GNSS System ID		
					NMEA v4.1 and above only		
19	CS	-	hexadecimal	*0D	Checksum		
20	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed		

Table Operation Mode

Operation Mode	Description		
Μ	Manually set to operate in 2D or 3D mode		
А	Automatically switching between 2D or 3D mode		

Table Navigation Mode

Navigation Mode	Description, see also position fix flags description				
1	Fix not available				
2	2D Fix				
3	3D Fix				

20.2.12 GST

20.2.12.1 GNSS Pseudo Range Error Statistics

Message	GST	GST				
Description	GNSS Pseudo I	GNSS Pseudo Range Error Statistics				
Firmware	Supported on:	Supported on:				
	• u-blox M8 fro	om firmware vers	ion 2.00 up to version 2.30			
Туре	Output Message	e				
Comment	This message re	ports statisical in	formation on the quality of the position solution.			
	ID for CFG-MSG Number of fields					
Message Info	0xF0 0x07	11				

Message Structure:

\$xxGST,time,rangeRms,stdMajor,stdMinor,orient,stdLat,stdLong,stdAlt*cs<CR><LF>

Example:

\$GPGST,082356.00,1.8,,,,1.7,1.3,2.2*7E

Field	Name	Unit	Format	Example	Description
No.					
0	XXGST	-	string	\$GPGST	GST Message ID (xx = current Talker ID)



GST continued

Field	Name	Unit	Format	Example	Description
No.					
1	time	-	hhmmss.ss	082356.00	UTC time of associated position fix, see note on
					UTC representation
2	rangeRms	m	numeric	1.8	RMS value of the standard deviation of the ranges
3	stdMajor	m	numeric	-	Standard deviation of semi-major axis (blank - not
					supported)
4	stdMinor	m	numeric	-	Standard deviation of semi-minor axis (blank - not
					supported)
5	orient	deg	numeric	-	Orientation of semi-major axis (blank - not
					supported)
6	stdLat	m	numeric	1.7	Standard deviation of latitude error
7	stdLong	m	numeric	1.3	Standard deviation of longitude error
8	stdAlt	m	numeric	2.2	Standard deviation of altitude error
9	CS	-	hexadecimal	*7E	Checksum
10	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

20.2.13 GSV

20.2.13.1 GNSS Satellites in View

Message	GSV	GSV					
Description	GNSS Satellites	GNSS Satellites in View					
Firmware	Supported on:	Supported on:					
	 u-blox M8 fro 	m firmware vers	ion 2.00 up to version 2.30				
Туре	Output Message	Output Message					
Comment	The number of s	atellites in view,	together with each SV ID, elevation azimuth, and signal				
	strength (C/No)	value. Only four	satellite details are transmitted in one message.				
	In a multi-GNS	5 system sets o	f GSV messages will be output multiple times, one				
	set for each GN	set for each GNSS.					
	ID for CFG-MSG	ID for CFG-MSG Number of fields					
Message Info	0xF0 0x03	816					

Message Structure:

\$xxGSV,numMsg,msgNum,numSV,{,sv,elv,az,cno},signalId*cs<CR><LF>

Example:

SGPGSV,3,1,10,23,38,230,44,29,71,156,47,07,29,116,41,08,09,081,36,0*7F

\$GPGSV,3,2,10,10,07,189,,05,05,220,09,34,274,42,18,25,309,44,0*72

\$GPGSV,3,3,10,26,82,187,47,28,43,056,46,0*77

Field	Name	Unit	Format	Example	Description	
No.						
0	XXGSV	-	string	\$GPGSV	GSV Message ID (xx = GSV Talker ID)	
1	numMsg	-	digit	3	Number of messages, total number of GSV	
					messages being output	
2	msgNum	-	digit	1	Number of this message	
3	numSV	-	numeric	10	Number of satellites in view	
Start c	f repeated block	(14 tin	nes)	•		

Start of repeated block (1..4 times)



GSV continued

Field	Name	Unit	Format	Example	Description
No.					
4 +	sv	-	numeric	23	Satellite ID
4*N					
5 +	elv	deg	numeric	38	Elevation (range 0-90)
4*N					
6 +	az	deg	numeric	230	Azimuth, (range 0-359)
4*N					
7 +	cno	dBH	numeric	44	Signal strength (C/N0, range 0-99), blank when not
4*N		Z			tracking
End of	frepeated block				
5	signalId	-	numeric	0	NMEA defined GNSS Signal ID (0 = All signals)
16					NMEA v4.1 and above only
6	CS	-	hexadecimal	*7F	Checksum
16					
7	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed
16					

20.2.14 RMC

20.2.14.1 Recommended Minimum data

Message	RMC	RMC					
Description	Recommended	Recommended Minimum data					
Firmware	Supported on:	Supported on:					
	• u-blox M8 fro	om firmware vers	ion 2.00 up to version 2.30				
Туре	Output Messag	Output Message					
Comment	The output of	this message is	dependent on the currently selected datum (default:				
	WGS84)						
	The recommend	The recommended minimum sentence defined by NMEA for GNSS system data.					
	ID for CFG-MSG	Number of fields					
Message Info	0xF0 0x04	16					

Message Structure:

\$xxRMC,time,status,lat,NS,long,EW,spd,cog,date,mv,mvEW,posMode,navStatus*cs<CR><LF>

Example:

\$GPRMC,083559.00,A,4717.11437,N,00833.91522,E,0.004,77.52,091202,,,A,V*57

Field	Name	Unit	Format	Example	Description
No.					
0	xxRMC	-	string	\$GPRMC	RMC Message ID (xx = current Talker ID)
1	time	-	hhmmss.ss	083559.00	UTC time, see note on UTC representation
2	status	-	character	А	Status, V = Navigation receiver warning, A = Data
					valid, see position fix flags description
3	lat	-	ddmm.	4717.11437	Latitude (degrees & minutes), see format description
			mmmmm		
4	NS	-	character	Ν	North/South indicator



RMC continued

Field	Name	Unit	Format	Example	Description
No.					
5	long	-	dddmm.	00833.91522	Longitude (degrees & minutes), see format
			mmmmm		description
6	EW	-	character	E	East/West indicator
7	spd	knot	numeric	0.004	Speed over ground
		S			
8	cog	degr	numeric	77.52	Course over ground
		ees			
9	date	-	ddmmyy	091202	Date in day, month, year format, see note on UTC
					representation
10	mv	degr	numeric	-	Magnetic variation value (blank - not supported)
		ees			
11	mvE₩	-	character	-	Magnetic variation E/W indicator (blank - not
					supported)
12	posMode	-	character	-	Mode Indicator, see position fix flags description
					NMEA v2.3 and above only
13	navStatu	-	character	V	Navigational status indicator (V = Equipment is not
	S				providing navigational status information)
					NMEA v4.1 and above only
14	CS	-	hexadecimal	*57	Checksum
15	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

20.2.15 TXT

20.2.15.1 Text Transmission

Message	ТХТ	тхт					
Description	Text Transmissi	Text Transmission					
Firmware	Supported on:	Supported on:					
	• u-blox M8 from	n firmware vers	ion 2.00 up to version 2.30				
Туре	Output Message	Output Message					
Comment	This message is	not configure	d through UBX-CFG-MSG, but instead through				
	UBX-CFG-INF.						
	This message out	puts various inf	ormation on the receiver, such as power-up screen,				
	software version	etc. This messag	ge can be configured using UBX Protocol message				
	UBX-CFG-INF.	UBX-CFG-INF.					
	ID for CFG-MSG	Number of fields					
Message Info	0xF0 0x41 7	7					

Message Structure:

\$xxTXT,numMsg,msgNum,msgType,text*cs<CR><LF>

Example:

\$GPTXT,01,01,02,u-blox ag - www.u-blox.com*50

\$GPTXT,01,01,02,ANTARIS ATR0620 HW 00000040*67

Field	Name	Unit	Format	Example	Description
No.					



TXT continued

Field	Name	Unit	Format	Example	Description
No.					
0	XXTXT	-	string	\$GPTXT	TXT Message ID (xx = current Talker ID)
1	numMsg	-	numeric	01	Total number of messages in this transmission, 01
					99
2	msgNum	-	numeric	01	Message number in this transmission, range 01xx
3	msgType	-	numeric	02	Text identifier, u-blox GNSS receivers specify the
					type of the message with this number.
					00: Error
					01: Warning
					02: Notice
					07: User
4	text	-	string	www.u-blox.	Any ASCII text
				com	
5	CS	-	hexadecimal	*67	Checksum
6	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

20.2.16 VLW

20.2.16.1 Dual ground/water distance

Message	VLW	VLW				
Description	Dual ground/v	vater distance				
Firmware	Supported on:					
	• u-blox M8 fro	om firmware vers	ion 2.00 up to version 2.30			
Туре	Output Message	ē				
Comment	The distance tra	veled, relative to	the water and over the ground.			
	ID for CFG-MSG	Number of fields				
Message Info	0xF0 0x0F	11				

Message Structure:

\$xxVLW,twd,twdUnit,wd,wdUnit,tgd,tgdUnit,gd,gdUnit*cs<CR><LF>

Example:

\$GPVLW,,N,,N,15.8,N,1.2,N*06

Field	Name	Unit	Format	Example	Description
No.					
0	XXVLW	-	string	\$GPVLW	VLW Message ID (xx = current Talker ID)
1	twd	nm	numeric	-	Total cumulative water distance, not output
2	twdUnit	-	character	N	Fixed field: nautical miles
3	wd	nm	numeric	-	Water distance since reset, not output
4	wdUnit	-	character	Ν	Fixed field: nautical miles
5	tgd	nm	numeric	15.8	Total cumulative ground distance
6	tgdUnit	-	character	N	Fixed field: nautical miles
7	gd	nm	numeric	1.2	Ground distance since reset
8	gdUnit	-	character	N	Fixed field: nautical miles
9	CS	-	hexadecimal	*06	Checksum
10	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed



20.2.17 VTG

20.2.17.1 Course over ground and Ground speed

Message	VTG	VTG				
Description	Course over g	Course over ground and Ground speed				
Firmware	Supported on: • u-blox M8 fr	Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30				
Туре	Output Messag	е				
Comment	Velocity is giver	n as Course over	Ground (COG) and Speed over Ground (SOG).			
	ID for CFG-MSG	Number of fields				
Message Info	0xF0 0x05	12				

Message Structure:

\$xxVTG,cogt,T,cogm,M,knots,N,kph,K,posMode*cs<CR><LF>

Example:

\$GPVTG,77.52,T,,M,0.004,N,0.008,K,A*06

701 V						
Field	Name	Unit	Format	Example	Description	
No.						
0	XXVTG	-	string	\$GPVTG	VTG Message ID (xx = current Talker ID)	
1	cogt	degr	numeric	77.52	Course over ground (true)	
		ees				
2	Т	-	character	Т	Fixed field: true	
3	cogm	degr	numeric	-	Course over ground (magnetic), not output	
		ees				
4	М	-	character	М	Fixed field: magnetic	
5	knots	knot	numeric	0.004	Speed over ground	
		s				
6	N	-	character	N	Fixed field: knots	
7	kph	km/	numeric	0.008	Speed over ground	
		h				
8	К	-	character	К	Fixed field: kilometers per hour	
9	posMode	-	character	A	Mode Indicator, see position fix flags description	
					NMEA v2.3 and above only	
10	CS	-	hexadecimal	*06	Checksum	
11	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed	



20.2.18 ZDA

20.2.18.1 Time and Date

Message	ZDA	ZDA				
Description	Time and Dat	e				
Firmware	Supported on:					
	 u-blox M8 fr 	om firmware version 2.00 up to version 2.30				
Type	Output Messag	je				
Comment	-					
	ID for CFG-MSG	Number of fields				
Message Info	0xF0 0x08	9				


Message Structure:

xxZDA,hhmmss.ss,day,month,year,ltzh,ltzn*cs<CR><LF>

Example:

\$GPZDA,082710.00,16,09,2002,00,00*64

Field	Name	Unit	Format	Example	Description
No.					
0	xxZDA	-	string	\$GPZDA	ZDA Message ID (xx = current Talker ID)
1	time	-	hhmmss.ss	082710.00	UTC Time, see note on UTC representation
2	day	day	dd	16	UTC day (range: 1-31)
3	month	mon	mm	09	UTC month (range: 1-12)
		th			
4	year	year	уууу	2002	UTC year
5	ltzh	-	-XX	00	Local time zone hours (fixed to 00)
6	ltzn	-	ZZ	00	Local time zone minutes (fixed to 00)
7	CS	-	hexadecimal	*64	Checksum
8	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed





20.3 PUBX Messages

Proprietary Messages: i.e. Messages defined by u-blox.

20.3.1 CONFIG (PUBX,41)

20.3.1.1 Set Protocols and Baudrate

Message	CONFIG	CONFIG			
Description	Set Protocols	and Baudrate			
Firmware	Supported on:				
	• u-blox M8 fr	om firmware vers	ion 2.00 up to version 2.30		
Туре	Set Message				
Comment	-				
	ID for CFG-MSG	Number of fields			
Message Info	0xF1 0x41	9			

Message Structure:

 $\texttt{PUBX,41,portId,inProto,outProto,baudrate,autobauding\texttt{*cs<CR><LF>}$

Example:

\$PUBX,41,1,0007,0003,19200,0*25

\$PUB2	PUBX, 41, 1, 0007, 0003, 19200, 0*25					
Field	Name	Unit	Format	Example	Description	
No.						
0	\$PUBX	-	string	\$PUBX	Message ID, UBX protocol header, proprietary	
					sentence	
1	msgId	-	numeric	41	Proprietary message identifier	
2	portId	-	numeric	1	ID of communication port. For a list of port IDs see	
					Serial Communication Ports Description.	
3	inProto	-	hexadecimal	0007	Input protocol mask. Bitmask, specifying which	
					protocols(s) are allowed for input. For details see	
					corresponding field in UBX-CFG-PRT.	
4	outProto	-	hexadecimal	0003	Output protocol mask. Bitmask, specifying which	
					protocols(s) are allowed for input. For details see	
					corresponding field in UBX-CFG-PRT.	
5	baudrate	bits/	numeric	19200	Baudrate	
		S				
6	autobaud	-	numeric	0	Autobauding: 1=enable, 0=disable (not supported	
	ing				on u-blox 5, set to 0)	
7	CS	-	hexadecimal	*25	Checksum	
8	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed	



20.3.2 POSITION (PUBX,00)

20.3.2.1 Lat/Long Position Data

Message	POSITION	POSITION				
Description	Lat/Long Posit	ion Data				
Firmware	Supported on:	Supported on:				
	• u-blox M8 fro	om firmware vers	ion 2.00 up to version 2.30			
Туре	Output Message	Output Message				
Comment	The output of	this message is	dependent on the currently selected datum (default:			
	WGS84)					
	This message co	ontains position s	olution data. The datum selection may be changed using			
	the message UE	X-CFG-DAT.				
	ID for CFG-MSG	Number of fields				
Message Info	0xF1 0x00	23				

Message Structure:

\$PUBX,00,time,lat,NS,long,EW,altRef,navStat,hAcc,vAcc,SOG,COG,vVel,diffAge,HDOP,VDOP,TDOP,numSvs,re

served,DR,*cs<CR><LF>

Example:

\$PUBX,00,081350.00,4717.113210,N,00833.915187,E,546.589,G3,2.1,2.0,0.007,77.52,0.007,,0.92,1.19,0.7

7,9,0,0*5F

,,,,,	J,0~5F				
Field No.	Name	Unit	Format	Example	Description
0	\$PUBX	-	string	\$PUBX	Message ID, UBX protocol header, proprietary
					sentence
1	msgId	-	numeric	00	Proprietary message identifier: 00
2	time	-	hhmmss.ss	081350.00	UTC time, see note on UTC representation
3	lat	-	ddmm.	4717.113210	Latitude (degrees & minutes), see format description
			mmmmm		
4	NS	-	character	N	North/South Indicator
5	long	-	dddmm.	00833.915187	Longitude (degrees & minutes), see format
			mmmmm		description
6	EW	-	character	E	East/West indicator
7	altRef	m	numeric	546.589	Altitude above user datum ellipsoid.
8	navStat	-	string	G3	Navigation Status, See Table below
9	hAcc	m	numeric	2.1	Horizontal accuracy estimate.
10	vAcc	m	numeric	2.0	Vertical accuracy estimate.
11	SOG	km/	numeric	0.007	Speed over ground
		h			
12	COG	deg	numeric	77.52	Course over ground
13	vVel	m/s	numeric	0.007	Vertical velocity (positive downwards)
14	diffAge	S	numeric	-	Age of differential corrections (blank when DGPS is
					not used)
15	HDOP	-	numeric	0.92	HDOP, Horizontal Dilution of Precision
16	VDOP	-	numeric	1.19	VDOP, Vertical Dilution of Precision
17	TDOP	-	numeric	0.77	TDOP, Time Dilution of Precision
18	numSvs	-	numeric	9	Number of satellites used in the navigation solution



POSITION continued

Field	Name	Unit	Format	Example	Description
No.					
19	reserved	-	numeric	0	Reserved, always set to 0
20	DR	-	numeric	0	DR used
21	cs	-	hexadecimal	*5B	Checksum
22	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

Table Navigation Status

Navigation Status	Description
NF	No Fix
DR	Dead reckoning only solution
G2	Stand alone 2D solution
G3	Stand alone 3D solution
D2	Differential 2D solution
D3	Differential 3D solution
RK	Combined GPS + dead reckoning solution
TT	Time only solution

20.3.3 RATE (PUBX,40)

20.3.3.1 Set NMEA message output rate

Message	RATE	RATE					
Description	Set NMEA me	Set NMEA message output rate					
Firmware	Supported on:	Supported on:					
	• u-blox M8 fro	• u-blox M8 from firmware version 2.00 up to version 2.30					
Туре	Set Message						
Comment	Set/Get messag	e rate configurat	ion (s) to/from the receiver.				
	• Send rate is r	elative to the eve	ent a message is registered on. For example, if the rate of a				
	navigation m	essage is set to 2	, the message is sent every second navigation solution.				
	ID for CFG-MSG	ID for CFG-MSG Number of fields					
Message Info	0xF1 0x40	11					

Message Structure:

\$PUBX,40,msgId,rddc,rus1,rus2,rusb,rspi,reserved*cs<CR><LF>

Example:

\$PUBX,40,GLL,1,0,0,0,0,0*5D

Field	Name	Unit	Format	Example	Description
No.	Name	Unit	Tonnat	LXample	Description
0	\$PUBX	-	string	\$PUBX	Message ID, UBX protocol header, proprietary
					sentence
1	ID	-	numeric	40	Proprietary message identifier
2	msgId	-	string	GLL	NMEA message identifier
3	rddc	cycl	numeric	1	output rate on DDC
		es			0 disables that message from being output on this
					port
					1 means that this message is output every epoch





RATE continued

Field	Name	Unit	Format	Example	Description
No.					
4	rus1	cycl	numeric	1	output rate on USART 1
		es			0 disables that message from being output on this
					port
					1 means that this message is output every epoch
5	rus2	cycl	numeric	1	output rate on USART 2
		es			0 disables that message from being output on this
					port
					1 means that this message is output every epoch
6	rusb	cycl	numeric	1	output rate on USB
		es			0 disables that message from being output on this
					port
					1 means that this message is output every epoch
7	rspi	cycl	numeric	1	output rate on SPI
		es			0 disables that message from being output on this
					port
					1 means that this message is output every epoch
8	reserved	-	numeric	0	Reserved: always fill with 0
9	CS	-	hexadecimal	*5D	Checksum
10	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed

20.3.4 SVSTATUS (PUBX,03)

20.3.4.1 Satellite Status

Message	SVSTATUS	SVSTATUS					
Description	Satellite Status	Satellite Status					
Firmware	Supported on:	Supported on:					
	 u-blox M8 fro 	 u-blox M8 from firmware version 2.00 up to version 2.30 					
Туре	Output Message	5					
Comment	The PUBX,03 me	essage contains s	satellite status information.				
	ID for CFG-MSG	ID for CFG-MSG Number of fields					
Message Info	0xF1 0x03	5 + 6*n					

Message Structure:

\$PUBX,03,GT{,sv,s,az,el,cno,lck},*cs<CR><LF>

Example:

\$PUBX,03,11,23,-,,,45,010,29,-,,,46,013,07,-,,,42,015,08,U,067,31,42,025,10,U,195,33,46,026,18,U,32

6, 08, 39, 026, 17, -, ,, 32, 015, 26, U, 306, 66, 48, 025, 27, U, 073, 10, 36, 026, 28, U, 089, 61, 46, 024, 15, -, ,, 39, 014*0D

Field	Name	Unit	Format	Example	Description	
No.						
0	\$PUBX	-	string	\$PUBX	Message ID, UBX protocol header, proprietary	
					sentence	
1	msgId	-	numeric	03	Proprietary message identifier: 03	
2	n	-	numeric	11	Number of GNSS satellites tracked	
Start o	Start of repeated block (n times)					

epe . (/



SVSTATUS continued

Field	Name	Unit	Format	Example	Description
No.					
3 +	sv	-	numeric	23	Satellite ID according to UBX svld mapping (see
6*N					section satellite numbering)
4 +	S	-	character	-	Satellite status, see table below
6*N					
5 +	az	deg	numeric	-	Satellite azimuth (range: 0-359)
6*N					
6+	el	deg	numeric	-	Satellite elevation (range: 0-90)
6*N					
7 +	cno	dBH	numeric	45	Signal strength (C/N0, range 0-99), blank when not
6*N		Z			tracking
8 +	lck	S	numeric	010	Satellite carrier lock time (range: 0-64)
6*N					0: code lock only
					64: lock for 64 seconds or more
End of	repeated block				
3 +	CS	-	hexadecimal	*0D	Checksum
6*n					
4 +	<cr><lf></lf></cr>	-	character	-	Carriage return and line feed
6*n					

Table Satellite Status

Satellite Status	Description
-	Not used
U	Used in solution
е	Ephemeris available, but not used for navigation

20.3.5 TIME (PUBX,04)

20.3.5.1 Time of Day and Clock Information

Message	TIME	TIME					
Description	Time of Day a	Time of Day and Clock Information					
Firmware	Supported on:	Supported on:					
	• u-blox M8 fr	 u-blox M8 from firmware version 2.00 up to version 2.30 					
Туре	Output Messag	Output Message					
Comment	-						
	ID for CFG-MSG	Number of fields					
Message Info	0xF1 0x04	12					

Message Structure:

\$PUBX,04,time,date,utcTow,utcWk,leapSec,clkBias,clkDrift,tpGran,*cs<CR><LF>

Example:

\$PUBX,04,073731.00,091202,113851.00,1196,15D,1930035,-2660.664,43,*3C

Field	Name	Unit	Format	Example	Description
No.					
0	\$PUBX	-	string	\$PUBX	Message ID, UBX protocol header, proprietary
					sentence



Field	Name	Unit	Format	Example	Description		
No.							
1	msgId	-	numeric	04	Proprietary message identifier: 04		
2	time	-	hhmmss.ss	073731.00	UTC time, see note on UTC representation		
3	date	-	ddmmyy	091202	UTC date, day, month, year format, see note on		
					UTC representation		
4	utcTow	S	numeric	113851.00	UTC Time of Week		
5	utcWk	-	numeric	1196	UTC week number, continues beyond 1023		
6	leapSec	S	numeric/text	15D	Leap seconds		
					The number is marked with a 'D' if the value is the		
				firmware default value. If the value is not marked it			
					has been received from a satellite.		
7	clkBias	ns	numeric	1930035	Receiver clock bias		
8	clkDrift	ns/s	numeric	-2660.664	Receiver clock drift		
9	tpGran	ns	numeric	43	Time Pulse Granularity, The quantization error of the		
					TIMEPULSE pin		
10	CS	-	hexadecimal	*3C	Checksum		
11	<cr><lf></lf></cr>	-	character	-	Carriage Return and Line Feed		

TIME continued

21 UBX Protocol


21.1 UBX Protocol Key Features

u-blox GNSS receivers support a u-blox proprietary protocol to communicate with a host computer. This protocol has the following key features:

- Compact uses 8 Bit Binary Data.
- Checksum Protected uses a low-overhead checksum algorithm
- Modular uses a 2-stage message identifier (Class and Message ID)

21.2 UBX Packet Structure

A basic UBX Packet looks as follows:



- Every Message starts with 2 Bytes: 0xB5 0x62
- A 1 Byte Class Field follows. The Class defines the basic subset of the message
- A 1 Byte ID Field defines the message that is to follow



- A 2 Byte Length Field is following. Length is defined as being the length of the payload, only. It does not include Sync Chars, Length Field, Class, ID or CRC fields. The number format of the length field is an unsigned 16-Bit integer in Little Endian Format.
- The Payload is a variable length field.
- CK_A and CK_B is a 16 Bit checksum whose calculation is defined below.

21.3 UBX Payload Definition Rules

21.3.1 Structure Packing

Values are placed in an order that structure packing is not a problem. This means that 2 byte values shall start on offsets which are a multiple of 2, 4 byte values shall start at a multiple of 4, and so on.

21.3.2 Reserved Elements

Some messages contain reserved fields or bits to allow for future expansion. The contents of these elements should be ignored in output messages and must be set to zero in input messages. Where a message is output and subsequently returned to the receiver as input message, reserved elements can either be explicitly set to zero or left with whatever value they were output with.

21.3.3 Undefined Values

The description of some fields provide specific meanings for specific values. For example, the field gnssld appears in many UBX messages and uses 0 to indicate GPS, 1 for SBAS and so on (see Satellite Numbering for details); however it is usually stored in a byte with far more possible values than the handful currently defined. All such undefined values are reserved for future expansion and therefore should not be used.

21.3.4 Message Naming

Referring to messages is done by adding the class name and a dash in front of the message name. For example, the ECEF-Message is referred to as UBX-NAV-POSECEF. Referring to values is done by adding a dash and the name, e.g. UBX-NAV-POSECEF-X

21.3.5 Number Formats

All multi-byte values are ordered in Little Endian format, unless otherwise indicated.

All floating point values are transmitted in IEEE754 single or double precision.

Variable Type Definitions

Short	Туре	Size	Comment	Min/Max	Resolution
		(Bytes)			
U1	Unsigned Char	1		0255	1
RU1_3	Unsigned Char	1	binary floating	0(31*2^7)	~ 2^(Value >> 5)
			point with 3 bit	non-continuous	
			exponent, eeeb		
			bbbb, (Value &		
			0x1F) << (Value		
			>> 5)		
11	Signed Char	1	2's complement	-128127	1
X1	Bitfield	1		n/a	n/a
U2	Unsigned Short	2		065535	1
12	Signed Short	2	2's complement	-3276832767	1




Variable Type Definitions continued

Short	Туре	Size	Comment	Min/Max	Resolution
		(Bytes)			
X2	Bitfield	2		n/a	n/a
U4	Unsigned Long	4		04 '294'967'295	1
14	Signed Long	4	2's complement	-2'147'483'648	1
				2'147'483'647	
X4	Bitfield	4		n/a	n/a
R4	IEEE 754 Single Precision	4		-1*2^+127	~ Value * 2^-24
				2^+127	
R8	IEEE 754 Double Precision	8		-1*2^+1023	~ Value * 2^-53
				2^+1023	
СН	ASCII / ISO 8859.1 Encoding	1			

21.4 UBX Checksum

The checksum is calculated over the packet, starting and including the CLASS field, up until, but excluding, the Checksum Field:



The checksum algorithm used is the 8-Bit Fletcher Algorithm, which is used in the TCP standard (<u>RFC 1145</u>). This algorithm works as follows:

Buffer[N] contains the data over which the checksum is to be calculated.

The two CK_ values are 8-Bit unsigned integers, only! If implementing with larger-sized integer values, make sure to mask both CK_A and CK_B with 0xFF after both operations in the loop.

```
CK_A = 0, CK_B = 0
For(I=0;I<N;I++)
{
     CK_A = CK_A + Buffer[I]
     CK_B = CK_B + CK_A
}</pre>
```

After the loop, the two U1 values contain the checksum, transmitted at the end of the packet.

21.5 UBX Message Flow

There are certain features associated with the messages being sent back and forth:

21.5.1 Acknowledgement

When messages from the class CFG are sent to the receiver, the receiver will send an "acknowledge" (ACK-AC K) or a "not acknowledge" (ACK-NAK) message back to the sender, depending on whether or not the message was processed correctly.



Some messages from other classes (e.g. LOG) also use the same acknowledgement mechanism.

21.5.2 Polling Mechanism

All messages that are output by the receiver in a periodic manner (i.e. messages in classes MON, NAV and RXM) can also be polled.

The UBX protocol is designed so that messages can be polled by sending the message required to the receiver but without a payload (or with just a single parameter that identifies the poll request). The receiver then responds with the same message with the payload populated.

21.6 UBX Satellite Numbering

UBX protocol messages use two different numbering schemes. Many UBX messages (e.g. UBX-NAV-SVINFO) use a single byte for the satellite identifier (normally named "svid"). This uses numbering similar to the "extended" NMEA scheme and is merely an extension of the scheme in use for previous generations of u-blox receivers.

With ever increasing numbers of GNSS satellites, this scheme will have to be phased out in future u-blox receivers (as numbers greater than 255 will become necessary). Consequently, newer messages use a more sophisticated, flexible and future-proof approach. This involves having a separate *gnssld* to identify which GNSS type the satellite is part of and a simple *svld* which indicates which number the satellite is in that system. In nearly all cases, this means that the "svld" is the natural number associated with the satellite. For example the GLONASS SV4 is identified as *gnssld* 6, *svld* 4, while the GPS SV4 is *gnssld* 0, *svld* 4.

See Satellite Numbering Summary for a complete list of satellite numbers.

GNSS Identifiers

gnssld	GNSS Type
0	GPS
1	SBAS
2	Galileo
3	BeiDou
4	IMES
5	QZSS
6	GLONASS

Other values will be added as support for other GNSS types is enabled in u-blox receivers.



GLONASS satellites can be tracked before they have been identified. In UBX messages, such unknown satellite numbers are always reported with svid 255.

21.7 UBX Class IDs

A class is a grouping of messages which are related to each other. The following table lists all the current message classes.

Name	Class	Description
NAV	0x01	Navigation Results: Position, Speed, Time, Acceleration, Heading, DOP, SVs used
RXM	0x02	Receiver Manager Messages: Satellite Status, RTC Status
INF	0x04	Information Messages: Printf-Style Messages, with IDs such as Error, Warning, Notice
ACK	0x05	Ack/Nack Messages: as replies to CFG Input Messages
CFG	0x06	Configuration Input Messages: Set Dynamic Model, Set DOP Mask, Set Baud Rate, etc.
UPD	0x09	Firmware Update Messages: Memory/Flash erase/write, Reboot, Flash identification, etc.
MON	0x0A	Monitoring Messages: Comunication Status, CPU Load, Stack Usage, Task Status



UBX Class IDs continued

Class	Description
0x0B	AssistNow Aiding Messages: Ephemeris, Almanac, other A-GPS data input
0x0D	Timing Messages: Time Pulse Output, Timemark Results
0x13	Multi-GNSS Assistance: Assistance data for various GNSS
0x21	Logging Messages: Log creation, deletion, info and retrieval
	0x0B 0x0D 0x13

All remaining class IDs are reserved.



21.8 UBX Messages Overview

Page	Mnemonic	Cls/ID	Length	Туре	Description
	UBX C	ass ACK		Ack/Nack Messages	
105	ACK-ACK	0x05 0x01	2	Output	Message Acknowledged
105	ACK-NAK	0x05 0x00	2	Output	Message Not-Acknowledged
	UBX C	lass AID	•	AssistNow Aiding Me	ssages
106	AID-ALM	0x0B 0x30	0	Poll Request	Poll GPS Aiding Almanac Data
106	AID-ALM	0x0B 0x30	1	Poll Request	Poll GPS Aiding Almanac Data for a SV
107	AID-ALM	0x0B 0x30	(8) or (40)	Input/Output	GPS Aiding Almanac Input/Output Message
107	AID-AOP	0x0B 0x33	0	Poll request	Poll AssistNow Autonomous data, all satellites
108	AID-AOP	0x0B 0x33	1	Poll request	Poll AssistNow Autonomous data, one GPS
108	AID-AOP	0x0B 0x33	68	Input/Output	AssistNow Autonomous data
109	AID-EPH	0x0B 0x31	0	Poll Request	Poll GPS Aiding Ephemeris Data
110	AID-EPH	0x0B 0x31	1	Poll Request	Poll GPS Aiding Ephemeris Data for a SV
110	AID-EPH	0x0B 0x31	(8) or (104)	Input/Output	GPS Aiding Ephemeris Input/Output Message
111	AID-HUI	0x0B 0x02	0	Poll Request	Poll GPS Health, UTC, ionosphere parameters
111	AID-HUI	0x0B 0x02	72	Input/Output	GPS Health, UTC and ionosphere parameters
113	AID-INI	0x0B 0x01	0	Poll Request	Poll GPS Initial Aiding Data
113	AID-INI	0x0B 0x01	48	Input/Output	Aiding position, time, frequency, clock drift
	UBX C	lass CFG	•	Configuration Input N	Nessages
116	CFG-ANT	0x06 0x13	0	Poll Request	Poll Antenna Control Settings
116	CFG-ANT	0x06 0x13	4	Input/Output	Antenna Control Settings
117	CFG-CFG	0x06 0x09	(12) or (13)	Command	Clear, Save and Load configurations
119	CFG-DAT	0x06 0x06	0	Poll Request	Poll Datum Setting
119	CFG-DAT	0x06 0x06	44	Input	Set User-defined Datum
120	CFG-DAT	0x06 0x06	52	Output	The currently defined Datum
121	CFG-DOSC	0x06 0x61	0		Poll DOSC settings
121	CFG-DOSC	0x06 0x61	4 + 32*numOsc	Set/Get	Disciplined oscillator configuration
123	CFG-ESRC	0x06 0x60	0	Poll Request	Poll ESRC settings
123	CFG-ESRC	0x06 0x60	4 + 36*numSo	Set/Get	External synchronization source configuration
125	CFG-GNSS	0x06 0x3E	0	Poll Request	Poll the GNSS system configuration
125	CFG-GNSS	0x06 0x3E	4 + 8*numCo	Input/Output	GNSS system configuration
127	CFG-INF	0x06 0x02	1	Poll Request	Poll configuration for one protocol
127	CFG-INF	0x06 0x02	0 + 10*N	Input/Output	Information message configuration
128	CFG-ITFM	0x06 0x39	0	Poll Request	Poll Jamming/Interference Monitor
129	CFG-ITFM	0x06 0x39	8	Command	Jamming/Interference Monitor configuration
130	CFG-LOGFILTER	0x06 0x47	0	Poll Request	Poll Data Logger filter Configuration
130	CFG-LOGFILTER	0x06 0x47	12	Input/Output	Data Logger Configuration
131	CFG-MSG	0x06 0x01	2	Poll Request	Poll a message configuration



OD/ IV	lessages Overview contin	aca			
Page	Mnemonic	Cls/ID	Length	Туре	Description
132	CFG-MSG	0x06 0x01	8	Input/Output	Set Message Rate(s)
132	CFG-MSG	0x06 0x01	3	Input/Output	Set Message Rate
133	CFG-NAV5	0x06 0x24	0	Poll Request	Poll Navigation Engine Settings
133	CFG-NAV5	0x06 0x24	36	Input/Output	Navigation Engine Settings
135	CFG-NAVX5	0x06 0x23	0	Poll Request	Poll Navigation Engine Expert Settings
135	CFG-NAVX5	0x06 0x23	40	Input/Output	Navigation Engine Expert Settings
137	CFG-NMEA	0x06 0x17	0	Poll Request	Poll the NMEA protocol configuration
137	CFG-NMEA	0x06 0x17	4	Input/Output	NMEA protocol configuration (deprecated)
139	CFG-NMEA	0x06 0x17	12	Input/Output	NMEA protocol configuration V0 (deprecated)
141	CFG-NMEA	0x06 0x17	20	Input/Output	Extended NMEA protocol configuration V1
144	CFG-ODO	0x06 0x1E	0	Poll Request	Poll Odometer, Low-speed COG Engine Settings
144	CFG-ODO	0x06 0x1E	20	Input/Output	Odometer, Low-speed COG Engine Settings
146	CFG-PM2	0x06 0x3B	0	Poll Request	Poll extended Power Mgmt configuration
146	CFG-PM2	0x06 0x3B	44	Input/Output	Extended Power Management configuration
148	CFG-PRT	0x06 0x00	0	Poll Request	Polls the configuration of the used I/O Port
148	CFG-PRT	0x06 0x00	1	Poll Request	Polls the configuration for one I/O Port
148	CFG-PRT	0x06 0x00	20	Input/Output	Port Configuration for UART
152	CFG-PRT	0x06 0x00	20	Input/Output	Port Configuration for USB Port
154	CFG-PRT	0x06 0x00	20	Input/Output	Port Configuration for SPI Port
156	CFG-PRT	0x06 0x00	20	Input/Output	Port Configuration for DDC Port
159	CFG-PWR	0x06 0x57	8	Set	Put receiver in a defined power state
159	CFG-RATE	0x06 0x08	0	Poll Request	Poll Navigation/Measurement Rate Settings
160	CFG-RATE	0x06 0x08	6	Input/Output	Navigation/Measurement Rate Settings
160	CFG-RINV	0x06 0x34	0	Poll Request	Poll contents of Remote Inventory
161	CFG-RINV	0x06 0x34	1 + 1*N	Input/Output	Contents of Remote Inventory
161	CFG-RST	0x06 0x04	4	Command	Reset Receiver / Clear Backup Data Structures
163	CFG-RXM	0x06 0x11	0	Poll Request	Poll RXM configuration
163	CFG-RXM	0x06 0x11	2	Input/Output	RXM configuration
164	CFG-SBAS	0x06 0x16	0	Poll Request	Poll contents of SBAS Configuration
164	CFG-SBAS	0x06 0x16	8	Input/Output	SBAS Configuration
166	CFG-SMGR	0x06 0x62	0	Poll Request	Poll SMGR settings
166	CFG-SMGR	0x06 0x62	20	Set/Get	Synchronization manager configuration
169	CFG-TMODE2	0x06 0x3D	0	Poll Request	Poll Time Mode Settings
169	CFG-TMODE2	0x06 0x3D	28	Get/Set	Time Mode Settings 2
170	CFG-TP5	0x06 0x31	0	Poll Request	Poll Time Pulse Parameters
171	CFG-TP5	0x06 0x31	1	Poll Request	Poll Time Pulse Parameters
171	CFG-TP5	0x06 0x31	32	Input/Output	Time Pulse Parameters
172	CFG-TP5	0x06 0x31	32	Input/Output	Time Pulse Parameters
L	1	I	I	1	1



ODA IV	icssages overview contin	ucu				
Page	Mnemonic	Cls/ID	Length	Туре	Description	
174	CFG-TXSLOT	0x06 0x53	16	Command	TX buffer time slots configuration	
175	CFG-USB	0x06 0x1B	0	Poll Request	Poll a USB configuration	
176	CFG-USB	0x06 0x1B	108	Input/Output	USB Configuration	
	UBX C	lass INF		Information Messages	5	
177	INF-DEBUG	0x04 0x04	0 + 1*N	Output	ASCII output with debug contents	
177	INF-ERROR	0x04 0x00	0 + 1*N	Output	ASCII output with error contents	
178	INF-NOTICE	0x04 0x02	0 + 1*N	Output	ASCII output with informational contents	
178	INF-TEST	0x04 0x03	0 + 1*N	Output	ASCII output with test contents	
179	INF-WARNING	0x04 0x01	0 + 1*N	Output	ASCII output with warning contents	
	UBX CI	ass LOG		Logging Messages		
180	LOG-CREATE	0x21 0x07	8	Command	Create Log File	
181	LOG-ERASE	0x21 0x03	0	Command	Erase Logged Data	
181	LOG-FINDTIME	0x21 0x0E	12	Input	Find index of the first log entry <= given time	
182	LOG-FINDTIME	0x21 0x0E	8	Output	Response to FINDTIME request.	
182	LOG-INFO	0x21 0x08	0	Poll Request	Poll for log information	
182	LOG-INFO	0x21 0x08	48	Output	Log information	
184	LOG-RETRIEVEPOSE	0x21 0x0f	32	Output	Odometer log entry	
185	LOG-RETRIEVEPOS	0x21 0x0b	40	Output	Position fix log entry	
186	LOG-RETRIEVESTRING	0x21 0x0d	16 + 1*byteC	Output	Byte string log entry	
186	LOG-RETRIEVE	0x21 0x09	12	Command	Request log data	
187	LOG-STRING	0x21 0x04	0 + 1*N	Command	Store arbitrary string in on-board flash	
	UBX Cla	ass MGA		Multi-GNSS Assistance		
188	MGA-ACK-DATA0	0x13 0x60	8	Output	Multi-GNSS Acknowledge message	
189	MGA-ANO	0x13 0x20	76	Input	Multi-GNSS AssistNow Offline Assistance	
189	MGA-DBD	0x13 0x80	0	Poll Request	Poll the Navigation Database	
190	MGA-DBD	0x13 0x80	12 + 1*N	Input / Output Message	Navigation Database Dump Entry	
190	MGA-FLASH-DATA	0x13 0x21	6 + 1*size	Input	Transfer MGA-ANO data block to flash	
191	MGA-FLASH-STOP	0x13 0x21	2	Input	Finish flashing MGA-ANO data	
191	MGA-FLASH-ACK	0x13 0x21	6	Output	Acknowledge last FLASH-DATA or -STOP	
192	MGA-GLO-EPH	0x13 0x06	48	Input	GLONASS Ephemeris Assistance	
193	MGA-GLO-ALM	0x13 0x06	36	Input	GLONASS Almanac Assistance	
194	MGA-GLO-TIMEOFF	0x13 0x06	20	Input	GLONASS Auxiliary Time Offset Assistance	
195	MGA-GPS-EPH	0x13 0x00	68	Input	GPS Ephemeris Assistance	
197	MGA-GPS-ALM	0x13 0x00	36	Input	GPS Almanac Assistance	
198	MGA-GPS-HEALTH	0x13 0x00	40	Input	GPS Health Assistance	
198	MGA-GPS-UTC	0x13 0x00	20	Input	GPS UTC Assistance	
199	MGA-GPS-IONO	0x13 0x00	16	Input	GPS Ionosphere Assistance	
			20	Input	Initial Position Assistance	



02/11	icssages overview contin					
Page	Mnemonic	Cls/ID	Length	Туре	Description	
200	MGA-INI-POS_LLH	0x13 0x40	20	Input	Initial Position Assistance	
201	MGA-INI-TIME_UTC	0x13 0x40	24	Input	Initial Time Assistance	
202	MGA-INI-TIME_GNSS	0x13 0x40	24	Input	Initial Time Assistance	
203	MGA-INI-CLKD	0x13 0x40	12	Input	Initial Clock Drift Assistance	
204	MGA-INI-FREQ	0x13 0x40	12	Input	Initial Frequency Assistance	
205	MGA-INI-EOP	0x13 0x40	72	Input	Earth Orientation Parameters Assistance	
205	MGA-QZSS-EPH	0x13 0x05	68	Input	QZSS Ephemeris Assistance	
207	MGA-QZSS-ALM	0x13 0x05	36	Input	QZSS Almanac Assistance	
208	MGA-QZSS-HEALTH	0x13 0x05	12	Input	QZSS Health Assistance	
	UBX Cla	ass MON		Monitoring Messages		
209	MON-GNSS	0x0A 0x28	8	Output	Information message GNSS selection	
211	MON-HW2	0x0A 0x0B	28	Periodic/Polled	Extended Hardware Status	
212	MON-HW	0x0A 0x09	60	Periodic/Polled	Hardware Status	
213	MON-IO	0x0A 0x02	0 + 20*N	Periodic/Polled	I/O Subsystem Status	
214	MON-MSGPP	0x0A 0x06	120	Periodic/Polled	Message Parse and Process Status	
214	MON-PATCH	0x0A 0x27	0	Poll Request	Poll Request for installed patches	
215	MON-PATCH	0x0A 0x27	4 + 16*nEntries	Output Message	Output information about installed patches.	
216	MON-RXBUF	0x0A 0x07	24	Periodic/Polled	Receiver Buffer Status	
216	MON-RXR	0x0A 0x21	1	Output	Receiver Status Information	
217	MON-SMGR	0x0A 0x2E	16	Output	Synchronization Manager Status	
220	MON-TXBUF	0x0A 0x08	28	Periodic/Polled	Transmitter Buffer Status	
221	MON-VER	0x0A 0x04	0	Poll Request	Poll Receiver/Software Version	
221	MON-VER	0x0A 0x04	40 + 30*N	Answer to Poll	Receiver/Software Version	
	UBX CI	ass NAV		Navigation Results		
222	NAV-AOPSTATUS	0x01 0x60	16	Periodic/Polled	AssistNow Autonomous Status	
223	NAV-CLOCK	0x01 0x22	20	Periodic/Polled	Clock Solution	
223	NAV-DGPS	0x01 0x31	16 + 12*numCh	Periodic/Polled	DGPS Data Used for NAV	
224	NAV-DOP	0x01 0x04	18	Periodic/Polled	Dilution of precision	
225	NAV-ODO	0x01 0x09	20	Periodic/Polled	Odometer Solution	
225	NAV-ORB	0x01 0x34	8 + 6*numSv	Periodic/Polled	GNSS Orbit Database Info	
228	NAV-POSECEF	0x01 0x01	20	Periodic/Polled	Position Solution in ECEF	
229	NAV-POSLLH	0x01 0x02	28	Periodic/Polled	Geodetic Position Solution	
229	NAV-PVT	0x01 0x07	92	Periodic/Polled	Navigation Position Velocity Time Solution	
232	NAV-RESETODO	0x01 0x10	0	Command	Reset odometer	
232	NAV-SAT	0x01 0x35	8 + 12*numSvs	Periodic/Polled	Satellite Information	
234	NAV-SBAS	0x01 0x32	12 + 12*cnt	Periodic/Polled	SBAS Status Data	
235	NAV-SOL	0x01 0x06	52	Periodic/Polled	Navigation Solution Information	
236	NAV-STATUS	0x01 0x03	16	Periodic/Polled	Receiver Navigation Status	
	•					



00/11	icssages overview contin	aca				
Page	Mnemonic	Cls/ID	Length	Туре	Description	
238	NAV-SVINFO	0x01 0x30	8 + 12*numCh	Periodic/Polled	Space Vehicle Information	
240	NAV-TIMEBDS	0x01 0x24	20	Periodic/Polled	BDS Time Solution	
241	NAV-TIMEGLO	0x01 0x23	20	Periodic/Polled	GLO Time Solution	
242	NAV-TIMEGPS	0x01 0x20	16	Periodic/Polled	GPS Time Solution	
243	NAV-TIMEUTC	0x01 0x21	20	Periodic/Polled	UTC Time Solution	
244	NAV-VELECEF	0x01 0x11	20	Periodic/Polled	Velocity Solution in ECEF	
245	NAV-VELNED	0x01 0x12	36	Periodic/Polled	Velocity Solution in NED	
	UBX CI	ass RXM		Receiver Manager Me	ssages	
246	RXM-PMREQ	0x02 0x41	8	Command	Requests a Power Management task	
246	RXM-RAWX	0x02 0x15	16 + 32*num	Periodic/Polled	Multi-GNSS Raw Measurement Data	
250	RXM-SFRBX	0x02 0x13	8 + 4*numWo	Aperiodic	Raw Subframe Data	
251	RXM-SVSI	0x02 0x20	8 + 6*numSV	Periodic/Polled	SV Status Info	
	UBX Class TIM			Timing Messages		
253	TIM-DOSC	0x0D 0x11	8	Output	Disciplined oscillator control	
253	TIM-FCHG	0x0D 0x16	32	Notification	Oscillator frequency changed notification	
254	ТІМ-НОС	0x0D 0x17	8	Input	Host oscillator control	
255	TIM-SMEAS	0x0D 0x13	12 + 24*num	Input/Output	Source measurement	
257	TIM-SVIN	0x0D 0x04	28	Periodic/Polled	Survey-in data	
258	TIM-TM2	0x0D 0x03	28	Periodic/Polled	Time mark data	
259	TIM-TOS	0x0D 0x12	56	Periodic	Time Pulse Time and Frequency Data	
261	ТІМ-ТР	0x0D 0x01	16	Periodic/Polled	Time Pulse Timedata	
263	TIM-VCOCAL	0x0D 0x15	12	Command	VCO calibration extended command	
264	TIM-VCOCAL	0x0D 0x15	12	Notification	Results of the calibration	
265	TIM-VRFY	0x0D 0x06	20	Polled/Once	Sourced Time Verification	
	UBX CI	ass UPD	•	Firmware Update Mes	ssages	
266	UPD-SOS	0x09 0x14	0	Poll Request	Poll Backup File Restore Status	
266	UPD-SOS	0x09 0x14	4	Input	Create Backup File in Flash	
267	UPD-SOS	0x09 0x14	4	Input	Clear Backup in Flash	
267	UPD-SOS	0x09 0x14	8	Output	Backup File Creation Acknowledge	
268	UPD-SOS	0x09 0x14	8	Output	System Restored from Backup	
	•		•			



21.9 UBX-ACK (0x05)

Ack/Nack Messages: i.e. as replies to CFG Input Messages.

Messages in this class are sent as a result of a CFG message (and certain other messages, e.g.

UBX-LOG-CREATE) being received, decoded and processed by the receiver.

21.9.1 UBX-ACK-ACK (0x05 0x01)


21.9.1.1 Message Acknowledged

Message		AC	ACK-ACK									
Description		Me	essage Ao	know	ledge	d						
Firmware			Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30									
Туре			tput	nom	111111000		011 2.00 (
Comment		Ou	tput upor	n proce	ssing c	of an in	out messa	ige				
		Hea	der	Class	ID	Length (Bytes)			Payload	Checksum		
Message Struct	ure	OxE	35 0x62	0x05	0x01	2			see below	CK_A CK_B		
Payload Conter	its:			-								
Byte Offset	Numl Form		Scaling	Name		Unit Description						
0	U1		-	clsI	D	- Class ID of the Acknowledged Message				lessage		
1	U1		-	msgl	D	- Message ID of the Acknowledged Message						

21.9.2 UBX-ACK-NAK (0x05 0x00)

21.9.2.1 Message Not-Acknowledged

Message		AC	ACK-NAK									
Description		Me	Message Not-Acknowledged									
Firmware Supported on:												
		• L	u-blox M8	from	firmwa	re versi	on 2.00 ι	p to version 2.30				
Туре		Ou	tput									
Comment		Ou	tput upor	n proce	ssing c	of an inp	out messa	ige				
		Hea	der	Class	ID	Length (Bytes)			Payload	Checksum		
Message Structu	ire	OxE	35 0x62	0x05	0x00	2			see below	CK_A CK_B		
Payload Content	s:											
Byte Offset	Numl	ber	Scaling	Name			Unit	Description				
	Form	ət										
0	U1		-	clsI	D	- Class ID of the Not-Acknowledged Message			ed Message			
1	U1		-	msgI	D		- Message ID of the Not-Acknowledged Message					





21.10 UBX-AID (0x0B)

AssistNow Aiding Messages: i.e. Ephemeris, Almanac, other A-GPS data input.

Messages in this class are used to send aiding data to the receiver. The use of this class is deprecated.

21.10.1 UBX-AID-ALM (0x0B 0x30)

21.10.1.1 Poll GPS Aiding Almanac Data

Message	AID-ALM	AID-ALM											
Description	Poll GPS Ai	Poll GPS Aiding Almanac Data											
Firmware	Supported o	Supported on:											
	• u-blox M8	³ from ⁻	firmwa	re version 2.00 up to version 2.30									
Туре	Poll Request	Poll Request											
Comment	All UBX-AI) mess	ages a	are deprecated; use UBX-MGA messa	ages inste	ad							
	Poll GPS Aid	ing Dat	ta (Alm	anac) for all 32 SVs by sending this me	sage to th	e receiver							
	without any	payloa	d. The	receiver will return 32 messages of type	e AID-ALM	as defined							
	below.												
	Header	Class	ID	Length (Bytes)	Payload	Checksum							
Message Structure	0xB5 0x62	0xB5 0x62 0x0B 0x30 0 see below CK_A CK_B											
No payload	•	•			•	•							

21.10.1.2 Poll GPS Aiding Almanac Data for a SV

Message		AI	D-ALM							
Description		Po	II GPS Aid	ding A	Imana	ic Data	for a S	/		
Firmware			oported o		<i>c</i> .		2.00			
		-	u-blox M8 from firmware version 2.00 up to version 2.30							
Туре		Pol	ll Request							
Comment		All UBX-AID messages are deprecated; use UBX-MGA messages instead Poll GPS Aiding Data (Almanac) for an SV by sending this message to the rece receiver will return one message of type AID-ALM as defined below.								
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum
Message Struc	ture	OxE	35 0x62	0x0B	0x30	1			see below	СК_АСК_В
Payload Conte	nts:			•	•	•			•	
Byte Offset	Numl Form						Unit	Description		
0	U1	- svid			-	SV ID for which the receiver shall return its Almanac Data (Valid Range: 1 32 or 51, 5 63).				



21.10.1.3 GPS Aiding Almanac Input/Output Message

Message		AID-ALM										
Description		GPS Aidin	g Alma	nac In	put/Ou	itput M	essage					
Firmware		Supported	on:									
		• u-blox N	18 from	firmwa	are vers	ion 2.00	up to version 2.30					
Туре		Input/Outp	out									
Comment		 All UBX-AID messages are deprecated; use UBX-MGA messages instead If the WEEK Value is 0, DWRD0 to DWRD7 are not sent as the Almanac is no for the given SV. This may happen even if NAV-SVINFO and RXM-SVSI are included almanac availability as the internal data may not represent the content of an broadcast almanac (or only parts thereof). DWORD0 to DWORD7 contain the 8 words following the Hand-Over Word (from the GPS navigation message, either pages 1 to 24 of sub-frame 5 or pa of subframe 4. See IS-GPS-200 for a full description of the contents of the Alpages. In DWORD0 to DWORD7, the parity bits have been removed, and the 24 bits located in Bits 0 to 23. Bits 24 to 31 shall be ignored. 							is not available re indicating of an original ord (HOW) or pages 2 to 10 ne Almanac			
		within the subframe can be found in DWRD0, Bits 15-0 whereas Bit 0 is the LSB.										
		Header	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	0xB5 0x62	0x0B	0x30	(8) or	(40)		see below	CK_A CK_B			
Payload Conte	nts:		•		•							
Byte Offset	Numi Form											
0	U4	-	svid	svid		-	SV ID for which the Almanac Data is (63).		l 32 or 51, 56,			
4	U4	-	week	<u>د</u>		-	Issue Date of Alm	anac (GPS we	ek number)			
Start of option	al block											
		-				1	· · ·					

8	U4[8]	-	dwrd	-	Almanac Words
End of optional b	lock				

21.10.2 UBX-AID-AOP (0x0B 0x33)

21.10.2.1 Poll AssistNow Autonomous data, all satellites

Message	AID-AOP									
Description	Poll AssistN	Poll AssistNow Autonomous data, all satellites								
Firmware	Supported of	Supported on:								
	• u-blox M8	u-blox M8 from firmware version 2.00 up to version 2.30								
Туре	Poll request	oll request								
Comment	All UBX-AID) mess	ages a	are deprecated; use UBX-MGA messa	iges inste	ad				
	Poll AssistNo	w Auto	onomo	us aiding data for all GPS satellites by se	ending this	empty				
	message. The	e receiv	ver will	return an AID-AOP message (see defini	tion below	/) for each GPS				
	satellite for v	vhich c	lata is a	available.						
	Header	leader Class ID Length (Bytes) Payload Checksum								
Message Structure	0xB5 0x62	0x0B	0x33	0	see below	CK_A CK_B				



No payload

21.10.2.2 Poll AssistNow Autonomous data, one GPS satellite

Message		AID	D-AOP							
Description		Pol	l AssistN	ow A	utono	mous d	lata, one	GPS satellite		
Firmware			Supported on:u-blox M8 from firmware version 2.00 up to version 2.30							
Туре			Il request							
Comment Message Structu	ire								eiver will return	
Payload Content	s:	I								
Byte Offset	Numl Forma		Scaling	Name			Unit	Description		
0	U1		-	svić	svid		-	GPS SV ID for which the data is requested (val range: 132).		

21.10.2.3 AssistNow Autonomous data

Message		AID	D-AOP										
Description		Ass	sistNow	Auton	omou	s data							
Firmware		Sup	oported o	n:									
		• L	u-blox M8	from firmware version 2.00 up to version 2.30									
Туре		Inp	ut/Outpu ⁻	ut									
Comment		All	UBX-AID) mess	messages are deprecated; use UBX-MGA messages instead								
		lf e	nabled, tł	nis mes	s message is output at irregular intervals. It is output whenever AssistNow								
		Au	<i>itonomous</i> has produced new data for a satellite. Depending on the availabilit								ability of the		
		opt	ional data	a the re	eceiver	will ou	tput eith	ner versic	on of the messa	ge. If this n	nessage is		
		pol	led using	one of	the tv	vo poll	requests	describe	ed above the re-	ceiver will s	end this		
		me	ssage if A	ssistNc	istNow Autonomous data is available or the corresponding poll request								
		me	nessage if no AssistNow Autonomous data is available for each satellite (i.e. svid 132). At										
		the	he user's choice the optional data may be chopped from the payload of a previously polled										
		me	nessage when sending the message back to the receiver. Sending a valid AID-AOP										
		me	ssage to t	the receiver will automatically enable the AssistNow Autonomous feature on									
		the	receiver.	ceiver. See the section AssistNow Autonomous in the receiver description for details									
		on	this featu	re.									
		Hea	der	Class	ID	Length	(Bytes)			Payload	Checksum		
Message Struc	ture	OxE	35 0x62	0x0B	0x33	68				see below	CK_A CK_B		
Payload Conte	nts:									•			
Byte Offset	Num	ber	Scaling	Name			Unit	Descript	tion				
Format													
0 U1 -				gnssId		-	GNSS	GNSS identifier (see Satellite Numbering)		nbering)			
1	U1		-	svId	svId		-	Satellite identifier (see Satellite Numbering)			umbering)		
2	U1[2	2]	-	rese	rved	1	-	Reserv	red				



AID-AOP continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
4	U1[64]	-	data	-	assistance data

21.10.3 UBX-AID-EPH (0x0B 0x31)

21.10.3.1 Poll GPS Aiding Ephemeris Data

Message	AID-EPH										
Description	Poll GPS Ai	Poll GPS Aiding Ephemeris Data									
Firmware	Supported of	Supported on:									
	• u-blox Ma	• u-blox M8 from firmware version 2.00 up to version 2.30									
Туре	Poll Request	Poll Request									
Comment	All UBX-AID messages are deprecated; use UBX-MGA messages instead										
	Poll GPS Aid	ling Da	ta (Eph	emeris) for all 32 SVs by sending	this message to [•]	the receiver					
	without any	payloa	d. The	receiver will return 32 messages of	of type AID-EPH	as defined					
	below.										
	Header	Class	ID	Length (Bytes)	Payload	Checksum					
Message Structure	0xB5 0x62	0xB5 0x62 0x0B 0x31 0 see below CK_A CK_B									
No payload			1	•		1					



21.10.3.2 Poll GPS Aiding Ephemeris Data for a SV

Message		AID	D-EPH							
Description		Pol	I GPS Aid	ding E	phem	eris Da	ta for a	SV		
Firmware		Sup	oported o	n:						
		 u-blox M8 from firmware version 2.00 up to version 2.30 								
Туре		Pol	ll Request							
Comment		Pol	l GPS Cor	nstellati	ion Da	ta (Ephe	emeris) f	I; use UBX-MGA mes or an SV by sending tl /pe AID-EPH as define	nis message	
		Hea	der	Class	ID	Length (Bytes) Payload			Checksum	
Message Struct	ure	OxE	35 0x62	0x0B	0x31	1 see below				CK_A CK_B
Payload Conter	nts:								•	
Byte Offset	Numb	ber	Scaling	Name			Unit	Description		
Format										
0	U1		-	svić	d		-	SV ID for which the	SV ID for which the receiver shall return its	
								Ephemeris Data (Va	lid Range: 1	32).

21.10.3.3 GPS Aiding Ephemeris Input/Output Message

Message		AIC	D-EPH							
Description		GP	5 Aiding	Epher	neris I	nput/C	Output M	essage		
Firmware			ported o I-blox M8		firmwa	are versi	on 2.00 ι	p to version 2.30		
Туре		Inp	ut/Outpu [.]	t						
Comment All UBX-AID messages are deprecated; use UBX-MGA messages instead • SF1D0 to SF3D7 is only sent if ephemeris is available for this SV. If not, the p be reduced to 8 Bytes, or all bytes are set to zero, indicating that this SV Nut not have valid ephemeris for the moment. This may happen even if NAV-SVI RXM-SVSI are indicating ephemeris availability as the internal data may not n content of an original broadcast ephemeris (or only parts thereof). • SF1D0 to SF3D7 contain the 24 words following the Hand-Over Word (HOW GPS navigation message, subframes 1 to 3. The Truncated TOW Count is not cannot be used. See IS-GPS-200 for a full description of the contents of the • In SF1D0 to SF3D7, the parity bits have been removed, and the 24 bits of da located in Bits 0 to 23. Bits 24 to 31 shall be ignored. • When polled, the data contained in this message does not represent the full ephemeris broadcast. Some fields that are irrelevant to u-blox receivers may The week number in Subframe 1 has already been modified to match the Ti Ephemeris (TOE).								e payload may Number does SVINFO and ot represent the IOW) from the not valid and he Subframes. data are full original hay be missing. e Time Of		
	-	Head		Class	ID	Length (-		Payload	Checksum
							see below	CK_A CK_B		
Payload Conter	nts:									
Byte Offset	Scaling	Name			Unit	Description				
0	U4 - svid				l		-	SV ID for which this ephemeris data is Range: 1 32).		lata is (Valid



AID-EPH continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
4	U4	-	how	-	Hand-Over Word of first Subframe. This is
					required if data is sent to the receiver.
					0 indicates that no Ephemeris Data is following.
Start of optiona	al block		·		
8	U4[8]	-	sfld	-	Subframe 1 Words 310 (SF1D0SF1D7)
40	U4[8]	-	sf2d	-	Subframe 2 Words 310 (SF2D0SF2D7)
72	U4[8]	-	sf3d	-	Subframe 3 Words 310 (SF3D0SF3D7)
End of optional	l block	•		·	

21.10.4 UBX-AID-HUI (0x0B 0x02)

21.10.4.1 Poll GPS Health, UTC, ionosphere parameters

Message	AID-HUI	AID-HUI									
Description	Poll GPS He	Poll GPS Health, UTC, ionosphere parameters									
Firmware	Supported o	Supported on:									
	• u-blox M8	• u-blox M8 from firmware version 2.00 up to version 2.30									
Туре	Poll Request	Poll Request									
Comment	All UBX-AI) mess	ages a	are deprecated; use UBX-MGA me	ssages inste	ad					
	-										
	Header	Class	ID	Length (Bytes)	Payload	Checksum					
Message Structure	0xB5 0x62	0xB5 0x62 0x0B 0x02 0 see below CK_A CK_B									
No payload	- 1			•							

21.10.4.2 GPS Health, UTC and ionosphere parameters

Message		AI	D-HUI											
Description		GP	S Health	, UTC a	and io	nosphe	ere para	meters						
Firmware		Sup	oported o	n:										
		• (u-blox M8	³ from ⁻	firmwa	re versi	on 2.00	up to version 2.30						
Туре		Inp	Input/Output											
Comment All UBX-AID messages are deprecated; use UBX-MGA messages instead								ad						
		Thi	s message	e conta	ins a h	ealth b	it mask, I	JTC time and Klobucha	r paramete	ers. For more				
		info	ormation	on the	se para	meters	, see the	ICD-GPS-200 document	tation.					
		Hea	nder	Class	Class ID Length				Payload	Checksum				
Message Struct	ture	OxE	35 0x62	0x0B	0x02	72			see below	CK_A CK_B				
Payload Conter	nts:									•				
Byte Offset	Numl	ber	Scaling	Name			Unit	Description						
	Form	ət												
0	X4		-	heal	th		-	Bitmask, every bit repr	esenst a G	iPS SV (1-32). If				
								the bit is set the SV is	healthy.					
4	4 R8 -			utcA	0		-	UTC - parameter A0	UTC - parameter A0					
12R8-utcA1-UTC - parameter A1														
20	14		-	utcl	WO		-	UTC - reference time of	of week					
24	12		-	utcW	NT		-	UTC - reference week	number					





AID-HUI continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
26	12	-	utcLS	-	UTC - time difference due to leap seconds
					before event
28	12	-	utcWNF	-	UTC - week number when next leap second
					event occurs
30	12	-	utcDN	-	UTC - day of week when next leap second event
					occurs
32	12	-	utcLSF	-	UTC - time difference due to leap seconds after
					event
34	12	-	utcSpare	-	UTC - Spare to ensure structure is a multiple of
					4 bytes
36	R4	-	klobA0	S	Klobuchar - alpha 0
40	R4	-	klobA1	s/semici	Klobuchar - alpha 1
				rcle	
44	R4	-	klobA2	s/semici	Klobuchar - alpha 2
				rcle^2	
48	R4	-	klobA3	s/semici	Klobuchar - alpha 3
				rcle^3	
52	R4	-	klobB0	S	Klobuchar - beta 0
56	R4	-	klobB1	s/semici	Klobuchar - beta 1
				rcle	
60	R4	-	klobB2	s/semici	Klobuchar - beta 2
				rcle^2	
64	R4	-	klobB3	s/semici	Klobuchar - beta 3
				rcle^3	
68	X4	-	flags	-	flags (see graphic below)

Bitfield flags

This Graphic explains the bits of flags

														2	1	0
														klobValid	utcValid	healthValid

■ signed value ■ unsigned value ■ reserved

Name	Description
healthValid	Healthmask field in this message is valid
utcValid	UTC parameter fields in this message are valid
klobValid	Klobuchar parameter fields in this message are valid



21.10.5 UBX-AID-INI (0x0B 0x01)

21.10.5.1 Poll GPS Initial Aiding Data

Message	AID-INI											
Description	Poll GPS In	Poll GPS Initial Aiding Data										
Firmware	Supported of	Supported on:										
	• u-blox Ma	8 from	firmwa	are version 2.00 up to versior	n 2.30							
Туре	Poll Request	Poll Request										
Comment	All UBX-All	D mess	ages a	are deprecated; use UBX-N	/IGA messages inste	ad						
	-											
	Header	Class	ID	Length (Bytes)	Payload	Checksum						
Message Structure	0xB5 0x62	0x0B	0x01	0	see below	CK_A CK_B						
No payload		•	•									

21.10.5.2 Aiding position, time, frequency, clock drift

Message		AI	D-INI											
Description		Aic	ding posi	tion, t	ime, f	requen	ncy, clock	drift						
Firmware		Sup	oported o	n:										
		• (u-blox M8	from	firmwa	ire versi	ion 2.00 ι	p to version 2.30						
Туре		Inp	ut/Outpu ⁻	t										
Comment		All	UBX-AID) mess	messages are deprecated; use UBX-MGA messages instead									
		Thi	s message	e conta	ins po	sition, t	ime and o	clock drift information.	The position	on can be input				
		in e	either the	ECEF >	(/Y/Z c	oordina	ite system	or as lat/lon/height. Th	ie time car	n either be input				
								cation interface, sufferi	-	-				
			-				-	ware time synchronizat						
								ots. It is also possible to						
				-		1		ous signal to an externa	1	1				
		Hea	nder	Class	ID	Length	(Bytes)		Payload	Checksum				
Message Struc	ture	OxE	35 0x62	0x0B 0x01 48					see below	СК_АСК_В				
Payload Conte	ents:													
Byte Offset	Numl	ber	Scaling	Name			Unit	Description						
	Forma	ət												
0	14		-	ecef	XOrL	at	cm_or_	WGS84 ECEF X coordinate or latitude,						
							deg*1e	depending on flags below						
							-7							
4	14		-	ecef	YOrL	on	cm_or_	WGS84 ECEF Y coordi		ngitude,				
							deg*1e	depending on flags be	low					
-				-			-7			·				
8	14		-	ecei	ZOrA	lt	cm	WGS84 ECEF Z coordi		itude,				
12	U4							depending on flags below						
12 16	X2		- posAcc				cm	-	Position accuracy (stddev)					
18	U2		-	tmCf	g DrDate		- week_o	Time mark configuration (see graphic below) Actual week number or yearSince2000/Month						
			[WILOC	JUDIC	C	r_year	(YYMM), depending on flags below						
							Month	(Trivity, depending on hags below						
							MOILUI							




AID-INI continued

Byte Offset	Number Format	Scaling	Name	Unit	Description
20	U4	-	towOrTime	ms_or_	Actual time of week or
				dayHou	DayOfMonth/Hour/Minute/Second
				rMinute	(DDHHMMSS), depending on flags below
				Sec	
24	14	-	towNs	ns	Fractional part of time of week
28	U4	-	tAccMs	ms	Milliseconds part of time accuracy
32	U4	-	tAccNs	ns	Nanoseconds part of time accuracy
36	14	-	clkDOrFreq	ns/s_or	Clock drift or frequency, depending on flags
				_Hz*1e	below
				-2	
40	U4	-	clkDAccOrFreq	ns/s_or	Accuracy of clock drift or frequency, depending
			Acc	_ppb	on flags below
44	X4	-	flags	-	Bitmask with the following flags (see graphic
					below)

Bitfield tmCfg

This Graphic explains the bits of tmCfg



■ signed value ■ unsigned value □ reserved

- reserved	
Name	Description
fEdge	use falling edge (default rising)
tml	time mark on extint 1 (default extint 0)
fl	frequency on extint 1 (default extint 0)

Bitfield flags

This Graphic explains the bits of flags

	10 7	6 5 4	4 3 2 1 0
	utc orevTm	ι μ	clockF tp clockD time pos

■ signed value ■ unsigned value ■ reserved

Name	Description
pos	Position is valid
time	Time is valid
clockD	Clock drift data contains valid clock drift, must not be set together with clockF
tp	Use time pulse
clockF	Clock drift data contains valid frequency, must not be set together with clockD
lla	Position is given in lat/long/alt (default is ECEF)
altInv	Altitude is not valid, if lla was set



Bitfield flags Description continued

Name	Description
prevTm	Use time mark received before AID-INI message (default uses mark received after message)
utc	Time is given as UTC date/time (default is GPS wno/tow)



21.11 UBX-CFG (0x06)

Configuration Input Messages: i.e. Set Dynamic Model, Set DOP Mask, Set Baud Rate, etc..

The CFG Class can be used to configure the receiver and read out current configuration values. Any messages in Class CFG sent to the receiver are acknowledged (with Message UBX-ACK-ACK) if processed successfully, and rejected (with Message UBX-ACK-NAK) if processing the message failed.

21.11.1 UBX-CFG-ANT (0x06 0x13)

21.11.1.1 Poll Antenna Control Settings


Message	CFG-ANT											
Description	Poll Antenr	Poll Antenna Control Settings										
Firmware	Supported o	n:										
	• u-blox M8	B from ⁻	firmwa	are version 2.00 up to version 2.30								
Туре	Poll Request	Poll Request										
Comment	Sending this	(empty	/ no-p	payload) message to the receiver results	in the rece	eiver returning a						
	message of	type CF	G-AN	Γ with a payload as defined below								
	Header	Class	ID	Length (Bytes)	Payload	Checksum						
Message Structure	0xB5 0x62	0x06	0x13	0	see below	CK_A CK_B						
No payload		•	•	•	•	•						

21.11.1.2 Antenna Control Settings

Message		CFO	CFG-ANT								
Description			Antenna Control Settings								
Firmware			Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30								
<i>Type</i> Input/Out			ut/Outpu	t							
Comment -			-								
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struct	ıre	OxE	35 0x62	0x06	0x13	4			see below	CK_A CK_B	
Payload Conten	ts:									•	
Byte Offset	Byte Offset Number Scaling		Scaling	Name	Name		Unit	Description			
	Form	ət									
0	X2		-	flag	flags		-	Antenna Flag Mask (see graphic below)			
2	X2	-		pins		-	Antenna Pin Configuration (see graphic below)				

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description
svcs	Enable Antenna Supply Voltage Control Signal
scd	Enable Short Circuit Detection



Bitfield flags Description continued

Name	Description
ocd	Enable Open Circuit Detection
pdwnOnSCD	Power Down Antenna supply if Short Circuit is detected. (only in combination with Bit 1)
recovery	Enable automatic recovery from short state

Bitfield pins

This Graphic explains the bits of pins

econfig pinOCD pinSCD nSwitch		
econ pin ∩Swi		
pi re		

unsigned value

Name	Description
pinSwitch	PIO-Pin used for switching antenna supply
pinSCD	PIO-Pin used for detecting a short in the antenna supply
pinOCD	PIO-Pin used for detecting open/not connected antenna
reconfig	if set to one, and this command is sent to the receiver, the receiver will reconfigure the pins as specified.

21.11.2 UBX-CFG-CFG (0x06 0x09)

21.11.2.1 Clear, Save and Load configurations

Message		CF	G-CFG								
Description		Clear, Save and Load configurations									
Firmware		Sup	oported o	n:							
		• l	u-blox M8	8 from	firmwa	ire versi	on 2.00	up to version 2.30			
Туре		Co	mmand								
Comment		See Receiver Configuration for a detailed description on how Receiver Configuration should be used. The three masks are made up of individual bits, each bit indicating the sub-section of all configurations on which the corresponding action shall be carried out. The reserved									
		the	bits in the masks must be set to '0'. For detailed information refer to the Organization of the Configuration Sections. Note that commands can be combined. The sequence of execution is Clear, Save, Load								
		Hea	ıder	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struct	ure	OxE	35 0x62	0x06	6 0x09 (12) o		r (13)		see below	CK_A CK_B	
Payload Conter	its:								•		
Byte Offset	Numl Form		Scaling	Name		Unit	Description				
0	X4 -		-	clearMask		-	Mask with configurati e. load default configu configurations in non- graphic below)	urations to	permanent		
4	X4 -		saveMask		-	Mask with configuration sub-sections to save e. save current configurations to non-volatile memory), see ID description of clearMask		non-volatile			



CFG-CFG continued

Byte Offset	Number	Scaling	Name	Unit	Description			
	Format							
8	X4	-	loadMask	-	Mask with configuration sub-sections to load (i. e. load permanent configurations from non-volatile memory to current configurations), see ID description of clearMask			
Start of optional	Start of optional block							
12 X1 - deviceMask - Mask which selects the memory devices for this command. (see graphic below)								
End of optional b	End of optional block							

Bitfield clearMask

This Graphic explains the bits of clearMask


12 11 10 9	4 3 2 1 0
ftsConf logConf antConf rinvConf	rxmConf navConf infMsg msgConf ioPort

■ signed value ■ unsigned value ■ reserved

Name	Description
ioPort	Communications port settings. Modifying this sub-section results in an IO system reset. Because of this undefined
	data may be output for a short period of time after receiving the message.
msgConf	Message configuration
infMsg	INF message configuration
navConf	Navigation configuration
rxmConf	Receiver Manager configuration
rinvConf	Remote inventory configuration
antConf	Antenna configuration
logConf	Logging configuration
ftsConf	FTS configuration. Only applicable to the FTS product variant.

Bitfield deviceMask

This Graphic explains the bits of deviceMask



signed value unsigned value reserved

Name	Description
devBBR	Battery backed RAM
devFlash	Flash
devEEPROM	EEPROM



Bitfield deviceMask Description continued

Name	Description
devSpiFlash	SPI Flash

21.11.3 UBX-CFG-DAT (0x06 0x06)

21.11.3.1 Poll Datum Setting

Message	CFG-DAT	CFG-DAT										
Description	Poll Datum	Poll Datum Setting										
Firmware	Supported c	Supported on:										
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 										
Туре	Poll Request	Poll Request										
Comment	Upon sendir	Upon sending of this message, the receiver returns CFG-DAT as defined below										
	Header	Class	ID	Length (Bytes)	Payload	Checksum						
Message Structure	0xB5 0x62	0x06	0x06	0	see below	CK_A CK_B						
No payload	1			•	•	1						

21.11.3.2 Set User-defined Datum

Message		CFG	-DAT								
Description		Set	User-de	efined	Datun	n					
Firmware			ported c -blox M8		firmwa	are versi	on 2.00	up to version 2.30			
Туре		Inpu	ut								
Comment		-									
		Heao	ler	Class	ID	Length ('Bytes)		Payload	Checksum	
Message Struc	ture	0xB	5 0x62	0x06	0x06	44			see below	CK_A CK_B	
Payload Conte	nts:					•					
Byte Offset	Numb Forma		Scaling	Name			Unit	Description			
0	R8		-	maj <i>P</i>	majA			Semi-major Axis (accepted range = 6,300,000. to 6,500,000.0 meters).			
8	R8		-	flat			-	1.0 / Flattening (accepted range is 0.0 to 500.)			
16	R4		-	dX			m	X Axis shift at the origin (accepted range is +/ 5000.0 meters).			
20	R4		-	dY			m	Y Axis shift at the origin (accepted range is +/- 5000.0 meters).			
24	R4		-	dZ			m	Z Axis shift at the origin (accepted range is +/- 5000.0 meters).			
28	R4		-	rotX	rotX		S	Rotation about the X / +/- 20.0 milli-arc second	Rotation about the X Axis (accepted range is		
32	R4		-	rotì	rotY			Rotation about the Y Axis (accepted range is +/- 20.0 milli-arc seconds).			
36	R4		-	rotZ	rotZ		S	Rotation about the Z Axis (accepted range is + 20.0 milli-arc seconds).			



CFG-DAT continued

Byte	e Offset	Number	Scaling	Name	Unit	Description
		Format				
40		R4	-	scale		Scale change (accepted range is 0.0 to 50.0
						parts per million).

21.11.3.3 The currently defined Datum

Message		CF	G-DAT								
Description		Th	e curren	tly def	ined D	Datum					
Firmware			oported c								
		• l	u-blox M8	3 from	firmwa	are vers	ion 2.00) up to version 2.30			
Туре		Ou	tput								
Comment					urrently o	defined datum. If no user-defined datum has bee	'n				
		_	, this will	-	1		(5, (,))				
		Hea		Class	ID	Length	(Bytes)	Payload Checksum			
Message Struc	ture	OxE	35 0x62	0x06	0x06	52		see below CK_A CK_B			
Payload Conte	nts:										
Byte Offset	Num Form		Scaling	Name			Unit	Description			
0	U2	al	-	datu	ımNum		_	Datum Number: 0 = WGS84, -1 = user-defined			
2	CH[6	51	-		umNam		-	ASCII String: WGS84 or USER	u		
8	R8	0]	-		majA		m	Semi-major Axis (accepted range = $6,300,000$	2.0		
0				110.01	1			to 6,500,000.0 meters).	5.0		
16			-	flat	flat		-	1.0 / Flattening (accepted range is 0.0 to 500	.0		
).			
24	R4		-	dX	dX		m	X Axis shift at the origin (accepted range is +/-			
								5000.0 meters).			
28	R4		-	dY			m	Y Axis shift at the origin (accepted range is +/-			
								5000.0 meters).			
32	R4		-	dZ			m	Z Axis shift at the origin (accepted range is +/-			
								5000.0 meters).			
36	R4		-	rotX	Ζ		S	Rotation about the X Axis (accepted range is			
								+/- 20.0 milli-arc seconds).			
40	R4		-	rotY	<u>C</u>		S	Rotation about the Y Axis (accepted range is			
								+/- 20.0 milli-arc seconds).			
44	R4		-	rotz	rotZ		S	Rotation about the Z Axis (accepted range is -	+/-		
								20.0 milli-arc seconds).			
48	R4		-	scal	le		ppm	Scale change (accepted range is 0.0 to 50.0			
								parts per million).			



21.11.4 UBX-CFG-DOSC (0x06 0x61)

21.11.4.1 Poll DOSC settings

Message	CFG-DOSC	FG-DOSC											
Description	Poll DOSC s	Poll DOSC settings											
Firmware	• u-blox M8	Supported on: • u-blox M8 from firmware version 2.20 up to version 2.30 (only available with FTS product variant)											
Туре													
Comment	5		0	he receiver results in the receiver return payload as defined below for the oscill	5	5 51							
	Header	Class	ID	Length (Bytes)	Payload	Checksum							
Message Structure	0xB5 0x62	0x06	0x61	0	see below	CK_A CK_B							
No payload	•	•			•	•							

21.11.4.2 Disciplined oscillator configuration

Message		CF	G-DOSC							
Description		Dis	sciplined	oscilla	ntor co	nfigur	ation			
Firmware		• i	oported o u-blox M8 product v	8 from		ire vers	ion 2.20	up to version 2.30 (only	availabl	e with FTS
Туре		Set	/Get							
Comment		to t The init The	This message allows the characteristics of the internal or external oscillator to be dest to the receiver. The gainVco and gainUncertainty parameters are normally set using the calibration p initiated using UBX-TIM-VCOCAL. The behavior of the system can be badly affected by setting the wrong values, so cu are advised to only change these parameters with care.							
Header				Class	ID	Length (Bytes)			Payload	Checksum
Message Structure 0xB5 0x62			0x06	0x61	4 + 32*numOsc			see below	СК_АСК_В	
Payload Conter	nts:			•		•				
Byte Offset	Num Form		Scaling	Name			Unit	Description		
0	U1		-	vers	sion		-	Message version (0 for this version)		
1	U1		-	numC)sc		-	Number of oscillators t length of this message	-	re (affects
2	U1[2	2]	-	rese	erved	1	-	Reserved		
Start of repeate	ed block	(num	Osc times)							
4 + 32*N	U1		-	oscId		-	ld of oscillator. 0 - internal oscillator 1 - external oscillator			
5 + 32*N	U1		-	rese	erved	2	-	Reserved		
6 + 32*N	X2		-	flag	js		-	flags (see graphic belo	w)	
8 + 32*N	U4		2^-2	freq	1		Hz	Nominal frequency of		
12 + 32*N	4		-	phas	seOff:	set	ps	Intended phase offset of the oscillator relative to the leading edge of the time pulse		




CFG-DOSC continued

Byte Offset	Number Format	Scaling	Name	Unit	Description
16 + 32*N	U4	2^-8	withTemp	ppb	Oscillator stability limit over operating temperature range (must be > 0)
20 + 32*N	U4	2^-8	withAge	ppb/yea r	
24 + 32*N	U2	-	timeToTemp	S	The minimum time that it could take for a temperature variation to move the oscillator frequency by 'withTemp' (must be > 0)
26 + 32*N	U1[2]	-	reserved3	-	Reserved
28 + 32*N	14	2^-16	gainVco	ppb/ra w LSB	Oscillator control gain/slope; change of frequency per unit change in raw control change
32 + 32*N	U1	2^-8	gainUncertain ty	-	Relative uncertainty (1 standard deviation) of oscillator control gain/slope
33 + 32*N	U1[3]	-	reserved4	-	Reserved
End of repeated	block				

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description
isCalibrated	1 if the oscillator gain is calibrated, 0 if not
controlIf	Communication interface for oscillator control:
	0: Custom DAC attached to receiver's I2C
	1: Microchip MCP4726 (12 bit DAC) attached to receiver's I2C
	2: TI DAC8571 (16 bit DAC) attached to receiver's I2C
	13: 12 bit DAC attached to host
	14: 14 bit DAC attached to host
	15: 16 bit DAC attached to host
	Note that for DACs attached to the host, the host must monitor TIM-DOSC messages and pass the supplied raw
	values on to the DAC.



21.11.5 UBX-CFG-ESRC (0x06 0x60)

21.11.5.1 Poll ESRC settings

Message	CFG-ESRC	CFG-ESRC										
Description	Poll ESRC s	Poll ESRC settings										
Firmware	• u-blox M8	 Supported on: u-blox M8 from firmware version 2.20 up to version 2.30 (only available with FTS product variant) 										
Туре	Poll Request											
Comment	-											
	Header	Class	ID	Length (Bytes)		Payload	Checksum					
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x60 0 see below CK_A CK_B										
No payload												

21.11.5.2 External synchronization source configuration

Message		CF	G-ESRC								
Description		Ext	ternal sy	nchroi	nizatio	on sour	ce con	figuration			
Firmware		• (oported c u-blox M8 product	3 from		are versi	on 2.20) up to version 2.30 (or	nly availabl	e with FTS	
Туре		Set	/Get								
Comment					• •		-	uration. The stability of urceType field docume		equency sources	
		Hea	nder	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	0xB	35 0x62	0x06	0x60	4 + 36	S*numS	ources	see below	CK_A CK_B	
Payload Conte	nts:			•							
Byte Offset	Numb Forma		Scaling	Name			Unit	Description	on		
0	U1		-	vers	sion		-	Message version (0	for this version	on)	
1	U1		-	numSources		es	-	Number of sources (message)	Number of sources (affects length of this message)		
2	U1[2]	-	rese	reserved1		-	Reserved			
Start of repeat	ed block ('num	Sources tim	nes)							
4 + 36*N	U1		-	ext]	Int		-	EXTINT index of this 1 for EXTINT1)	source (0 fc	or EXTINTO and	
5 + 36*N U1 -		sour	sourceType		-	 Source type: 0: none 1: frequency source; use withTemp, withAge timeToTemp and maxDevLifeTime to describe the stability of the source 2: time source; use offset, offsetUncertainty and jitter fields to describe the stability of the source 3: feedback from external oscillator; stability data is taken from the external oscillator's configuration 					






CFG-ESRC continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
6 + 36*N	X2	-	flags	-	Flags (see graphic below)
8 + 36*N	U4	2^-2	freq	Hz	Nominal frequency of source
12 + 36*N	U1[4]	-	reserved2	-	Reserved
16 + 36*N	U4	2^-8	withTemp	ppb	Oscillator stability limit over operating
					temperature range (must be > 0)
					Only used if sourceType is 1.
20 + 36*N	U4	2^-8	withAge	ppb/yea	Oscillator stability with age (must be > 0)
				r	Only used if sourceType is 1.
24 + 36*N	U2	-	timeToTemp	S	The minimum time that it could take for a
					temperature variation to move the oscillator
					frequency by 'withTemp' (must be > 0)
					Only used if sourceType is 1.
26 + 36*N	U2	-	maxDevLifeTim	ppb	Maximum frequency deviation during lifetime
			е		(must be > 0)
					Only used if sourceType is 1.
28 + 36*N	14	-	offset	ns	Phase offset of signal
					Only used if sourceType is 2.
32 + 36*N	U4	-	offsetUncerta	ns	Uncertainty of phase offset (one standard
			inty		deviation)
					Only used if sourceType is 2.
36 + 36*N	U4	-	jitter	ns/s	Phase jitter (must be > 0)
					Only used if sourceType is 2.
End of repeated	block	•	- •		

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description
polarity	Polarity of signal:
	0: leading edge is rising edge
	1: leading edge is falling edge
gnssUtc	Time base of timing signal:
	0: GNSS - as specified in CFG-TP5 (or GPS if CFG-TP5 indicates UTC)
	1: UTC
	Only used if sourceType is 2.



21.11.6 UBX-CFG-GNSS (0x06 0x3E)

21.11.6.1 Poll the GNSS system configuration

Message	CFG-GNSS											
Description	Poll the GN	Poll the GNSS system configuration										
Firmware	Supported of	Supported on:										
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 										
Туре	Poll Request	Poll Request										
Comment	Polls the cor	nfigurat	ion of	the GNSS system configuration								
	Header	Class	ID	Length (Bytes)	Payload	Checksum						
Message Structure	0xB5 0x62	0x06	0x3E	0	see below	CK_A CK_B						
No payload	·	•	•	•								

21.11.6.2 GNSS system configuration

Message		CFC	G-GNSS										
Description		GN	SS syste	m con	figura	tion							
Firmware		Sup	ported o	n:									
		• U	I-blox M8	B from	firmwa	are versi	on 2.00	up to version 2.30					
Туре		Inp	ut/Outpu	t									
Comment		Get	s or sets	the GN	ISS sys	tem cha	annel sh	aring configuration. T	The receiver w	rill send an			
		UB>	X-ACK-A	CK me	ssage i	f the co	onfigurat	ion is valid, an UBX-A	ACK-NAK if ar	ny configuration			
		par	ameter is	invalio	ł.								
		The	e number	of trac	king cl	hannels	in use r	nust not exceed the i	number of tra	cking channels			
								reserved tracking cha					
			equal to the number of tracking channels in use. Additionally, the maximum number of										
			acking channels used for the specific GNSS system must be greater or equal to the umber of reserved tracking channels.										
						0							
								cussion of the use of		and section			
						-		he GNSS IDs available					
			Configuration specific to the GNSS system can be done via other messages (e.g.										
			X-CFG-S	,	~ -				1				
								cannot be selected w		iver is			
			-					de (using UBX-CFG-					
		Head		Class				oth enabled or both o		Checksum			
						Length		(DI I	Payload				
Message Struc		OXB	5 0x62	0x06	0x3E	4 + 8*	numCo	nfigBlocks	see below	СК_АСК_В			
Payload Conte													
Byte Offset	Numb	ber	Scaling	Name			Unit	Description					
	Forma	at											
0	U1		-	msg\			-	Message version (=					
1	U1		-	num	「rkChl	Hw	-	Number of tracking	0	ailable in			
								hardware (read on					
2	U1		-	num	rkCh	Use	-	Number of tracking	g channels to	use (<=			
								numTrkChHw)		<u> </u>			
3	U1		-		Config	gBloc	-	Number of configu	uration blocks	tollowing			
				ks									



CFG-GNSS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
Start of repeate	ed block (nun	nConfigBloc	ks times)	·	
4 + 8*N	U1	-	gnssId	-	GNSS identifier (see Satellite Numbering)
5 + 8*N	U1	-	resTrkCh	-	Number of reserved (minimum) tracking
					channels for this GNSS system
6 + 8*N	U1	-	maxTrkCh	-	Maximum number of tracking channels used for
					this GNSS system (>=resTrkChn)
7 + 8*N	U1	-	reserved1	-	Reserved
8 + 8*N	X4	-	flags	-	bitfield of flags (see graphic below)
End of repeated	d block	•	÷	·	

Bitfield flags

This Graphic explains the bits of flags

sigCfgMask enable				23	22	21	20	19	18	17	16								0
				×.															enable

signed value unsigned value reserved

Name	Description
enable	Enable this GNSS system
sigCfgMask	Signal configuration mask
	When gnssld is 0 (GPS)
	* 0x01 = GPS L1CA
	When gnssld is 1 (SBAS)
	* 0x01 = SBAS L1CA
	When gnssld is 3 (BeiDou)
	* 0x01 = BDS B1I
	When gnssld is 5 (QZSS)
	* 0x01 = QZSS L1CA
	* 0x04 = QZSS L1SAIF
	When gnssld is 6 (GLONASS)
	* 0x01 = GLONASS L1OF



21.11.7 UBX-CFG-INF (0x06 0x02)

21.11.7.1 Poll configuration for one protocol

Message		CFC	G-INF										
Description		Pol	ll configu	iration	for o	ne pro	tocol						
Firmware		Sup	oported on:										
		• L	u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Pol	l Request										
Comment		-											
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	0xB	35 0x62	5 0x62 0x06 0x02 1 see below CK_A CK_B									
Payload Contei	nts:												
Byte Offset	Numb Forma		Scaling	Name			Unit	Description					
0	U1		-	prot	.ocol:	ID	-	Protocol Identifier, iden protocol for this Poll R valid Protocol Identifie 0: UBX Protocol 1: NMEA Protocol 2-255: Reserved	equest. Th				

21.11.7.2 Information message configuration

Message		CF	CFG-INF										
Description		Inf	ormatio	n mess	age co	onfigui	ration						
Firmware		Sup	oported o	n:									
		• (u-blox M8	3 from	firmwa	ire versi	on 2.00	up to version 2.30					
Туре		Inp	put/Output										
Comment		me Me In t fro cor poi	The value of infMsgMask[x] below are that each bit represents one of the INF class messages (Bit 0 for ERROR, Bit 1 for WARNING and so on.). For a complete list, see the Message Class INF. Several configurations can be concatenated to one input message in this case the payload length can be a multiple of the normal length. Output messages rom the module contain only one configuration unit. Note that I/O Ports 1 and 2 correspond to serial ports 1 and 2. I/O port 0 is DDC. I/O port 3 is USB. I/O port 4 is SPI. I/o port 5 is reserved for future use. Meader Class ID Length (Bytes) Payload Checksum										
				Class	ID				Payload	Checksum			
Message Struct	ure	0xE	35 0x62	0x06	0x02	0 + 10)*N		see below	CK_A CK_B			
Payload Conter	nts:												
Byte Offset	Num Form		Scaling	Name			Unit	Description					
Start of repeate	ed block	(N tir	mes)										
N*10	U1		-	prot	cocol	ID	-	Protocol Identifier, ide protocol the configur following are valid Pro 0: UBX Protocol 1: NMEA Protocol 2-255: Reserved	ation is set	/get. The			




CFG-INF continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
1 + 10*N	U1[3]	-	reserved1	-	Reserved
4 + 10*N	X1[6]	-	infMsgMask	-	A bit mask, saying which information messages are enabled on each I/O port (see graphic below)
End of repeated	block				

Bitfield infMsgMask

This Graphic explains the bits of infMsgMask



■ signed value ■ unsigned value ■ reserved

Name	Description
ERROR	enable ERROR
WARNING	enable WARNING
NOTICE	enable NOTICE
TEST	enable TEST
DEBUG	enable DEBUG

21.11.8 UBX-CFG-ITFM (0x06 0x39)

21.11.8.1 Poll Jamming/Interference Monitor configuration

Message	CFG-ITFM					
Description	Poll Jammi	ng/Inte	erferei	nce Monitor configuration		
Firmware	Supported c u-blox M8 		firmwa	re version 2.00 up to version 2.30		
Туре	Poll Request					
Comment	-					
	Header	Class	ID	Length (Bytes)	Payload	Checksum
Message Structure	0xB5 0x62	0x06	0x39	0	see below	CK_A CK_B
No payload		•				·



21.11.8.2 Jamming/Interference Monitor configuration

Message		CFO	FG-ITFM										
Description		Jan	nming/Ir	terfer	ence M	Nonito	r config	uration					
Firmware			oported o u-blox M8		firmwa	ire versi	on 2.00	up to version 2.30					
Туре		Co	mmand										
Comment		Co	nfiguratio	n of Ja	mming	g/Interfe	erence m	ionitor.					
		Hea	leader Class ID Length (Bytes) Payload Checksum										
Message Struc	ture	OxE	35 0x62	0x06	0x39	8			see below	CK_A CK_B			
Payload Conte	nts:								•	•			
Byte Offset	Num Form		Scaling	Name			Unit	Description					
0	X4		-	conf	ig		-	interference config wo	ord. (see g	raphic below)			
4	X4		-	conf	ig2		-	extra settings for jamn (see graphic below)	ning/interf	erence monitor			

Bitfield config

This Graphic explains the bits of config

31 30 29 28 27 20	5 25 24	23 22	2 21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
enable enable al@orithmBits al@orithmBits reserved																cwThreshold					bbThreshold			
Name	Descripti	ion																						
bbThreshold	Broadba	nd jamm	ning d	etecti	ion tł	hresk	nold	(uni	t = d	IB)														

bbThreshold	Broadband jamming detection threshold (unit = dB)
cwThreshold	CW jamming detection threshold (unit = dB)
algorithmBits	reserved algorithm settings - should be set to 0x16B156 in hex for correct settings
enable	enable interference detection

Bitfield config2

This Graphic explains the bits of config2



Name	Description
generalBits	general settings - should be set to 0x31E in hex for correct setting
antSetting	antennaSetting, 0=unknown, 1=passive, 2=active
enable2	Set to 1 to scan auxiliary bands (u-blox M8 only, otherwise ignored)



21.11.9 UBX-CFG-LOGFILTER (0x06 0x47)

21.11.9.1 Poll Data Logger filter Configuration

Message	CFG-LOGFII	CFG-LOGFILTER											
Description	Poll Data L	Poll Data Logger filter Configuration											
Firmware	Supported o	Supported on:											
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 											
Туре	Poll Request	Poll Request											
Comment	Upon sendir	ng of th	is mes	sage, the receiver returns CFG-LOGFILTE	R as defin	ed below							
	Header	Class	ID	Length (Bytes)	Payload	Checksum							
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x47 0 see below CK_A CK_B											
No payload	·	•	•	•		•							

21.11.9.2 Data Logger Configuration

Message		CFC	CFG-LOGFILTER																	
Description		Dat	ta Logge	r Conf	igurat	tion														
Firmware		Sup	oported o	n:																
		• L	u-blox M8 from firmware version 2.00 up to version 2.30																	
Туре		Inp	ut/Outpu [.]	t																
Comment This message is used to enable/disable logging and to get or set the position entry settings. Position entries can be filtered based on time difference, position difference or cur speed thresholds. Position and speed filtering also have a minimum time interval. A position is logged if any of the thresholds are exceeded. If a threshold is set to z ignored. The maximum rate of position logging is 1Hz. The filter settings will only be applied if the 'applyAllFilterSettings' flag is set. This recording to be enabled/disabled without affecting the other settings.									e or current erval. et to zero it is											
		Header Class ID Length (Bytes)							Payload	Checksum										
Message Structure 0xB5 0x62				0x06	0x47	12		see below	СК_АСК_В											
Payload Conte	nts:					•														
Byte Offset	Numb Forma		Scaling	Name	Name		Unit	Description												
0	U1		-	version		-	The version of this message. Set to 1													
1	X1		-	flag	IS		-	Flags (see graphic below)												
2	U2		-		-		-		-						minInterval		S	Minimum time interval between logged		
								positions (0 = not set). This is only applied i												
							combination with the speed and/or													
								position thresholds												
4	U2		-	time	timeThreshold		S	If the time difference is greater than the threshold then the position is logged ($0 = not$ set).												
6	U2	-		spee d	speedThreshol d		m/s	If the current speed is greater than the threshold then the position is logged (0 = not set). minInterval also applies												




CFG-LOGFILTER continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
8	U4	-	positionThres	m	If the 3D position difference is greater than the
			hold		threshold then the position is logged (0 = not
					set). minInterval also applies

Bitfield flags

This Graphic explains the bits of flags



reserved

Name	Description
recordEnabled	1 = enable recording, 0 = disable recording
psmOncePerWak	1 = enable recording only one single position per PSM on/off mode wake up period, 0 = disable once per wake up
upEnabled	
applyAllFilte	1 = apply all filter settings, 0 = only apply recordEnabled
rSettings	

21.11.10 UBX-CFG-MSG (0x06 0x01)

21.11.10.1 Poll a message configuration

Message		CFO	CFG-MSG										
Description		Po	Poll a message configuration										
Firmware			upported on: u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Pol	Poll Request										
Comment		-		-	_								
		Hea	der	Class	ID	Length ((Bytes)		Payload	Checksum			
Message Struct	ıre	OxE	35 0x62	0x06	0x01	2			see below	CK_A CK_B			
Payload Conten	ts:					•			•				
Byte Offset	Numb	ber	Scaling	Name			Unit	Description					
	Forma	ət											
0	U1		-	msgC	lass		-	Message Class					
1	U1		-	msgl	D		-	Message Identifier					



21.11.10.2 Set Message Rate(s)

Message		CFG	G-MSG										
Description		Set	Set Message Rate(s)										
Firmware			upported on:										
			u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Inpι	nput/Output										
Comment Message Structu		 Set/Get message rate configuration (s) to/from the receiver. See also section How to change between protocols. Send rate is relative to the event a message is registered on. For example, if the rate of a navigation message is set to 2, the message is sent every second navigation solution. For configuring NMEA messages, the section NMEA Messages Overview describes Class and Identifier numbers used. Header Class ID Length (Bytes) Payload Checksum 0xB5 0x62 0x06 0x01 8 									if the rate of a on solution. For ribes Class and		
Payload Contents	s:												
Byte Offset	Numbe Format		Scaling	Name	Name Unit Description								
0	U1		-	msgClass - Message Class									
1	U1		-	msgI	D		-	Message Identifier					
2	U1[6]]	-	rate	5		-	Send rat	te on I/O Port	(6 Ports)			

21.11.10.3 Set Message Rate

Message		CFO	G-MSG										
Description		Set	Set Message Rate										
Firmware			upported on: u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Inp	nput/Output										
Comment			Set message rate configuration for the current port. See also section How to change between protocols.										
		Hea	der	Class	ID	Length ((Bytes)		Payload	Checksum			
Message Struct	ure	OxE	35 0x62	0x06	0x01	3			see below	CK_A CK_B			
Payload Conten	ts:												
Byte Offset	Num Form		Scaling	ng Name			Unit	Description					
0	U1		-	msgC	msgClass			Message Class					
1	U1		-	msgI	msgID			Message Identifier					
2	U1		-	rate			-	Send rate on current Port					



21.11.11 UBX-CFG-NAV5 (0x06 0x24)

21.11.11.1 Poll Navigation Engine Settings

Message	CFG-NAV5	CFG-NAV5									
Description	Poll Naviga	Poll Navigation Engine Settings									
Firmware	Supported o	n:									
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 									
Туре	Poll Request										
Comment	-			bayload) message to the receiver results /5 with a payload as defined below.	in the rece	eiver returning a					
	Header	Header Class ID Length (Bytes) Payload Checksum									
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x24 0 see below CK_A CK_B									
No payload	·	•	•		•						

21.11.11.2 Navigation Engine Settings

Message		CFC	CFG-NAV5								
Description		Na	lavigation Engine Settings								
Firmware		Sup	Supported on:								
		• L	u-blox M8 from firmware version 2.00 up to version 2.30								
Туре		Inp	ut/Outpu ⁻	t							
Comment		See	the Navi	gation	Config	guratior	Settings	Description for a detail	ed descrip	tion of how	
		the	se setting	s affec	t recei	ver ope	ration.				
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	OxB	5 0x62	0x06	0x24	36			see below	CK_A CK_B	
Payload Conte	nts:					•				•	
Byte Offset	Numb	ber	Scaling	Name			Unit	Description			
	Forma	ət									
0	X2		-	mask	2		-	Parameters Bitmask. Only the masked			
								parameters will be applied. (see graphic below			
2	U1		-	dyn№	dynModel			Dynamic platform model:			
								0: portable			
								2: stationary			
								3: pedestrian			
								4: automotive			
								5: sea			
								6: airborne with <1g A			
								7: airborne with <2g A			
								8: airborne with <4g A	Acceleratic	n	
3	U1		-	fix№	Iode		-	Position Fixing Mode:			
								1: 2D only			
								2: 3D only			
								3: auto 2D/3D			
4	4		0.01	_	edAlt		m	Fixed altitude (mean sea level) for 2D fix mode			
8	U4		0.0001		edAlt	Var	m^2	Fixed altitude variance			
12	11		-	minE	llev		deg	Minimum Elevation fo	r a GNSS s	atellite to be	
								used in NAV			




CFG-NAV5 continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
13	U1	-	drLimit	S	Reserved
14	U2	0.1	pDop	-	Position DOP Mask to use
16	U2	0.1	tDop	-	Time DOP Mask to use
18	U2	-	рАсс	m	Position Accuracy Mask
20	U2	-	tAcc	m	Time Accuracy Mask
22	U1	-	staticHoldThr	cm/s	Static hold threshold
			esh		
23	U1	-	dgpsTimeOut	S	DGPS timeout.
24	U1	-	cnoThreshNumS	-	Number of satellites required to have C/N0
			Vs		above cnoThresh for a fix to be attempted
25	U1	-	cnoThresh	dBHz	C/N0 threshold for deciding whether to attempt
					a fix
26	U1[2]	-	reserved1	-	Reserved
28	U2	-	staticHoldMax	m	Static hold distance threshold (before quitting
			Dist		static hold)
30	U1	-	utcStandard	-	UTC standard to be used:
					0: not specified; receiver may choose freely
					3: UTC as operated by the U.S. Naval
					Observatory (USNO); derived from GPS time
					6: UTC as operated by the former Soviet Union;
					derived from GLONASS time
					7: UTC as operated by the National Time Service
					Center, China; derived from BeiDou time
					(not supported in protocol versions less than 16).
31	U1[5]	-	reserved2	-	Reserved

Bitfield mask

This Graphic explains the bits of ${\tt mask}$



■ signed value ■ unsigned value ■ reserved

Name	Description
dyn	Apply dynamic model settings
minEl	Apply minimum elevation settings
posFixMode	Apply fix mode settings
drLim	Reserved
posMask	Apply position mask settings
timeMask	Apply time mask settings



Bitfield mask Description continued

Name	Description
staticHoldMas	Apply static hold settings
k	
dgpsMask	Apply DGPS settings.
cnoThreshold	Apply CNO threshold settings (cnoThresh, cnoThreshNumSVs).
utc	Apply UTC settings.
	(not supported in protocol versions less than 16).

21.11.12 UBX-CFG-NAVX5 (0x06 0x23)

21.11.12.1 Poll Navigation Engine Expert Settings

Message	CFG-NAVX	CFG-NAVX5									
Description	Poll Naviga	Poll Navigation Engine Expert Settings									
Firmware	Supported o	Supported on:									
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 									
Туре	Poll Request	Poll Request									
Comment	Sending this	(empt	y / no-p	payload) message to the receiver results	in the rece	eiver returning a					
	message of	type CF	G-NA	VX5 with a payload as defined below.							
	Header	Class	ID	Length (Bytes)	Payload	Checksum					
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x23 0 see below CK_A CK_B									
No payload	•	•	•	•	•	•					

21.11.12.2 Navigation Engine Expert Settings

Message		CF	CFG-NAVX5								
Description		Na	avigation Engine Expert Settings								
Firmware		Su	upported on:								
		• 1	u-blox M8 from firmware version 2.00 up to version 2.30								
Туре		Inp	out/Outpu	ut							
Comment		-									
		Hea	Header Class ID Length (Bytes) Payl				Payload	Checksum			
Message Struct	ture	0x8	35 0x62	0x06	0x23	40			see below	CK_A CK_B	
Payload Conter	nts:										
Byte Offset	Num	ber	Scaling	Name			Unit	Description			
	Form	at									
0	U2		-	vers	sion		-	Message version (0 for this version)			
2	X2		-	mask1		- F		First parameters bitmask. Only the flagged			
								parameters will be ap	plied, unus	ed bits must be	
								set to 0. (see graphic	below)		
4	X4		-	mask	mask2		- Second parameters bitmask. O			y the flagged	
								parameters will be applied, unused bits must be			
								set to 0. (see graphic	below)		
8	U1[2	2]	-	rese	erved	1	-	Reserved	Reserved		
10	U1		-	mins	minSVs		#SVs	Minimum number of satellites for navigation			
11	U1		-	maxs	SVs		#SVs	Maximum number of satellites for navigation			
12	U1		-	minC	CNO		dBHz	Minimum satellite signal level for navigation			






CFG-NAVX5 continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
13	U1	-	reserved2	-	Reserved
14	U1	-	iniFix3D	-	1 = initial fix must be 3D
15	U1[2]	-	reserved3	-	Reserved
17	U1	-	ackAiding	-	1 = issue acknowledgements for assistance
					message input
18	U2	-	wknRollover	-	GPS week rollover number; GPS week numbers
					will be set correctly from this week up to 1024
					weeks after this week. Setting this to 0 reverts
					to firmware default.
20	U1[6]	-	reserved4	-	Reserved
26	U1	-	usePPP	-	1 = use Precise Point Positioning (only available
					with the PPP product variant)
27	U1	-	aopCfg	-	AssistNow Autonomous configuration (see
					graphic below)
28	U1[2]	-	reserved5	-	Reserved
30	U2	-	aopOrbMaxErr	m	Maximum acceptable (modeled) AssistNow
					Autonomous orbit error (valid range = 51000,
					or 0 = reset to firmware default)
32	U1[4]	-	reserved6	-	Reserved
36	U1[3]	-	reserved7	-	Reserved
39	U1	-	useAdr	-	Only supported on certain product variants

Bitfield mask1

This Graphic explains the bits of mask1



■ signed value ■ unsigned value ■ reserved

Name	Description
minMax	1 = apply min/max SVs settings
minCno	1 = apply minimum C/N0 setting
initial3dfix	1 = apply initial 3D fix settings
wknRoll	1 = apply GPS weeknumber rollover settings
ackAid	1 = apply assistance acknowledgement settings
ppp	1 = apply usePPP flag
aop	1 = apply aopCfg (useAOP flag) and aopOrbMaxErr settings (AssistNow Autonomous)




Bitfield mask2

This Graphic explains the bits of mask2

	6
	는 문
signed value unsigned value reserved	
Name	Description
adr	Apply ADR usage setting (useAdr flag)

Bitfield aopCfg

This Graphic explains the bits of aopCfg



Name	Description
useAOP	1 = enable AssistNow Autonomous

21.11.13 UBX-CFG-NMEA (0x06 0x17)

21.11.13.1 Poll the NMEA protocol configuration

Message	CFG-NMEA	CFG-NMEA									
Description	Poll the NN	Poll the NMEA protocol configuration									
Firmware	Supported of	Supported on:									
	• u-blox M	 u-blox M8 from firmware version 2.00 up to version 2.30 									
Туре	Poll Request	Poll Request									
Comment	-										
	Header	Header Class ID Length (Bytes) Payload Checksum									
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x17 0 see below CK_A CK_B									
No payload		1	•			1					

21.11.13.2 NMEA protocol configuration (deprecated)


Message	CFG-NMEA	CFG-NMEA									
Description	NMEA prot	NMEA protocol configuration (deprecated)									
Firmware	Supported o	Supported on:									
	• u-blox M8	• u-blox M8 from firmware version 2.00 up to version 2.30									
Туре	Input/Output										
Comment	This message	ge ver	sion is	provided for backwards compatibili	ty only. L	Jse the last					
	version list	ed bel	ow ins	tead (its fields are backwards compa	atible wit	h this version,					
	it just has e	xtra fi	elds d	efined).							
	Set/Get the	NMEA	protoc	ol configuration. See section NMEA Prot	ocol Conf	iguration for a					
	detailed deso	criptior	of the	e configuration effects on NMEA output							
	Header	Header Class ID Length (Bytes) Payload Checksum									
Message Structure	0xB5 0x62	0x06	0x17	4	see below	CK_A CK_B					



Payload Conte	Payload Contents:							
Byte Offset	Number	Scaling	Name	Unit	Description			
	Format							
0	X1	-	filter	-	filter flags (see graphic below)			
1	U1	-	nmeaVersion	-	0x23: NMEA version 2.3			
					0x21: NMEA version 2.1			
2	U1	-	numSV	-	Maximum Number of SVs to report per Talkerld.			
					0: unlimited			
					8: 8 SVs			
					12: 12 SVs			
					16: 16 SVs			
3	X1	-	flags	-	flags (see graphic below)			

Bitfield filter


This Graphic explains the bits of filter



Name	Description
posFilt	Enable position output for failed or invalid fixes
mskPosFilt	Enable position output for invalid fixes
timeFilt	Enable time output for invalid times
dateFilt	Enable date output for invalid dates
gpsOnlyFilter	Restrict output to GPS satellites only
trackFilt	Enable COG output even if COG is frozen

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description
compat	enable compatibility mode.
	This might be needed for certain applications when customer's NMEA parser expects a fixed number of digits in
	position coordinates
consider	enable considering mode.



21.11.13.3 NMEA protocol configuration V0 (deprecated)

		-		-		-				1			
Message		CFC	CFG-NMEA										
Description		NM	IEA prot	ocol c	onfigu	iration	V0 (de	precated)					
Firmware		Sup	ported o	n:									
		• u	i-blox M8	3 from	firmwa	are vers	ion 2.00) up to version 2.30					
Туре		Input/Output											
Comment		Thi	s messa	ge ver	sion is	provi	ded for	backwards compatibili	ty only. I	Use the last			
			version listed below instead (its fields are backwards compatible with this version,										
		-	ust has e										
			Set/Get the NMEA protocol configuration. See section NMEA Protocol Configuration for a										
				-				effects on NMEA output					
		Head	der	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	0xB	5 0x62	0x06	0x17	12			see below	CK_A CK_B			
Payload Conte	nts:												
Byte Offset	Numb	ber	Scaling	Name	Name		Unit	Description					
	Forma	at											
0	X1		-	filt	er		-	filter flags (see graphic	filter flags (see graphic below)				
1	U1		-	nmeaVersion		-	0x23: NMEA version 2						
							0x21: NMEA version 2						
2	U1	-		nums	numSV		-	Maximum Number of	oort per Talkerld.				
								0: unlimited					
								8: 8 SVs					
								12: 12 SVs					
2								16: 16 SVs					
3	X1		-	flag		- .	-	flags (see graphic below)					
4	X4		-	gnss	SToFi	lter	-		Filters out satellites based on their GNSS. If a				
								bitfield is enabled, the corresponding		-			
8	U1		-					-	will be not output. (see graphic below) Configures the display of satellites that do not				
0			-	SVNI	umber	ing	-	have an NMEA-defined		es that do not			
								Note: this does not ap		ullitos with an			
								unknown ID.					
								0: Strict - Satellites are	not outp	+			
								1: Extended - Use prop	•				
								Satellite numbering)	netary nt	ambening (see			
								Satellite numbering)					






CFG-NMEA continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
9	U1	-	mainTalkerId		 By default the main Talker ID (i.e. the Talker ID used for all messages other than GSV) is determined by the GNSS assignment of the receiver's channels (see UBX-CFG-GNSS). This field enables the main Talker ID to be overridden. O: Main Talker ID is not overridden 1: Set main Talker ID to 'GP' 2: Set main Talker ID to 'GN' 4: Set main Talker ID to 'GA' 5: Set main Talker ID to 'GB'
10	U1	-	gsvTalkerId	-	By default the Talker ID for GSV messages is GNSS specific (as defined by NMEA). This field enables the GSV Talker ID to be overridden. 0: Use GNSS specific Talker ID (as defined by NMEA) 1: Use the main Talker ID
11	U1	-	version	-	Message version (set to 0 for this version)

Bitfield filter

This Graphic explains the bits of filter



signed value unsigned value


reserved	

Name	Description
posFilt	Enable position output for failed or invalid fixes
mskPosFilt	Enable position output for invalid fixes
timeFilt	Enable time output for invalid times
dateFilt	Enable date output for invalid dates
gpsOnlyFilter	Restrict output to GPS satellites only
trackFilt	Enable COG output even if COG is frozen



Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description
compat	enable compatibility mode.
	This might be needed for certain applications when customer's NMEA parser expects a fixed number of digits in
	position coordinates
consider	enable considering mode.

Bitfield gnssToFilter

This Graphic explains the bits of gnssToFilter

	6 5	4	1	0
	je j	dzs gzs	sbas	SdS

■ signed value ■ unsigned value ■ reserved

Name	Description
gps	Disable reporting of GPS satellites
sbas	Disable reporting of SBAS satellites
qzss	Disable reporting of QZSS satellites
glonass	Disable reporting of GLONASS satellites
beidou	Disable reporting of BeiDou satellites

21.11.13.4 Extended NMEA protocol configuration V1

Message		CFC	CFG-NMEA								
Description		Ext	xtended NMEA protocol configuration V1								
Firmware		Sup	Supported on:								
		• L	ı-blox M8	from	firmwa	ire versi	on 2.00	up to version 2.30			
Туре		Inp	ut/Output	t							
Comment		Set	/Get the N	IMEA	protoc	<mark>ol</mark> confi	guration	See section NMEA Pr	otocol Conf	iguration for a	
		det	ailed deso	ription	n of the	e config	uration e	ffects on NMEA outp	ut.		
		Head	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Structur	re	0xB	5 0x62	0x06	0x17	20 see below CH			CK_A CK_B		
Payload Contents	5.				•	•					
Byte Offset	Numb	nber Scaling Name Unit Description									
	Forma	nt									
0	X1		-	filt	ilter - filter flags (see graphic below)						



CFG-NMEA continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
1	U1	-	nmeaVersion	-	0x41: NMEA version 4.1
					0x40: NMEA version 4.0
					0x23: NMEA version 2.3
					0x21: NMEA version 2.1
2	U1	-	numSV	-	Maximum Number of SVs to report per Talkerld.
					0: unlimited
					8: 8 SVs
					12: 12 SVs
					16: 16 SVs
3	X1	-	flags	-	flags (see graphic below)
4	X4	-	gnssToFilter	-	Filters out satellites based on their GNSS. If a
					bitfield is enabled, the corresponding satellites
					will be not output. (see graphic below)
8	U1	-	svNumbering	-	Configures the display of satellites that do not
					have an NMEA-defined value.
					Note: this does not apply to satellites with an
					unknown ID.
					0: Strict - Satellites are not output
					1: Extended - Use proprietary numbering (see
					Satellite numbering)
9	U1	-	mainTalkerId	-	By default the main Talker ID (i.e. the Talker ID
					used for all messages other than GSV) is
					determined by the GNSS assignment of the
					receiver's channels (see UBX-CFG-GNSS).
					This field enables the main Talker ID to be
					overridden.
					0: Main Talker ID is not overridden
					1: Set main Talker ID to 'GP'
					2: Set main Talker ID to 'GL'
					3: Set main Talker ID to 'GN'
					4: Set main Talker ID to 'GA'
					5: Set main Talker ID to 'GB'
10	U1	-	gsvTalkerId	-	By default the Talker ID for GSV messages is
			-		GNSS specific (as defined by NMEA).
					This field enables the GSV Talker ID to be
					overridden.
					0: Use GNSS specific Talker ID (as defined by
					NMEA)
					1: Use the main Talker ID
11	U1	-	version	-	Message version (set to 1 for this version)
12	CH[2]	-	bdsTalkerId	-	Sets the two characters that should be used for
					the BeiDou Talker ID
					If these are set to zero, the default BeiDou
					Talkerld will be used




CFG-NMEA continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
14	U1[6]	-	reserved1	-	Reserved

Bitfield filter


This Graphic explains the bits of filter



Name	Description
posFilt	Enable position output for failed or invalid fixes
mskPosFilt	Enable position output for invalid fixes
timeFilt	Enable time output for invalid times
dateFilt	Enable date output for invalid dates
gpsOnlyFilter	Restrict output to GPS satellites only
trackFilt	Enable COG output even if COG is frozen

Bitfield flags

This Graphic explains the bits of flags



signed value unsigned value reserved

Name	Description
compat	enable compatibility mode.
	This might be needed for certain applications when customer's NMEA parser expects a fixed number of digits in
	position coordinates
consider	enable considering mode.
limit82	enable strict limit to 82 characters maximum.

Bitfield gnssToFilter

This Graphic explains the bits of gnssToFilter

															6	5	4		1	0
															beidou	glonass	dzss		sbas	Sps
si ur re	igned nsign eserv	l va ied ied	lue valu	e																





Bitfield gnssToFilter Description continued

Name	Description
Name	Description
gps	Disable reporting of GPS satellites
sbas	Disable reporting of SBAS satellites
qzss	Disable reporting of QZSS satellites
glonass	Disable reporting of GLONASS satellites
beidou	Disable reporting of BeiDou satellites

21.11.14 UBX-CFG-ODO (0x06 0x1E)

21.11.14.1 Poll Odometer, Low-speed COG Engine Settings

Message	CFG-ODO	CFG-ODO												
Description	Poll Odome	Poll Odometer, Low-speed COG Engine Settings												
Firmware	Supported c	Supported on:												
	• u-blox M8	u-blox M8 from firmware version 2.00 up to version 2.30												
Туре	Poll Request	Poll Request												
Comment	Sending this	(empt	y / no-p	payload) message to the receiver results	in the rece	eiver returning a								
	message of	type CF	G-OD	O with a payload as defined below.										
	Header	Class	ID	Length (Bytes)	Payload	Checksum								
Message Structure	ructure 0xB5 0x62 0x06 0x1E 0 see below CK_A CK_B													
No payload	•	•	•	•	•									

21.11.14.2 Odometer, Low-speed COG Engine Settings

Message		CFG-C	ODO										
Description		Odon	neter,	Low-s	peed	COG Ei	ngine Se	ettings					
Firmware	orted o	rted on:											
	• u-b	u-blox M8 from firmware version 2.00 up to version 2.30											
Туре		Input/	/Output	t									
Comment	feature	e is not supported for the FTS product variant.											
		Header	-	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Structure 0xB5 0x62			0x62	0x06	0x1E	20			see below	СК_АСК_В			
Payload Conte	nts:	•			•	•			•				
Byte Offset	Num	ber Sca	aling	Name			Unit	Description					
	Form	at											
0	U1	-		vers	sion		-	Message version (0 for this version)					
1	U1[3	3] -		rese	erved	1	-	Reserved					
4	U1	-		flag	js		-	Odometer/Low-speed COG filter flags (see graphic below)					
5	X1	-		odoC	fg		-	Odometer filter setting	gs (see gra	phic below)			
6	U1[6	5] -		rese	erved	2	-	Reserved					
12	U1	16	e-1	cogM	laxSp	eed	m/s	Speed below which co	ourse-over-	ground (COG)			
						is computed with the low-speed COG filter							
13	U1	-		cogM	laxPo	sAcc	m	Maximum acceptable position accuracy for					
								computing COG with the low-speed COG filter					




CFG-ODO continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
14	U1[2]	-	reserved3	-	Reserved
16	U1	-	velLpGain	-	Velocity low-pass filter level, range 0255
17	U1	-	cogLpGain	-	COG low-pass filter level (at speed < 8 m/s),
					range 0255
18	U1[2]	-	reserved4	-	Reserved

Bitfield flags

This Graphic explains the bits of flags




unsigned reserved

Name	Description
use0D0	Odometer enabled flag
useCOG	Low-speed COG filter enabled flag
outLPVel	Output low-pass filtered velocity flag
outLPCog	Output low-pass filtered heading (COG) flag

Bitfield odoCfg

This Graphic explains the bits of odoCfg





21.11.15 UBX-CFG-PM2 (0x06 0x3B)

21.11.15.1 Poll extended Power Mgmt configuration

Message	CFG-PM2													
Description	Poll extend	Poll extended Power Mgmt configuration												
Firmware		Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30												
Туре	Poll Request	Poll Request												
Comment	-													
	Header	Class	ID	Length (Bytes)	Payload	Checksum								
Message Structure	0xB5 0x62	0x06	0x3B	0	see below	CK_A CK_B								
No payload		•	•	•	·									

21.11.15.2 Extended Power Management configuration

Message	(CFG-PM2												
Description	I	Extended	Power	Manag	gemen	t config	guration							
Firmware			Supported on:											
	•	 u-blox M 	3 from firmware version 2.00 up to version 2.30											
Туре	1	nput/Outpu	put/Output											
Comment	1	This featuı	re is no	t supp	orted	for eith	ner the ADR or FTS pr	oduct varia	ints.					
	ŀ	Header	Class	ID	Length	(Bytes)		Payload	Checksum					
Message Struc	ture (0xB5 0x62	0x06	0x3B	44			see below	CK_A CK_B					
Payload Conte	nts:		•					·						
Byte Offset	Numbe Format													
0	U1	-	vers	version			Message version (1 f	Message version (1 for this version)						
1	U1	-	reserved1			-	Reserved							
2	U1	-	maxStartupSta			S	Maximum time to sp	pend in Acqu	<i>uisition</i> state. If					
			teDu	teDur			0: bound disabled (s	(see maxStartupStateDur).						
							(Only supported in protocol versions 17+)							
3	U1	-	rese	erved	2	-	Reserved							
4	X4	-	flag	js		-	PSM configuration flags (see graphic below)							
8	U4	-	upda	atePe	riod	ms	Position update period. If set to 0, the receiver							
							will never retry a fix	and it will w	ait for external					
							events							
12	U4	-	sear	cchPe	riod	ms	Acquisition retry per	•						
							to 0, the receiver wi	,						
16 U4 -			grio	dOffs	et	ms	Grid offset relative to		of week					
20	U2					S	Time to stay in <i>Tracking</i> state							
22	U2	-	minA	AcqTi	me	S	minimal search time							
24	U1[20)] -	rese	erved	3	-	Reserved	Reserved						



Bitfield flags

This Graphic explains the bits of flags

	18 17 16 12 11 10 9 8 6 5 4									
	mode chix tSel tSel									
	mode mode updateEPH updateEPH waitTimeFix limitPeakCurr extintWake extintWake extintSel									
	textint text									
	e timi sa No									
signed value	о <u>–</u>									
unsigned value reserved										
Name	Description									
extintSel	EXTINT Pin Select									
	0 EXTINTO									
	1 EXTINT1									
extintWake	EXTINT Pin Control									
	0 disabled									
	1 enabled, keep receiver awake as long as selected EXTINT pin is 'high'									
extintBackup	EXTINT Pin Control									
	0 disabled									
	1 enabled, force receiver into BACKUP mode when selected EXTINT pin is 'low'									
limitPeakCurr	Limit Peak Current									
	00 disabled									
	01 enabled, peak current is limited									
	10 reserved									
	11 reserved									
waitTimeFix	Wait for Timefix (see waitTimeFix)									
	0 wait for normal fix ok before starting on time									
	1 wait for time fix ok before starting on time									
updateRTC	Update Real Time Clock (see updateRTC)									
	0 Do not wake-up to update RTC. RTC is updated during normal on-time.									
	1 Update RTC. The receiver adds extra wake-up cycles to update the RTC.									
updateEPH	Update Ephemeris (see updateEPH)									
	0 Do not wake-up to update Ephemeris data									
	1 Update Ephemeris. The receiver adds extra wake-up cycles to update the Ephemeris data									
doNotEnterOff	Behavior of receiver in case of no fix (see doNotEnterOff)									
	0 receiver enters (Inactive) Awaiting Next Search state									
	1 receiver does not enter (Inactive) Awaiting Next Search state but keeps trying to acquire a fix instead									
mode	Mode of operation (see mode)									
	00 ON/OFF operation (PSMOO)									
	01 Cyclic tracking operation (PSMCT)									
	10 reserved									
	11 reserved									



21.11.16 UBX-CFG-PRT (0x06 0x00)

21.11.16.1 Polls the configuration of the used I/O Port

Message	CFG-PRT	CFG-PRT								
Description	Polls the co	Polls the configuration of the used I/O Port								
Firmware	Supported c	Supported on:								
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 								
Туре	Poll Request	Poll Request								
Comment	Polls the cor	figurat	ion of	the I/O Port on which this message is r	eceived					
	Header	Class	ID	Length (Bytes)	Payload	Checksum				
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x00 0 see below CK_A CK_B								
No payload	·	•	•			•				

21.11.16.2 Polls the configuration for one I/O Port

Message		CFO	CFG-PRT								
Description		Po	Polls the configuration for one I/O Port								
Firmware		Sup	oported o	n:							
		•ι	u-blox M8	8 from	firmwa	ire versi	on 2.00	up to version 2.30)		
Туре		Pol	oll Request								
Comment		Sending this message with a port ID as payload results in having the receiver return the configuration for the specified port.						r return the			
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	OxE	35 0x62	0x06	0x00	1			see below	CK_A CK_B	
Payload Conte	nts:			•		•			ŀ		
Byte Offset	Numl	ber	Scaling	Name			Unit	Description			
	Forma	rmat									
0	U1		-	Port	PortID			Port Identifier N	Port Identifier Number (see the other version		
								CFG-PRT for vali	id values)		

21.11.16.3 Port Configuration for UART

Message	CFG-PRT	CFG-PRT								
Description	Port Config	Port Configuration for UART								
Firmware	Supported o	Supported on:								
	 u-blox M8 	⁸ from ⁻	firmwa	are version 2.00 up to version 2.30						
Туре	Input/Outpu	t								
Comment	Several confi	Several configurations can be concatenated to one input message. In this case the payload								
	length can b	e a mu	Itiple o	of the normal length (see the other versi	ons of CFC	G-PRT). Output				
	messages fro	om the	modu	le contain only one configuration unit.						
	Note that thi	is mess	age ca	in affect baud rate and other transmission	on parame	ters. Because				
	there may be	there may be messages queued for transmission there may be uncertainty about which								
	protocol app	lies to	such n	nessages. In addition a message current	y in transr	nission may be				
	corrupted by	/ a prot	ocol c	hange. Host data reception paramaters	may have [.]	to be changed				
	to be able to	receiv	e futui	re messages, including the acknowledge	message	resulting from				
	the CFG-PRT	messa	ige.							
	Header	Class	ID	Length (Bytes)	Payload	Checksum				



Message Structure 0xB5 0x62			0x06	0x00	20		see below C	K_A CK_B		
Payload Conte	ents:		•	•	•		· · ·			
Byte Offset	Numb Forma	J J	Name			Unit	Description			
0	U1	-	port	portID		-	Port Identifier Number (see Serial Communication Ports Description f port IDs)	for valid UART		
1	U1	-	rese	erved	1	-	Reserved			
2	X2	-	txRe	eady		-	TX ready PIN configuration (see gra	aphic below)		
4	X4	-	mode	mode		-	A bit mask describing the UART mode (see graphic below)			
8	U4	-	baud	lRate		Bits/s	Baud rate in bits/second			
12	X2	-	inPr	inProtoMask			A mask describing which input pro active. Each bit of this mask is used for a p Through that, multiple protocols ca on a single port. (see graphic below	protocol. an be defined		
14	X2	-	out	outProtoMask			A mask describing which output protocols a active. Each bit of this mask is used for a protocol. Through that, multiple protocols can be defi on a single port. (see graphic below)			
16	X2	-	flag	js		-	Flags bit mask (see graphic below)			
18	U1[2] -	rese	erved	2	-	Reserved			

Bitfield txReady

This Graphic explains the bits of txReady

15 14 13 12 11 1	0 9 8 7 6 5 4 3 2 1 0
thres	pin pol
■ signed value ■ unsigned value ■ reserved	
Name	Description
en	Enable TX ready feature for this port
pol	Polarity
	0 High-active
	1 Low-active
pin	PIO to be used (must not be in use already by another function)



Bitfield txReady Description continued

Name	Description
thres	Threshold
	The given threshold is multiplied by 8 bytes.
	The TX ready PIN goes active after >= thres*8 bytes are pending for the port and going inactive after the last
	pending bytes have been written to hardware (0-4 bytes before end of stream).
	0x000 no threshold
	0x001 8byte
	0x002 16byte
	0x1FE 4080byte
1	0x1FF 4088byte


Bitfield mode

This Graphic explains the bits of mode

	13 12 11 10 9 7 6
Signed value	nStopBits charlen
unsigned value reserved	
Name	Description
charLen	Character Length
	00 5bit (not supported)
	01 6bit (not supported)
	10 7bit (supported only with parity)
	11 8bit
parity	000 Even Parity
	001 Odd Parity
	10X No Parity
	X1X Reserved
nStopBits	Number of Stop Bits
	00 1 Stop Bit
	01 1.5 Stop Bit
	10 2 Stop Bit
	11 0.5 Stop Bit

Bitfield inProtoMask

This Graphic explains the bits of inProtoMask






Bitfield inProtoMask Description continued

Name	Description
inUbx	UBX protocol
inNmea	NMEA protocol
inRtcm	RTCM protocol

Bitfield outProtoMask


This Graphic explains the bits of outProtoMask



signed value unsigned value reserved	
Name	Description
outUbx	UBX protocol
outNmea	NMEA protocol

Bitfield flags

This Graphic explains the bits of flags



signed vo unsigned reserved

Name	Description
extendedTxTim	Extended TX timeout: if set, the port will timeout if allocated TX memory >=4 kB and no activity for 1.5s. If not set
eout	the port will timoout if no activity for 1.5s regardless on the amount of allocated TX memory.



21.11.16.4 Port Configuration for USB Port

Message		CFG-PRT								
Description		Port Configuration for USB Port								
Firmware		Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30								
Туре		Input/Output								
Comment		Several configurations can be concatenated to one input message. In this case the payl length can be a multiple of the normal length (see the other versions of CFG-PRT). Out messages from the module contain only one configuration unit.								
		Header	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	0xB5 0x6	2 0x06	5 0x00	20			see below	СК_АСК_В	
Payload Conte	nts:		I		1					
Byte Offset	Numb Forma		ing Name			Unit	Description	iption		
0	U1	-	poi	tID		-	Port Identifier Numb	er Number (= 3 for USB port)		
1	U1	-	res	erved	.1	-	Reserved			
2	X2	-	txF	leady		-	TX ready PIN config	dy PIN configuration (see graphic below)		
4	U1[8]] -	res	erved	.2	-	Reserved			
12	X2	- inProtoMask		-	A mask describing v active. Each bit of this mas Through that, multi on a single port. (se	k is used for ple protocols	a protocol. s can be defined			
14	X2	-	out	outProtoMask		-	active. Each bit of this mas Through that, multi	A mask describing which output protocols are active. Each bit of this mask is used for a protocol. Through that, multiple protocols can be defin on a single port. (see graphic below)		
16	U1[2]] -	res	erved	.3	-	Reserved			
18	U1[2]] -	res	erved	.4	-	Reserved			

Bitfield txReady

This Graphic explains the bits of txReady

15 14 13 12 11	10 9 8 7 6 5 4 3 2 1 0
thres	pin en
↓ signed value unsigned value reserved	
Name	Description
en	Enable TX ready feature for this port
pol	Polarity
	0 High-active
	1 Low-active
pin	PIO to be used (must not be in use already by




Bitfield txReady Description continued

Name	Description
thres	Threshold
	The given threshold is multiplied by 8 bytes.
	The TX ready PIN goes active after >= thres*8 bytes are pending for the port and going inactive after the last
	pending bytes have been written to hardware (0-4 bytes before end of stream).
	0x000 no threshold
	0x001 8byte
	0x002 16byte
	0x1FE 4080byte
	0x1FF 4088byte


Bitfield inProtoMask

This Graphic explains the bits of inProtoMask



Bitfield outProtoMask

This Graphic explains the bits of outProtoMask



signed value unsigned value reserved

Name	Description
outUbx	UBX protocol
outNmea	NMEA protocol



21.11.16.5 Port Configuration for SPI Port

Message		CFG-PRT									
Description		Port Configuration for SPI Port									
Firmware			ported o I-blox M8	n: from firmware version 2.00 up to version 2.30							
Туре		Inpu	ut/Outpu	t							
Comment		leng	gth can b	e a mu	ultiple o	of the n	ormal le	ted to one input messag ength (see the other vers one configuration unit.			
		Head	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	0xB	5 0x62	0x06	0x00	20			see below	СК_АСК_В	
Payload Conte	nts:								•		
Byte Offset	Numb Forma	-	Scaling	Name	Name		Unit	Description	Description		
0	U1		-	port	ID		-	Port Identifier Number (= 4 for SPI port)			
1	U1		-	reserved1		-	Reserved				
2	X2		-	txReady		-	TX ready PIN configur	TX ready PIN configuration (see graphic below)			
4	X4		-	mode	mode		-	SPI Mode Flags (see g	SPI Mode Flags (see graphic below)		
8	U1[4]]	-	rese	reserved2		-	Reserved			
12	X2	-		inPr	inProtoMask		-	active. Each bit of this mask Through that, multipl	A mask describing which input protocols are active. Each bit of this mask is used for a protocol. Through that, multiple protocols can be defined on a single port. (see graphic below)		
14	X2	- outProtoMask		-	active. Each bit of this mask Through that, multipl	A mask describing which output protocols are active. Each bit of this mask is used for a protocol. Through that, multiple protocols can be defined on a single port. (see graphic below)					
16	X2		-	flag	js		-	Flags bit mask (see gr	Flags bit mask (see graphic below)		
18	U1[2]]	-	rese	erved	3	-	Reserved			

Bitfield txReady

This Graphic explains the bits of txReady

15 14 13 12 11 10	9 8 7 6 5 4 3 2 1 0						
thres	pin en						
↓) signed value unsigned value reserved							
Name	Description						
en	Enable TX ready feature for this port						
pol	Polarity						
	0 High-active						
	1 Low-active						
pin	PIO to be used (must not be in use already by						




Bitfield txReady Description continued

Name	Description
thres	Threshold
	The given threshold is multiplied by 8 bytes.
	The TX ready PIN goes active after >= thres*8 bytes are pending for the port and going inactive after the last
	pending bytes have been written to hardware (0-4 bytes before end of stream).
	0x000 no threshold
	0x001 8byte
	0x002 16byte
	0x1FE 4080byte
	0x1FF 4088byte


Bitfield mode

This Graphic explains the bits of mode



Bitfield inProtoMask

This Graphic explains the bits of inProtoMask



reserved




Bitfield outProtoMask

This Graphic explains the bits of outProtoMask



Bitfield flags

This Graphic explains the bits of flags



Name	Description
extendedTxTim	Extended TX timeout: if set, the port will timeout if allocated TX memory >=4 kB and no activity for 1.5s.
eout	

21.11.16.6 Port Configuration for DDC Port

Message		CF	CFG-PRT										
Description		Port Configuration for DDC Port											
Firmware		Supported on:											
		• ı	 u-blox M8 from firmware version 2.00 up to version 2.30 										
Туре		Input/Output											
Comment		len	gth can b	e a mu	ltiple c	of the n	ormal len	d to one input message gth (see the other version ne configuration unit.					
		Hea	der	Class	ID	Length (Bytes) Payload Checksu			Checksum				
Message Structu	re	OxE	35 0x62	0x06	0x00	20 see below CK_ACK_			CK_A CK_B				
Payload Content	s:												
Byte Offset	Num! Form		Scaling	Name	Name		Unit	Description					
0	U1		-	port	ID		-	Port Identifier Number (= 0 for DDC port)					
1	U1	1 -		rese	rved	1	-	Reserved					
2	X2		-	txRe	txReady		-	TX ready PIN configuration (see graphic below)					
4	X4		-	mode	mode		-	DDC Mode Flags (see graphic below)					
8	U1[4	1]	-	rese	reserved2		-	Reserved					



CFG-PRT continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
12	X2	-	inProtoMask	-	A mask describing which input protocols are
					active.
					Each bit of this mask is used for a protocol.
					Through that, multiple protocols can be defined
					on a single port. (see graphic below)
14	X2	-	outProtoMask	-	A mask describing which output protocols are
					active.
					Each bit of this mask is used for a protocol.
					Through that, multiple protocols can be defined
					on a single port. (see graphic below)
16	X2	-	flags	-	Flags bit mask (see graphic below)
18	U1[2]	-	reserved3	-	Reserved

Bitfield txReady

This Graphic explains the bits of txReady


0x1FF 4088byte

15 14 13 12 11									
thres	en bi								
⇒ ■signed value ■unsigned value ■reserved									
Name	Description								
en	Enable TX ready feature for this port								
pol	Polarity								
1	0 High-active								
	1 Low-active								
pin	PIO to be used (must not be in use already by another function)								
thres	Threshold								
	The given threshold is multiplied by 8 bytes.								
	The TX ready PIN goes active after >= thres*8 bytes are pending for the port and going inactive after the last								
	pending bytes have been written to hardware (0-4 bytes before end of stream).								
	0x000 no threshold								
	0x001 8byte								
1	0x002 16byte								
l	0x1FE 4080byte								



Bitfield mode

This Graphic explains the bits of mode




Bitfield inProtoMask

This Graphic explains the bits of inProtoMask




Bitfield outProtoMask

This Graphic explains the bits of outProtoMask



Bitfield flags

This Graphic explains the bits of flags





21.11.17 UBX-CFG-PWR (0x06 0x57)

21.11.17.1 Put receiver in a defined power state

Message		CFO	CFG-PWR								
Description		Put	Put receiver in a defined power state								
Firmware		Supported on:									
		•ι	u-blox M8 from firmware version 2.00 up to version 2.30								
Туре		Set									
Comment		-									
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struct	ture	OxE	35 0x62	0x06	0x57	8 see below		CK_A CK_B			
Payload Conter	nts:			•						•	
Byte Offset	Numl		Scaling	Name	Name		Unit	Description	Description		
0	Form U1	at	-	vers	version		-	Message version (1 for	Message version (1 for this version)		
1	U1[3	3]	-	-	reserved1		-	Reserved		,	
4	U4 -		-	stat	state		-	Enter system state			
						0x52554E20: GNSS running					
								0x53544F50: GNSS stopped			
								0x42434B50: Software	0x42434B50: Software Backup		

21.11.18 UBX-CFG-RATE (0x06 0x08)

21.11.18.1 Poll Navigation/Measurement Rate Settings

Message	CFG-RATE	CFG-RATE										
Description	Poll Naviga	Poll Navigation/Measurement Rate Settings										
Firmware	Supported c	Supported on:										
	• u-blox M8	3 from	firmwa	re version 2.00 up to version 2.30								
Туре	Poll Request											
Comment	-			payload) message to the receiver resu Te with a payload as defined below	lts in the reco	eiver returning a						
	Header	Class	ID	Length (Bytes)	Payload	Checksum						
Message Structure	0xB5 0x62	0x06	0x08	0	see below	CK_A CK_B						
No payload			•									



21.11.18.2 Navigation/Measurement Rate Settings

Message		CFG-RATE	CFG-RATE									
Description		Navigatior	Navigation/Measurement Rate Settings									
Firmware		Supported on:										
		• u-blox M	8 from	firmwa	are vers	ion 2.00	up to version 2.30					
Туре		Input/Output										
Comment		This featu	re is no	t supp	oorted	for the l	FTS product variant.					
		The u-blox positioning technology supports navigation update rates higher or lower than 1										
		update per second. The calculation of the navigation solution will always be aligned to the										
		top of a second.										
		• The update rate has a direct influence on the power consumption. The more fixes that										
		are required, the more CPU power and communication resources are required.										
		 For most applications a 1 Hz update rate would be sufficient. 										
			• When using Power Save Mode, measurement and navigation rate can differ from the									
			values configured here. See Measurement and navigation rate with Power Save Mode									
		for details.										
		Header	Class	ID	Length	(Bytes)) Payload Checksum					
Message Struc	ture	0xB5 0x62	0x06	0x08	6			see below	CK_A CK_B			
Payload Conte	ents:											
Byte Offset	Num	ber Scaling	Name			Unit	Description					
	Form	at										
0	U2	-	meas	sRate		ms	Measurement Rate, G	SPS measur	rements are			
							taken every measRate					
2	U2	-	navF	Rate		cycles	Navigation Rate, in nu					
							cycles. This parameter cannot be changed, and					
							must be set to 1.					
4	U2	-	time	eRef		-	Alignment to referen	ce time				
							0: UTC time					
							1: GPS time					

21.11.19 UBX-CFG-RINV (0x06 0x34)

21.11.19.1 Poll contents of Remote Inventory

Message	CFG-RINV	CFG-RINV							
Description	Poll conten	Poll contents of Remote Inventory							
Firmware		upported on: u-blox M8 from firmware version 2.00 up to version 2.30							
Туре	Poll Request	Poll Request							
Comment	-								
	Header	Class	ID	Length (Bytes)	Payload	Checksum			
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x34 0 see below CK_A CK_B							
No payload		•			•	•			




21.11.19.2 Contents of Remote Inventory

Message		CFC	-G-RINV							
Description		Со	ontents of Remote Inventory							
Firmware			upported on:							
		•ι	u-blox M8 from firmware version 2.00 up to version 2.30							
Туре		Inp	put/Output							
Comment			V is greater than 30, the excess bytes are discarded. In future firmware versions, this lir ay change.							rsions, this limit
		Hea	der	Class	ID	Length (Bytes)			Payload	Checksum
Message Structu	ıre	OxE	35 0x62	0x06	0x34	1 + 1*N see below			CK_A CK_B	
Payload Conten	ts:									
Byte Offset	Numl Form		Scaling	Name			Unit	Description		
0	X1	- flags					-	Flags (see graphic below)		
Start of repeated	d block	(N tin	nes)							
1 + 1*N	U1		- data - Data to store/stored in Remote Inventory						nventory	
End of repeated	block		•	•						

Bitfield flags

This Graphic explains the bits of flags



Name	Description
dump	Dump data at startup. Does not work if flag binary is set.
binary	Data is binary

21.11.20 UBX-CFG-RST (0x06 0x04)

21.11.20.1 Reset Receiver / Clear Backup Data Structures

Message	CFG-RST	CFG-RST						
Description	Reset Recei	Reset Receiver / Clear Backup Data Structures						
Firmware		Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30						
Туре	Command	Command						
Comment	Newer FWOlder FW	 Don't expect this message to be acknowledged by the receiver. Newer FW version won't acknowledge this message at all. Older FW version will acknowledge this message but the acknowledge may not be sent completely before the receiver is reset. 						
	Header	Header Class ID Length (Bytes) Payload Checksum						
Message Structure	0xB5 0x62 0x06 0x04 4 see below CK_A CK_B							
Payload Contents:								



CFG-RST continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
0	X2	-	navBbrMask	-	BBR Sections to clear. The following Special Sets
					apply:
					0x0000 Hot start
					0x0001 Warm start
					0xFFFF Cold start (see graphic below)
2	U1	-	resetMode	-	Reset Type
					0x00 - Hardware reset (Watchdog) immediately
					0x01 - Controlled Software reset
					0x02 - Controlled Software reset (GNSS only)
					0x04 - Hardware reset (Watchdog) after
					shutdown
					0x08 - Controlled GNSS stop
					0x09 - Controlled GNSS start
3	U1	-	reserved1	-	Reserved

Bitfield navBbrMask

This Graphic explains the bits of navBbrMask

15	8 7 6 5 4 3 2 1 0						
aop	rtc clkd pos alm eph eph						
■ signed value ■ unsigned value ■ reserved							
Name	Description						
eph	Ephemeris						
alm	Almanac						
health	Health						
klob	Klobuchar parameters						
pos	Position						
clkd	Clock Drift						
OSC	Oscillator Parameter						
utc	UTC Correction + GPS Leap Seconds Parameters						
rtc	RTC						
aop	Autonomous Orbit Parameters						



21.11.21 UBX-CFG-RXM (0x06 0x11)

21.11.21.1 Poll RXM configuration

Message	CFG-RXM	CFG-RXM							
Description	Poll RXM co	Poll RXM configuration							
Firmware	Supported o	upported on:							
	• u-blox M8	u-blox M8 from firmware version 2.00 up to version 2.30							
Туре	Poll Request	Poll Request							
Comment	Upon sendir	ig of th	is mes	sage, the receiver returns CFG-RXM as c	defined be	low			
	Header	leader Class ID Length (Bytes) Payload Checksum							
Message Structure	0xB5 0x62	DxB5 0x62 0x06 0x11 0 see below CK_A CK_B							
No payload	÷	•	•	•	•	•			

21.11.21.2 RXM configuration

Message		CFO	FG-RXM								
Description		RX	XM configuration								
Firmware		Sup	Supported on:								
		•ι	u-blox M8 from firmware version 2.00 up to version 2.30								
Туре		Inp	nput/Output								
Comment		For	a detaile	d desci	ription	see sec	tion Pow	er Management.			
		No	te that Po	wer Sa	ive Mo	de canr	not be se	lected when the receive	r is configu	ured to process	
L		GL	LONASS signals (using CFG-GNSS).								
		Hea	der Class ID Length (Bytes) Payload Che						Checksum		
Message Struc	ture	0xB5 0x62 0x06 0x11 2 see below CK_A						CK_A CK_B			
Payload Conte	nts:	-									
Byte Offset	Numb	ber	Scaling	Name			Unit	Description			
	Forma	ət									
0	U1		-	rese	erved	1	-	Reserved			
1	U1		-	lpMc	ode		-	Low Power Mode			
								0: Continous Mode	0: Continous Mode		
								1: Power Save Mode			
								4: Continuous Mode			
								Note that for receivers	-		
								larger or equal to 14, both Low Power N			
					settings 0 and 4 confi				figure the receiver to		
								Continuous Mode.			



21.11.22 UBX-CFG-SBAS (0x06 0x16)

21.11.22.1 Poll contents of SBAS Configuration

Message	CFG-SBAS								
Description	Poll conten	ts of S	BAS C	onfiguration					
Firmware	Supported of	upported on:							
	• u-blox M	u-blox M8 from firmware version 2.00 up to version 2.30							
Туре	Poll Request	Poll Request							
Comment	-								
	Header	Class	ID	Length (Bytes)	Payload	Checksum			
Message Structure	0xB5 0x62	DxB5 0x62 0x06 0x16 0 see below CK_A CK_B							
No payload	1	•		•		1			


21.11.22.2 SBAS Configuration

Message		CF	FG-SBAS								
Description		SB	SBAS Configuration								
Firmware Supported on:											
	• u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Inp	Input/Output								
Comment			-		-			er subsystem (i.e. W for a detailed descri			
			ect receiv	-		5	1			5	
	Class	ID	Length	(Bytes)		Payload	Checksum				
Message Struc	ture	0x6	35 0x62	0x06	0x16	8			see below	CK_A CK_B	
Payload Conte	nts:			1		1					
Byte Offset	Num	ber	Scaling	Name			Unit	Description			
	Form	at									
0	X1		-	mode	2		-	SBAS Mode (see	graphic below)		
1	X1		-	usag	ge		-	SBAS Usage (see graphic below)			
2	U1		-	maxSBAS			-	Maximum Number of SBAS prioritized tracking channels (valid range: 0 - 3) to use (obsolete and superseeded by UBX-CFG-GNSS in protoco versions 14+).			
3	X1		-	scar	scanmode2		-	Continuation of scanmode bitmask below (see graphic below)			
4	X4 - scanmodel		1	-	 Which SBAS PRN numbers to search for (Bitmask) If all Bits are set to zero, auto-scan (i.e. all valid PRNs) are searched. Every bit corresponds to a PRN number (see graphic below) 						



Bitfield mode

This Graphic explains the bits of mode




■ signed value ■ unsigned value ■ reserved

Name	Description
enabled	SBAS Enabled (1) / Disabled (0)
test	SBAS Testbed: Use data anyhow (1) / Ignore data when in Test Mode (SBAS Msg 0)

Bitfield usage

This Graphic explains the bits of usage




■ signed value ■ unsigned value ■ reserved

Name	Description
range	Use SBAS GEOs as a ranging source (for navigation)
diffCorr	Use SBAS Differential Corrections
integrity	Use SBAS Integrity Information

Bitfield scanmode2

This Graphic explains the bits of scanmode2



Bitfield scanmode1

This Graphic explains the bits of scanmodel

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PRN151	PRN150	PRN149	PRN148	PRN147	PRN146	PRN145	PRN144	PRN143	PRN142	PRN141	PRN140	PRN139	PRN138	PRN137	PRN136	PRN135	PRN134	PRN133	PRN132	PRN131	PRN130	PRN129	PRN128	PRN127	PRN126	PRN125	PRN124	PRN123	PRN122	PRN121	PRN120
<u> </u>	igne Insig eser	ned		e																											



21.11.23 UBX-CFG-SMGR (0x06 0x62)

21.11.23.1 Poll SMGR settings

Message	CFG-SMGR	CFG-SMGR								
Description	Poll SMGR	oll SMGR settings								
Firmware	• u-blox M8	 Supported on: u-blox M8 from firmware version 2.20 up to version 2.30 (only available with FTS product variant) 								
Туре	Poll Request	:								
Comment	-									
	Header	Class	ID	Length (Bytes)		Payload	Checksum			
Message Structure	0xB5 0x62	0x06	0x62	0		see below	CK_A CK_B			
No payload	•	•	•	·						

21.11.23.2 Synchronization manager configuration

Message		CFG-SMGR														
Description		Synchronization manager configuration														
Firmware		 Supported on: u-blox M8 from firmware version 2.20 up to version 2.30 (only available with FTS product variant) 														
Туре		Set/	'Get													
Comment		-														
		Heac	der	Class	ID	Length ((Bytes)		Payload	Checksum						
Message Struc	ture	0xB	5 0x62	0x06	0x62	20			see below	CK_A CK_B						
Payload Conte	nts:															
Byte Offset	Numb Forma		Scaling	Name			Unit	Description								
0	U1		-	version			-	Message version (0 for	r this versio	on)						
1	U1	J1 -		minGNSSFix			-		Minimum number of GNSS fixes before we commit to use it as a source							
2	U2		-	maxFreqChange Rate			ppb/s	Maximum frequency change rate during disciplining. Must not exceed 30ppb/s								
4 U2 -				maxI ate	Phase(CorrR	ns/s	Maximum phase correction rate in coherent time pulse mode. For maximum phase correction rate in correct time pulse mode see maxSlewRate. Note that in coherent time pulse mode phase correction is achieved by intentional frequence offset. Allowing for a high phase correction ra can result in large intentional frequency offse Must not exceed 100ns/s								
6	U1[2]	-	rese	erved	1	-	Reserved								
8	freq	Tole:	rance	ppb	Limit of possible deviation from nominal before TIM-TOS indicates that frequency is out of tolerance											



CFG-SMGR continued

Byte Offset	Number Format	Scaling	Name	Unit	Description
10	U2	-	timeTolerance	ns	Limit of possible deviation from nominal before TIM-TOS indicates that time pulse is out of tolerance
12	X2	-	messageCfg	-	Sync manager message configuration (see graphic below)
14	U2	-	maxSlewRate	us/s	Maximum slew rate, the maximum time correction that shall be applied between locked pulses in corrective time pulse mode. To have no limit on the slew rate, set the flag disableMaxSlewRate to 1 For maximum phase correction rate in coherent time pulse mode see maxPhaseCorrRate.
16	X4	-	flags	-	Flags (see graphic below)

Bitfield messageCfg

This Graphic explains the bits of messageCfg



■ signed value ■ unsigned value ■ reserved

Name	Description
measInternal	1 = report the estimated offset of the internal oscillator based on the oscillator model
measGNSS	1 = report the internal oscillator's offset relative to GNSS
measEXTINT0	1 = report the internal oscillator's offset relative to the source on EXTINTO
measEXTINT1	1 = report the internal oscillator's offset relative to the source on EXTINT1

Bitfield flags

This Graphic explains the bits of flags

				16	15	14	13	12	11	10	7	6	5	4	3	2	1	0
■ signed value ■ unsigned value ■ reserved				disableOffset	TPCoherent		issueTimeWarning	issueFreqWarning	disableMaxSlewRate	useAnyFix	enableHostMeasExt	enableHostMeasInt	enableEXTINT1	enableEXTINTO	enableGNSS	preferenceMode	disableExternal	disableInternal
— Name	Description	 	 	 														



Bitfield flags Description continued

Name	Description
disableIntern	1 = disable disciplining of the internal oscillator
al	
disableExtern	1 = disable disciplining of the external oscillator
al	
preferenceMod	Reference selection preference
е	0 - best frequency accuracy
	1 - best phase accuracy
enableGNSS	1 = enable use of GNSS as synchronization source
enableEXTINT0	1 = enable use of EXTINTO as synchronization source
enableEXTINT1	1 = enable use of EXTINT1 as synchronization source
enableHostMea	1 = enable use of host measurements on the internal oscillator as synchronization source
sInt	Measurements made by the host must be sent to the receiver using a TIM-SMEAS-DATA0 message.
enableHostMea	1 = enable use of host measurements on the external oscillator as synchronization source
sExt	Measurements made by the host must be sent to the receiver using a TIM-SMEAS-DATA0 message.
useAnyFix	0 - use over-determined navigation solutions only
	1 - use any fix
disableMaxSle	0 - use the value in the field maxSlewRate for maximum time correction in corrective time pulse mode
wRate	1 - don't use the value in the field maxSlewRate
issueFreqWarn	1 = issue a warning (via TIM-TOS flag) when frequency uncertainty exceeds freqTolerance
ing	
issueTimeWarn	1 = issue a warning (via TIM-TOS flag) when time uncertainty exceeds timeTolerance
ing	
TPCoherent	Control time pulse coherency
	0 - Coherent pulses. Time phase offsets will be corrected gradually by varying the GNSS oscillator rate within
	frequency tolerance limits. There will always be the correct number of GNSS oscillator cycles between time pulses.
	Given tight limits this may take a long time
	1 - Non-coherent pulses. In this mode the receiver will correct time phase offsets as quickly as allowed by the
	specified maximum slew rate, in which case there may not be the expected number of GNSS oscillator cycles
	between time pulses.
	2 - Post-initialization coherent pulses. The receiver will run in non-coherent mode as described above until the
	pulse timing has been corrected and PLL is active on the internal oscillator, but will then switch to coherent pulse
	mode.
disable0ffset	1 = disable automatic storage of oscillator offset



21.11.24 UBX-CFG-TMODE2 (0x06 0x3D)

21.11.24.1 Poll Time Mode Settings

Message	CFG-TMOD	E2											
Description	Poll Time N	lode S	etting	s									
Firmware	• u-blox M8	 Supported on: u-blox M8 from firmware version 2.00 up to version 2.30 (only available with Timing or FTS product variants) 											
Туре		Poll Request											
Comment	Sending this	(empty	y / no-p	le only for timing receivers bayload) message to the receiver results DDE2 with a payload as defined below	in the rece	eiver returning a							
	Header	Class	ID	Length (Bytes)	Payload	Checksum							
Message Structure	0xB5 0x62 0x06 0x3D 0 see below CK_A CK_B												
No payload													

21.11.24.2 Time Mode Settings 2

Message		CFC	G-TMOD	E2								
Description		Tin	ne Mode	Settir	ngs 2							
Firmware		• ر	oported c u-blox M8 or FTS pr	3 from			on 2.00 ι	p to version 2.30 (only	/ availabl	e with Timing		
Туре		Get	t/Set									
Comment		This message is available only for timing receiversSee the Time Mode Description for details. This message replaces the deprecatedUBX-CFG-TMODE message.								cated		
								Payload	Checksum			
Message Structu	lessage Structure 0xB5 0x62 0x06 0x3D 28 see							see below	CK_A CK_B			
Payload Contents	5:					1				•		
Byte Offset	Numb Forma		Scaling	Name			Unit	Description				
0	U1		-	timeMode			-	Time Transfer Mode: 0 Disabled 1 Survey In 2 Fixed Mode (true po required) 3-255 Reserved	sition info	rmation		
1	U1		-	rese	erved	1	-	Reserved				
2	X2		-	flag	js		-	Time mode flags (see	<u> </u>			
4	14 -			ecef	ecefXOrLat			WGS84 ECEF X coordinate or latitude, depending on flags above				
8 14 -			ecef	ecefYOrLon			WGS84 ECEF Y coordinate or longitude, depending on flags above					




CFG-TMODE2 continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
12	14	-	ecefZOrAlt	cm	WGS84 ECEF Z coordinate or altitude,
					depending on flags above
16	U4	-	fixedPosAcc	mm	Fixed position 3D accuracy
20	U4	-	svinMinDur	S	Survey-in minimum duration
24	U4	-	svinAccLimit	mm	Survey-in position accuracy limit

Bitfield flags

This Graphic explains the bits of flags



signed value unsigned value

片		
	reserved	

Name	Description
lla	Position is given in LAT/LON/ALT (default is ECEF)
altInv	Altitude is not valid, in case lla was set

21.11.25 UBX-CFG-TP5 (0x06 0x31)

21.11.25.1 Poll Time Pulse Parameters

Message	CFG-TP5													
Description	Poll Time P	Poll Time Pulse Parameters												
Firmware	Supported o	Supported on:												
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 												
Туре	Poll Request	Poll Request												
Comment	-			bayload) message to the receiver results 5 with a payload as defined below for ti		-								
	Header	Class	ID	Length (Bytes)	Payload	Checksum								
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x31 0 see below CK_A CK_B												
No payload														



21.11.25.2 Poll Time Pulse Parameters

Message		CFC	G-TP5										
Description		Pol	l Time P	ulse Pa	aramet	ters							
Firmware			Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Pol	Poll Request										
Comment		Sending this message to the receiver results in the receiver returning a message of type CFG-TP5 with a payload as defined below for the specified time pulse.											
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	OxB	35 0x62	0x06	0x31	1			see below	CK_A CK_B			
Payload Conte	nts:								L				
Byte Offset Number Scaling Name Format							Unit	Description					
0) U1 -				tpIdx			Time pulse select TIMEPULSE2)	Time pulse selection (0 = TIMEPULSE, 1 = TIMEPULSE2)				

21.11.25.3 Time Pulse Parameters

Message		CFO	G-TP5											
Description		Tin	ne Pulse	Param	eters									
Firmware		Sup	oported o	n:										
		•ι	u-blox M8	3 firmw	are ve	rsion 2.0	00							
Туре		Inp	ut/Outpu	ıt										
Comment		Thi	s messag	e is use	d to g	et/set ti	me pulse	parameters. For more i	nformatior	n see section				
		Tim	ne pulse.											
		Hea	der	Class	ID	Length ((Bytes)		Payload	Checksum				
Message Struc	ture	0xE	35 0x62	0x06	0x31	32			see below	СК_АСК_В				
Payload Conte	nts:					1								
Byte Offset	Numb	ber	Scaling	Name			Unit	Description						
	Forma	at												
0	U1		-	tpId	tpIdx			Time pulse selection (0) = TIMEPU	JLSE, 1 =				
								TIMEPULSE2)						
1	U1		-	vers	version			Version, 0 for this message						
2	U1[2]	-	rese	erved	1	-	Reserved						
4	12		-	antC	Cable	Delay	ns	Antenna cable delay						
6	12		-	rfGr	coupD	elay	ns	RF group delay						
8	U4		-	freq	Perio	od	Hz_or_	Frequency or period time, depending on settin						
							us	of bit 'isFreq'						
12	U4		-	freq	Perio	odLoc	Hz_or_	Frequency or period ti						
				k			us	time, only used if 'lock						
16	U4		-	puls	seLen	Ratio	us_or_2	Pulse length or duty cy	cle, deper	nding on				
							^-32	'isLength'						
20	20 U4 -			_		Ratio	us_or_2							
							^-32	time, only used if 'lockedOtherSet' is set						
24	4 -			userConfigDel			ns	User configurable time	e pulse del	ау				



CFG-TP5 continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
28	X4	-	flags	-	Configuration flags (see graphic below)

Bitfield flags

This Graphic explains the bits of flags

											7	6	5	4	3	2	1	0
											gridUtcGps	polarity	alignToTow	isLength	isFreq	lockedOtherSet	lockGpsFreq	active

■ signed value ■ unsigned value ■ reserved

Name	Description
active	if set enable time pulse; if pin assigned to another function, other function takes precedence
lockGpsFreq	if set synchronize time pulse to GPS as soon as GPS time is valid, otherwise use local clock
lockedOtherSe	if set use 'freqPeriodLock' and 'pulseLenRatioLock' as soon as GPS time is valid and 'freqPeriod' and
t	'pulseLenRatio' if GPS time is invalid,
	if flag is cleared 'freqPeriod' and 'pulseLenRatio' used regardless of GPS time
isFreq	if set 'freqPeriodLock' and 'freqPeriod' interpreted as frequency, otherwise interpreted as period
isLength	if set 'pulseLenRatioLock' and 'pulseLenRatio' interpreted as pulse length, otherwise interpreted as duty cycle
alignToTow	align pulse to top of second (period time must be integer fraction of 1s)
polarity	pulse polarity:
	0 = falling edge at top of second
	1 = rising edge at top of second
gridUtcGps	timegrid to use:
	0 = UTC
	1 = GPS

21.11.25.4 Time Pulse Parameters

Message		CFC	G-TP5										
Description		Tin	ne Pulse	Param	eters								
Firmware		Sup	Supported on:										
		•ι	 u-blox M8 from firmware version 2.20 up to version 2.30 										
Туре		Inp	ut/Output	t									
Comment		This message is used to get/set time pulse parameters. For more information see section Time pulse.											
		Hea	der	Class	ID	Length (Bytes) Payload Checksul				Checksum			
Message Structu	re	0xE	35 0x62	0x06	0x31	32			see below	CK_A CK_B			
Payload Content	s:									•			
Byte Offset	Numb	ber	Scaling	Name			Unit	Description					
	Forma	Format											
0	U1		-	tpIc	lx		-	Time pulse selection (0	= TIMEPL	JLSE, 1 =			
								TIMEPULSE2)					



CFG-TP5 continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
1	U1	-	version	-	Version, 1 for this message
2	U1[2]	-	reserved1	-	Reserved
4	12	-	antCableDelay	ns	Antenna cable delay
6	12	-	rfGroupDelay	ns	RF group delay
8	U4	-	freqPeriod	Hz_or_	Frequency or period time, depending on setting
				us	of bit 'isFreq'
12	U4	-	freqPeriodLoc	Hz_or_	Frequency or period time when locked to GNSS
			k	us	time, only used if 'lockedOtherSet' is set
16	U4	-	pulseLenRatio	us_or_2	Pulse length or duty cycle, depending on
				^-32	'isLength'
20	U4	-	pulseLenRatio	us_or_2	Pulse length or duty cycle when locked to GNSS
			Lock	^-32	time, only used if 'lockedOtherSet' is set
24	14	-	userConfigDel	ns	User configurable time pulse delay
			ay		
28	X4	-	flags	-	Configuration flags (see graphic below)

Bitfield flags

This Graphic explains the bits of flags

	13 12 11 10 9 8 7	6 5 4 3 2 1 0
	syncMode gridUtcGnss	polarity alignToTow isLength isFreq lockedOtherSet lockGnssFreq active

■ signed value ■ unsigned value ■ reserved

Name	Description
active	If set enable time pulse; if pin assigned to another function, other function takes precedence.
	Must be set for FTS variant.
lockGnssFreq	If set synchronize time pulse to GNSS as soon as GNSS time is valid. If not set, or before GNSS time is valid use
	local clock.
	This flag is ignored by the FTS product variant; in this case the receiver always locks to the best available
	time/frequency reference (which is not necessarily GNSS).
lockedOtherSe	If set the receiver switches between the timepulse settings given by 'freqPeriodLocked' & 'pulseLenLocked' and
t	those given by 'freqPeriod' & 'pulseLen'. The 'Locked' settings are used where the receiver has an accurate sense
	of time. For non-FTS products, this occurs when GNSS solution with a reliable time is available, but for FTS
	products the setting syncMode field governs behavior. In all cases, the receiver only uses 'freqPeriod' & 'pulseLen'
	when the flag is unset.
isFreq	If set 'freqPeriodLock' and 'freqPeriod' are interpreted as frequency, otherwise interpreted as period.
isLength	If set 'pulseLenRatioLock' and 'pulseLenRatio' interpreted as pulse length, otherwise interpreted as duty cycle.
alignToTow	Align pulse to top of second (period time must be integer fraction of 1s).
	Also set 'lockGnssFreq' to use this feature.
	This flag is ignored by the FTS product variant; it is assumed to be always set (as is lockGnssFreq). Set maxSlewRate
	and maxPhaseCorrRate fields of CFG-SMGR to 0 to disable alignment.



Bitfield flags Description continued

Name	Description
polarity	Pulse polarity:
	0: falling edge at top of second
	1: rising edge at top of second
gridUtcGnss	Timegrid to use:
	0: UTC
	1: GPS
	2: GLONASS
	3: BeiDou
	This flag is only relevant if 'lockGnssFreq' and 'alignToTow' are set.
	Note that configured GNSS time is estimated by the receiver if locked to any GNSS system. If the receiver has a
	valid GNSS fix it will attempt to steer the TP to the specified time grid even if the specified time is not based on
	information from the constellation's satellites. To ensure timing based purely on a given GNSS, restrict the
	supported constellations in CFG-GNSS.
syncMode	Sync Manager lock mode to use:
	0: switch to 'freqPeriodLock' and 'pulseLenRatioLock' as soon as Sync Manager has an accurate time, never
	switch back to 'freqPeriod' and 'pulseLenRatio'
	1: switch to 'freqPeriodLock' and 'pulseLenRatioLock' as soon as Sync Manager has an accurate time, and switch
	back to 'freqPeriod' and 'pulseLenRatio' as soon as time gets inaccurate
	This field is only relevant for the FTS product variant.
	This field is only relevant if the flag 'lockedOtherSet' is set.

21.11.26 UBX-CFG-TXSLOT (0x06 0x53)

21.11.26.1 TX buffer time slots configuration

Message		CFC	CFG-TXSLOT								
Description	n TX buffer time slots configuration										
Firmware		Sup	ported o	n:							
		•ι	u-blox M8	from ⁻	firmwa	ire versi	on 2.20	up to version 2.30	(only	/ available	e with FTS
		F	oroduct v	variant	t)						
Туре		Cor	mmand								
Comment		This	s message	e config	gures h	now tra	nsmit tin	ne slots are defined	for t	he receiver	r interfaces.
		The	These time slots are relative to the chosen time pulse. A receiver that supports this message								
		offers 3 time slots: nr. 0, 1 and 2. These time pulses follow each other and their associated									
		priorities decrease in this order. The end of each can be specified in this message, the									
		beginning is when the circularly previous slot ends (i.e. slot 0 starts when slot 2 finishes).									
		Hea	der	Class	ID	Length (Bytes)				Payload	Checksum
Message Structu	ıre	0xB	35 0x62	0x06	0x53	16				see below	CK_A CK_B
Payload Conten	ts:										
Byte Offset	Numl	ber	Scaling	Name			Unit	Description			
Format											
0	U1		-	version		-	Message version	(0 for this version)			
1	X1		-	enak	ole		-	Bitfield of ports for which the slots are enabled.			ots are enabled.
								(see graphic below)			




CFG-TXSLOT continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
2	U1	-	refTp	-	Reference timepulse source
					0 - Timepulse
					1 - Timepulse 2
3	U1	-	reserved1	-	Reserved
Start of repeated	block (3 tin	nes)			
4 + 4*N	U4	-	end	-	End of timeslot in milliseconds after time pulse
End of repeated l	block		•		

Bitfield enable

This Graphic explains the bits of enable



signed value unsigned value

reserved	
----------	--

Name	Description
DDC	DDC/I2C
UART1	UART 1
UART2	UART 2
USB	USB
SPI	SPI

21.11.27 UBX-CFG-USB (0x06 0x1B)

21.11.27.1 Poll a USB configuration

Message	CFG-USB	CFG-USB										
Description	Poll a USB	Poll a USB configuration										
Firmware	Supported of	Supported on:										
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 										
Туре	Poll Request	Poll Request										
Comment	-											
	Header	Header Class ID Length (Bytes) Payload Checksum										
Message Structure	0xB5 0x62	0xB5 0x62 0x06 0x1B 0 see below CK_A CK_B										
No payload	1				l	•						




21.11.27.2 USB Configuration


Message		CFG-USB									
Description USB Co			SB Configuration								
Firmware		Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30									
Туре		Input/Output									
Comment		-									
	1	Header	Class	ID	Length ((Bytes)		Payload	Checksum		
Message Struc	ture	0xB5 0x62	0x06	0x1B	108			see below	CK_A CK_B		
Payload Conte	nts:								•		
Byte Offset Number Scaling Format			Name			Unit	Description	Description			
0	U2	-	veno	vendorID		-	Vendor ID. This field shall only be set to registered Vendor IDs. Changing this field requires special Host drivers.				
2	U2	-	proc	productID		-	Product ID. Changing this field requires specia Host drivers.				
4	U1[2]	-	rese	erved	1	-	Reserved				
6	U1[2]	-	rese	erved	2	-	Reserved				
8	U2	-	powe ion	powerConsumpt ion		mA	Power consumed by the device				
10	X2	-	flag	js		-	various configuration	ious configuration flags (see graphic below			
12	CH[32	2] -	vendorString		-	String containing the vendor name. 32 ASCII bytes including 0-termination.					
44	CH[32	2] -	proc	productString		-	String containing the product name. 32 ASCII bytes including 0-termination.				
76	CH[32	2] -	seri	serialNumber			String containing the serial number. 32 ASC bytes including 0-termination. Changing the String fields requires special H drivers.				

Bitfield flags

This Graphic explains the bits of flags



Name	Description
reEnum	force re-enumeration
powerMode	self-powered (1), bus-powered (0)





21.12 UBX-INF (0x04)

Information Messages: i.e. Printf-Style Messages, with IDs such as Error, Warning, Notice.

The INF Class is basically an output class that allows the firmware and application code to output strings with a printf-style call. All INF messages have an associated type to indicate the kind of message.

21.12.1 UBX-INF-DEBUG (0x04 0x04)

21.12.1.1 ASCII output with debug contents

Message		INF	NF-DEBUG									
Description		AS	Cll outpu	ıt with	n debu	g cont	ents					
Firmware			Supported on:									
	•ι	u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Ou	tput									
Comment		Thi	s message	e has a	a variable length payload, representing an ASCII string.							
		Hea	der	Class	ID	Length (Bytes)			Payload	Checksum		
Message Struct	ure	OxE	35 0x62	0x04	0x04	0 + 1*N			see below	CK_A CK_B		
Payload Conten	its:								•			
Byte Offset	Num	ber	Scaling	Name			Unit	Description				
	Form	at										
Start of repeate	d block	(N tin	nes)									
N*1	CH	- str					-	ASCII Character				
End of repeated	d block											

21.12.2 UBX-INF-ERROR (0x04 0x00)

21.12.2.1 ASCII output with error contents

Message		INF	-ERROR								
Description		AS	Cll outpu	ıt with	error	conter	nts				
Firmware		Sup	oported o	n:							
		•ι	u-blox M8	from	firmwa	re versi	on 2.00 i	up to version 2.30			
Туре		Ou	tput								
Comment		Thi	nis message has a variable length payload, representing an ASCII string.								
Header				Class	ID	Length (Bytes) P			Payload	Checksum	
Message Structu	ire	0xE	35 0x62	0x04	0x00	0 + 1*	N		see below	CK_A CK_B	
Payload Content	ts:					•			•		
Byte Offset	Numl Form		Scaling	Name			Unit	Description			
Start of repeated	d block	(N tin	nes)	•				•			
N*1	CH		-	str			-	ASCII Character			
End of repeated	block										



21.12.3 UBX-INF-NOTICE (0x04 0x02)

21.12.3.1 ASCII output with informational contents

Message		INF	-NOTICE							
Description		AS	Cll outpu	ıt with	infor	mation	al conte	ents		
Firmware		Sup	oported o	n:						
		• L	u-blox M8	from	firmwa	re versi	on 2.00	up to version 2.30		
Туре		Ou	tput							
Comment		Thi	s message	e has a	variab	le lengt	h payloa	d, representing an ASC	ll string.	
Header Class					ID	Length (Checksum			
Message Structu	re	OxE	35 0x62	0x04	0x02	0 + 1*	N		see below	CK_A CK_B
Payload Content	s:									
Byte Offset	Num! Forma		Scaling	Name			Unit	Description		
Start of repeated	I block	(N tin	nes)							
N*1	СН		-	str			-	ASCII Character		
End of repeated	block		•					•		

21.12.4 UBX-INF-TEST (0x04 0x03)

21.12.4.1 ASCII output with test contents

Message		INF	-TEST							
Description		AS	CII outpu	ıt with	test o	onten	ts			
Firmware			ported o		_					
		•ι	i-plox M8	from	firmwa	re versi	on 2.00	up to version 2.30		
Туре		Out	tput							
Comment		This	s message	e has a	variab	le lengt	h payloa	d, representing an ASC	ll string.	
Header				Class	ID	Length (Bytes) Payload Chec				Checksum
Message Structur	re	OxB	5 0x62	0x04	0x03	0 + 1*	Ν		see below	CK_A CK_B
Payload Contents	5.								•	•
Byte Offset	Numb	ber	Scaling	Name			Unit	Description		
	Forma	ət								
Start of repeated	block (N tin	nes)							
N*1	CH		-	str			-	ASCII Character		
End of repeated l	block			•			•			



21.12.5 UBX-INF-WARNING (0x04 0x01)

21.12.5.1 ASCII output with warning contents

Message		INF	NF-WARNING									
Description		AS	Cll outpu	ıt with	warn	ing co	ntents					
Firmware		Sup	oported o	n:								
		• L	u-blox M8 from firmware version 2.00 up to version 2.30									
Туре		Ou	tput									
Comment		Thi	is message has a variable length payload, representing an ASCII string.									
		Header Class ID Length (Bytes) Payload Checksum								Checksum		
Message Structu	re	OxE	35 0x62	0x04	0x01	0 + 1*	N		see below	СК_АСК_В		
Payload Content	s:											
Byte Offset	Numb	ber	Scaling	Name			Unit	Description				
	Forma	ət										
Start of repeated	l block	(N tin	nes)									
N*1 CH - str - ASCII Character												
End of repeated	block											



21.13 UBX-LOG (0x21)

Logging Messages: i.e. Log creation, deletion, info and retrieval.

The logging feature allows position fixes and arbitrary byte strings to be logged in flash memory attached to the receiver. For a full description of this feature see Logging.


21.13.1 UBX-LOG-CREATE (0x21 0x07)

21.13.1.1 Create Log File

Message		LOG-	.OG-CREATE										
Description		Crea	te Log	File									
Firmware		Supp	orted o	on:									
		• u-k	blox M8	from firmware version 2.00 up to version 2.30									
Туре		Com	mand										
Comment		This message is used to create an initial logging file and activate the logging subsystem.											
		UBX-ACK-ACK or UBX-ACK-NAK are returned to indicate success or failure.											
		This r	message	e does	does not handle activation of recording or filtering of log entries (see								
		UBX-	-CFG-L	OGFII	TER).								
		Heade	er	Class	ID	Length ((Bytes)		Payload	Checksum			
Message Struc	ture	0xB5	0x62	0x21	0x07	8			see below	СК_АСК_В			
Payload Conte	nts:												
Byte Offset	Num	ber So	caling	Name	Name			Description					
	Form	at											
0	U1	-		version		-	The version of this me	ssage. Set	to 0				
1	X1	-		logCfg		-	Config flags (see graphic below)						
2	U1	-		rese	erved	1	-	Reserved					
3	U1	-		logS	lize		-	Indicates the size of the log:					
								0 (maximum safe size)		55 5			
								not be interupted and					
								avaiable for all other u	ises of the	filestore			
								1 (minimum size):					
								2 (user defined): See 'userDefinedSize' below					
4	04	-		user	Defi	nedSi	bytes	Sets the maximum am					
				ze				filestore that can be us	-				
								This field is only applic	able it log	Size is set to			
								user defined.					

Bitfield logCfg

This Graphic explains the bits of logCfg



Name	Description
circular	Log is circular (new entries overwrite old ones in a full log) if this bit set



21.13.2 UBX-LOG-ERASE (0x21 0x03)

21.13.2.1 Erase Logged Data

Message	LOG-ERASE											
Description	Erase Logg	Erase Logged Data										
Firmware	Supported o	Supported on:										
	• u-blox M8	u-blox M8 from firmware version 2.00 up to version 2.30										
Туре	Command	Command										
Comment	This message	e deact	ivates ⁻	the logging system and erases all logged	d data.							
	UBX-ACK-A	CK or	UBX-A	CK-NAK are returned to indicate succes	ss or failure	2.						
	Header	Class	ID	Length (Bytes)	Payload	Checksum						
Message Structure	0xB5 0x62	0x21	0x03	0	see below	CK_A CK_B						
No payload		•		•	•							

21.13.3 UBX-LOG-FINDTIME (0x21 0x0E)

21.13.3.1 Find index of the first log entry <= given time

Message		LO	DG-FINDTIME											
Description		Fin	d index	of the	first lo	og enti	′y <= giv	en time						
Firmware		Sup	ported o	l on:										
		• U	I-blox M8	3 from	firmwa	ire versi	on 2.00	up to version 2.30						
Туре		Inp	ut											
Comment		This	s message	e can b	can be used to search a log for the index of the first entry less than or equal									
		to t	he given	time. 1	time. This index can then be used with the UBX-LOG-RETRIEVE message to									
provide time-based retrieval of log entries.														
Header Class ID Length (Bytes) Payload Checksur									Checksum					
Message Struc	ture	0xB	5 0x62	0x21	0x0E	12		see below CK_A CK_B						
Payload Conte	nts:	•		•	•					·				
Byte Offset	Numb	ber	Scaling	Name	Name			Description						
	Forma	at												
0	U1		-	vers	sion		-	Message version (=0 for this version)						
1	U1		-	type	2		-	Message type, 0 for re	or request					
2	U1[2]	-	rese	erved	1	-	Reserved						
4	U2		-	year	-		-	Year (1-65635) of UTC	C time					
6	U1		-	mont	h		-	Month (1-12) of UTC time						
7	U1		-	day			-	Day (1-31) of UTC time						
8 U1 -			hour	<u> </u>		-	Hour (0-23) of UTC time							
9	U1		-	minu	ıte		-	Minute (0-59) of UTC						
10	U1		-	seco	ond		-	Second (0-60) of UTC time						
11	U1		-	rese	erved	2	-	Reserved						



21.13.3.2 Response to FINDTIME request.

Message		LO	G-FINDTI	ME								
Description		Re	sponse to	5 FIND	TIME	reques	t.					
Firmware			pported o u-blox M8		firmwa	ire versi	on 2.00	up to version 2.30				
Туре		Ou	tput									
Comment		-	-									
		Hea	Header Class ID Length (Bytes) Payload Checksum									
Message Struct	ure	OxE	35 0x62	0x21	0x0E	8		see below CK_A CK_B				
Payload Conter	nts:					•						
Byte Offset	Numb		Scaling	Name			Unit	Description				
0	U1	<i>a</i> (-	vers	ion		-	Message version (=1 f	or this vers	sion)		
1	U1		-	type	2		-	Message type, 1 for response				
2	U1[2	2]	-	rese	rved	1	-	Reserved				
4 U4 - entr				yNumł	oer	-	Index of the most rece specified	ent entry w	/ith time <=			

21.13.4 UBX-LOG-INFO (0x21 0x08)

21.13.4.1 Poll for log information

Message	LOG-INFO											
Description	Poll for log	Poll for log information										
Firmware	Supported c	Supported on:										
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 										
Туре	Poll Request	Poll Request										
Comment	Upon sendir	ng of th	is mes	sage, the receiver returns UBX-LOG-INFC) as define	ed below.						
	Header	Class	ID	Length (Bytes)	Payload	Checksum						
Message Structure	0xB5 0x62	0x21	0x08	0	see below	CK_A CK_B						
No payload					•							

21.13.4.2 Log information


Message	LOG-INFO
Description	Log information
Firmware	Supported on:
	 u-blox M8 from firmware version 2.00 up to version 2.30
Туре	Output
Comment	This message is used to report information about the logging subsystem.
	Note:
	• The reported maximum log size will be smaller than that originally specified in
	LOG-CREATE due to logging and filestore implementation overheads.
	• Log entries are compressed in a variable length fashion, so it may be difficult to predict
	log space usage with any precision.
	• There may be times when the receiver does not have an accurate time (e.g. if the week number is not yet known), in which case some entries will not have a timestamp - this may result in the oldest/newest entry time values not taking account of these entries.



Size grow to	see below	CK_A CK_B			
Byte OffsetNumber FormatScaling ScalingNameUnitDescription0U1-version-The version of this mess1U1[3]-reserved1-Reserved4U4-filestoreCapa citybytesThe capacity of the file city8U1[8]-reserved2-Reserved16U4-currentMaxLog sizebytesThe maximum size the grow to20U4-currentLogSiz ebytesApproximate amount of occupied24U4-entryCount-Number of entries in th	ssage. Set				
FormatVersion-The version of this mest0U1-version-The version of this mest1U1[3]-reserved1-Reserved4U4-filestoreCapa citybytesThe capacity of the file city8U1[8]-reserved2-Reserved16U4-currentMaxLog SizebytesThe maximum size the grow to20U4-currentLogSiz ebytesApproximate amount of occupied24U4-entryCount-Number of entries in th	ssage. Set				
0U1-version-The version of this mest1U1[3]-reserved1-Reserved4U4-filestoreCapa citybytesThe capacity of the file city8U1[8]-reserved2-Reserved16U4-currentMaxLog SizebytesThe maximum size the grow to20U4-currentLogSiz ebytesApproximate amount of occupied24U4-entryCount-Number of entries in the	ssage. Set				
1U1[3]-reserved1-Reserved4U4-filestoreCapa citybytesThe capacity of the file city8U1[8]-reserved2-Reserved16U4-currentMaxLog SizebytesThe maximum size the grow to20U4-currentLogSiz ebytesApproximate amount of occupied24U4-entryCount-Number of entries in the	ssage. set	to 1			
4U4-filestoreCapa citybytesThe capacity of the file city8U1[8]-reserved2-Reserved16U4-currentMaxLog SizebytesThe maximum size the grow to20U4-currentLogSiz ebytesApproximate amount of occupied24U4-entryCount-Number of entries in the					
8U1[8]-reserved2-Reserved16U4-currentMaxLog SizebytesThe maximum size the grow to20U4-currentLogSiz ebytesApproximate amount of occupied24U4-entryCount-Number of entries in the					
16U4-currentMaxLog SizebytesThe maximum size the grow to20U4-currentLogSiz ebytesApproximate amount of occupied24U4-entryCount-Number of entries in the					
Sizegrow to20U4-currentLogSiz ebytesApproximate amount of occupied24U4-entryCount-Number of entries in the	Reserved				
20 U4 - currentLogSiz bytes Approximate amount of occupied 24 U4 - entryCount - Number of entries in the occupied	The maximum size the current log is allowe grow to				
24 U4 - entryCount - Number of entries in th					
when a group of entrie space for new ones.	this value				
28 U2 - oldestYear - Oldest entry UTC year there are no entries wi					
	Oldest month (1-12)				
31 U1 - oldestDay - Oldest day (1-31)					
32 U1 - oldestHour - Oldest hour (0-23)					
33 U1 - oldestMinute - Oldest minute (0-59)					
34 U1 - oldestSecond - Oldest second (0-60)					
35 U1 - reserved3 - Reserved					
36 U2 - newestYear - Newest year (1-65635) entries with known tim		f there are no			
38 U1 - newestMonth - Newest month (1-12)					
39 U1 - newestDay - Newest day (1-31)					
40 U1 - newestHour - Newest hour (0-23)					
41 U1 - newestMinute - Newest minute (0-59)					
42 U1 - newestSecond - Newest second (0-60)					
43 U1 - reserved4 - Reserved					
44 X1 - status - Log status flags (see gr	flags (see graphic below)				
45 U1[3] - reserved5 - Reserved	raphic belo	ow)			

Bitfield status

This Graphic explains the bits of status



UBX-13003221 - R08



Bitfield status Description continued

Name	Description
recording	Log entry recording is currently turned on
inactive	Logging system not active - no log present
circular	The current log is circular

21.13.5 UBX-LOG-RETRIEVEPOSEXTRA (0x21 0x0f)

21.13.5.1 Odometer log entry

Message		LO	G-RETRI	EVEPO	SEXTR	A					
Description		Od	lometer	log en	try						
Firmware		Sup	oported o	n:							
		 ι 	u-blox M8	3 from	firmwa	are vers	ion 2.00) up to version 2.30			
Туре		Ou	tput								
Comment		Thi	s messag	e is use	ed to re	eport ar	n odome	eter log entry			
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	OxE	35 0x62	0x21	0x0f	32			see below	СК_АСК_В	
Payload Conte	nts:								•	•	
Byte Offset	Numb	er	Scaling	Name			Unit	Description			
	Forma	at									
0	U4		-	entr	ryInde	ex	-	The index of this log			
4	U1		-	vers	sion		-	The version of this m	ersion of this message. Set to 0		
5	U1		-	rese	erved	1	-	Reserved			
6	U2		-	year	2		-	Year (1-65635) of UTC time. Will be zero if tim			
								not known			
8	U1		-	mont	h		-	Month (1-12) of UTC	: time		
9	U1		-	day			-	Day (1-31) of UTC tir	ne		
10	U1		-	hour	<u></u>		-	Hour (0-23) of UTC t	ime		
11	U1		-	minu	ıte		-	Minute (0-59) of UTC	C time		
12	U1		-	seco	ond		-	Second (0-60) of UT	C time		
13	U1[3]	-	rese	reserved2			Reserved			
16	U4		-	dist	ance		-	Odometer distance traveled			
20	U1[1	2]	-	rese	erved	3	-	Reserved			



21.13.6 UBX-LOG-RETRIEVEPOS (0x21 0x0b)

21.13.6.1 Position fix log entry

Message		LOG-RETRI	RIEVEPOS								
Description		Position fix	log ei	ntry							
Firmware		Supported c	n:								
		u-blox M8	3 from	firmwa	are vers	ion 2.00	up to version 2.30				
Туре		Output									
Comment		This messag	e is use	ed to re	eport a	position	fix log entry				
		Header	Class	ID	Length	(Bytes)		Payload	Checksum		
Message Struc	ture	0xB5 0x62	0x21	0x0b	40			see below	CK_A CK_B		
Payload Conte	nts:								•		
Byte Offset	Num	ber Scaling	Name			Unit	Description				
	Form	at									
0	U4	-	entr	ryInd	ex	-	The index of this log e	ntry			
4	14	1e-7	lon			deg	Longitude				
8	14	1e-7	lat			deg	Latitude				
12	14	-	hMSI	J		mm	Height above mean sea level				
16	U4	-	hAco	2		mm	Horizontal accuracy estimate				
20	U4	-	gSpe	eed		mm/s	Ground speed (2-D)				
24	U4	-	head	ling		deg	Heading				
28	U1	-	vers	sion		-	The version of this me	ssage. Set	to 0		
29	U1	-	fixT	Гуре		-	Fix type:				
							2: 2D-Fix				
							3: 3D-Fix				
30	U2	-	year			-	Year (1-65635) of UTC				
32	U1	-	mont	:h		-	Month (1-12) of UTC				
33	U1	-	day			-	Day (1-31) of UTC tim				
34	U1	-	hour			-	Hour (0-23) of UTC tir				
35	U1	-	minu			-	Minute (0-59) of UTC time				
36	U1	-	seco			-	Second (0-60) of UTC time				
37	U1	-	-	erved	1	-	Reserved				
38	U1	-	numS			-	Number of satellites u	sed in the	position fix		
39	U1	-	rese	erved	2	-	Reserved				



21.13.7 UBX-LOG-RETRIEVESTRING (0x21 0x0d)

21.13.7.1 Byte string log entry

Message		LO	G-RETRI	EVEST	RING					
Description		By	te string	log er	ntry					
Firmware		Sup	ported c	on:						
		 ι 	u-blox M8	8 from	firmwa	ire versi	on 2.00	up to version 2.30		
Туре		Ou	tput							
Comment		Thi	s messag	e is use	ed to re	eport a	byte stri	ng log entry		
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum
Message Struct	essage Structure 0xB5 0x62 0x21 0x0d 16 + 1*byteCount see below CK						CK_A CK_B			
Payload Conten	nts:				•				•	·
Byte Offset	Numb	er	Scaling	Name			Unit	Description		
	Forma	t								
0	U4		-	entr	ryInd	ex	-	The index of this log e	entry	
4	U1		-	vers	sion		-	The version of this me	ssage. Set	to 0
5	U1		-	rese	erved	1	-	Reserved		
6	U2		-	year			-	Year (1-65635) of UT	C time. Wi	l be zero if time
								not known		
8	U1		-	mont	h		-	Month (1-12) of UTC	time	
9	U1		-	day			-	Day (1-31) of UTC tim	е	
10	U1		-	hour	2		-	Hour (0-23) of UTC tir	ne	
11	U1		-	minu	ıte		-	Minute (0-59) of UTC	time	
12	U1		-	seco	ond		-	Second (0-60) of UTC	time	
13	U1		-	rese	erved	2	-	Reserved		
14	U2		-	byte	Coun	t	-	Size of string in bytes		
Start of repeate	ed block (i	byte	Count time	s)						
16 + 1*N	U1		-	byte	es		-	The bytes of the string	9	
End of repeated	d block									

21.13.8 UBX-LOG-RETRIEVE (0x21 0x09)

21.13.8.1 Request log data

Message	LOG-RETRIEVE
Description	Request log data
Firmware	Supported on:
	 u-blox M8 from firmware version 2.00 up to version 2.30
Туре	Command
Comment	This message is used to request logged data (log recording must first be disabled, see
	UBX-CFG-LOGFILTER).
	Log entries are returned in chronological order, using the messages
	UBX-LOG-RETRIEVEPOS and UBX-LOG-RETRIEVESTRING. The maximum number of
	entries that can be returned in response to a single UBX-LOG-RETRIEVE message is 256. If
	more entries than this are required the mesage will need to be sent multiple times with
	different startNumbers. The retrieve will be stopped if any UBX-LOG message is received.
	The speed of transfer can be maximized by using a high data rate and temporarily stopping
	the GPS processing (see UBX-CFG-RST)



		Hea	der	Class	ID	Length ('Bytes)		Payload	Checksum
Message Structur	e	0xB	35 0x62	0x21	0x09	12			see below	CK_A CK_B
Payload Contents:										
Byte Offset	Numb	er	Scaling	Name			Unit	Description		
	Forma	at								
0	U4		-	star	tNum	ber	-	Index of first entry to b	pe transfer	red
4	U4		-	entr	ryCour	nt	-	Number of log entries	to transfe	r. The maximum
								is 256		
8	U1		-	vers	sion		-	The version of this message. Set to 0		
9	U1[3]	-	rese	erved	L	-	Reserved		

21.13.9 UBX-LOG-STRING (0x21 0x04)

21.13.9.1 Store arbitrary string in on-board flash

Message		LO	G-STRING	3							
Description		Sto	ore arbitr	ary st	ring in	on-bo	ard flas	า			
Firmware		Sup	ported o	n:							
		•ι	a-plox M8	from	firmwa	re versi	on 2.00	up to version 2.30			
Туре		Cor	mmand								
Comment		This	This message can be used to store an arbitrary byte string in the on-board flash memory.								
		The maximum length that can be stored is 256 bytes.									
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Structu	re	OxB	35 0x62	0x21	0x04	0 + 1*	N		see below	CK_A CK_B	
Payload Contents	s:	•			•	•			•		
Byte Offset	Numb	ber	Scaling	Name			Unit	Description			
	Forma	ət									
Start of repeated	l block ((N tin	nes)								
N*1	U1		-	byte	s		-	The string of bytes to I	be logged	(maximum 256)	
End of repeated block											



21.14 UBX-MGA (0x13)

Multi-GNSS Assistance: i.e. Assistance data for various GNSS.

21.14.1 UBX-MGA-ACK (0x13 0x60)

21.14.1.1 UBX-MGA-ACK-DATA0

Message		UBX-M	GA-A	CK-D	ATA0								
Description		Multi-G	inss	Ackn	owled	ge me	ssage						
Firmware		Support			firmwa	are versi	on 2.00	up to version 2.30					
Туре		Output											
Comment		message	This message is sent by a u-blox receiver to acknowledge the receipt of an assistance message. Acknowledgements are enabled by setting the ackAiding parameter in the UBX-CFG-NAVX5 message. See the description of flow control for details.										
		Header		Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	0xB5 0x	62	0x13	0x60	8			see below	CK_A CK_B			
Payload Conte	nts:					1			•				
Byte Offset	Numb Forma		ng	Name			Unit	Description					
0	U1	-		type	5		-	Type, 1 = ACK, 0 = N/	ре, 1 = АСК, 0 = NACK				
1	U1	-		vers	sion		-	The version of this me	he version of this message, always set to 0				
2	1 U1 - v				orCod	e	-	 0: No error occured (c ACK) 1: The receiver doesn' use the data (To resolv UBX-MGA-INI-TIME supplied first) 2: The message version receiver 3: The message size d message version 4: The message data of database 	Indicates the reason why a NACK was retur 0: No error occured (only if message type is ACK) 1: The receiver doesn't know the time so ca use the data (To resolve this an UBX-MGA-INI-TIME_UTC message shoul supplied first) 2: The message version is not supported by receiver 3: The message size does not match the message version 4: The message data could not be stored to database 5: The receiver is not ready to use the message data				
3	U1	-		msgl	Id		-	UBX message ID of the ack'ed message					
4	U1[4		msgPayloadSta rt			-	The first 4 bytes of the payload	The first 4 bytes of the ack'ed message's					



21.14.2 UBX-MGA-ANO (0x13 0x20)

21.14.2.1 Multi-GNSS AssistNow Offline Assistance

Message		MGA-ANC)									
Description		Multi-GNS	SS Assis	tNow	Offline	Assist	ance					
Firmware		Supported	ported on:									
		• u-blox N	18 from	firmwa	ire versi	on 2.00) up to version 2.30					
Туре		Input										
Comment		This messa	ge is cre	ated by	y the As	ssistNov	v Offline service to delive	er AssistNov	v Offline			
		assistance	to the re	ceiver.	See the	e descrip	otion of AssistNow Offlin	ne for detai	ls.			
Header Class ID Length (Bytes) Payload							Payload	Checksum				
Message Struc	ture	0xB5 0x62	0x13	0x20	76			see below	CK_A CK_B			
Payload Conte	nts:		- 1					- 1	I			
Byte Offset	Numb	er Scaling	Name	Name			Description					
	Forma	t										
0	U1	-	type	2		-	message type (always 0x00)					
1	U1	-	vers	sion		-	message version (always 0x00)					
2	U1	-	svId	1		-	Satellite identifier (see	Satellite identifier (see Satellite Numbering)				
3	U1	-	gnss	sId		-	GNSS identifier (see S	Satellite Nur	nbering)			
4	U1	-	year			-	years since the year 2	2000				
5	U1	-	mont	h		-	month (112)					
6	U1	- day		-	day (131)							
7	U1	- reserved1		1	-	Reserved	Reserved					
8	U1[6	[64] - data				-	assistance data	assistance data				
72	U1[4]	1[4] - reserved2				-	Reserved					

21.14.3 UBX-MGA-DBD (0x13 0x80)

21.14.3.1 Poll the Navigation Database

Message	MGA-DBD	MGA-DBD											
Description	Poll the Na	Poll the Navigation Database											
Firmware	Supported o	Supported on:											
	• u-blox M8	from ⁻	firmwa	re version 2.00 up to version 2.30									
Туре	Poll Request												
Comment	Poll the who	Poll the whole navigation data base. The receiver will send all available data from its											
	internal data	base. 1	he rec	eiver will indicate the finish of the trans	mission wi	th a							
	UBX-MGA-A	. <mark>ск</mark> . Th	e msgl	PayloadStart field of the UBX-MGA-ACK	message	will contain a							
	U4 represen	ting the	e numk	per of UBX-MGA-DBD-DATA* messages	sent.								
	Header	Class	ID	Length (Bytes)	Payload	Checksum							
Message Structure	0xB5 0x62 0x13 0x80 0 see below CK_A CK_B												
No payload													



21.14.3.2 Navigation Database Dump Entry

Message		MG	A-DBD									
Description		Nav	vigation	Datab	ase D	ump Ei	ntry					
Firmware		Sup	ported o	n:								
		• u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Inp	Input / Output Message									
Comment UBX-MGA-DBD messages are only intended to be sent back to the same rece							me receiver					
		tha	it genera	ted th	iem.							
		Nav	igation d	atabas	e entry	. The d	ata field	s are firmware specific	. Transmissio	on of this type		
		of r	nessage v	will be	acknov	wledge	d by MGA	A-ACK messages, if ac	knowledgen	nent has been		
		ena	bled (see	the de	escripti	on of fl	ow cont	rol for details).				
		The	The maximum payload size for firmware 2.01 is 164 bytes (which makes the maximum									
		me	ssage size	e 172 b	ytes).							
		Head	der	Class	ID	Length	(Bytes)		Payload	Checksum		
Message Struct	ure	0xB	5 0x62	0x13	0x80	12 + 1	*N		see below	СК_АСК_В		
Payload Conten	ts:											
Byte Offset	Numb	er	Scaling	Name			Unit	Description				
	Forma	at										
0 U1[12] - reserved1 - Reserved												
Start of repeate	d block ('N tin	nes)									
12 + 1*N	U1		-	data	L		-	fw specific data				
End of repeated	l block											

21.14.4 UBX-MGA-FLASH (0x13 0x21)

21.14.4.1 UBX-MGA-FLASH-DATA

Message	l	UBX	X-MGA-F	LASH	DATA						
Description	1	Tra	nsfer M	GA-AN	O dat	a block	to flash				
Firmware	(Supported on:									
	•	• u-blox M8 from firmware version 2.00 up to version 2.30									
Туре	I	Input									
Comment This message is used to transfer a block of MGA-ANO data from host to the receiver. U reception of this message, the receiver will write the payload data to its internal non-volatile memory (flash). Also, on reception of the first MGA-FLASH-DATA message, receiver will erase the flash allocated to storing any existing MGA-ANO data. The payload can be up to 512 bytes. Payloads larger than this would exceed the receiver's internal buffering capabilities. The receiver will ACK/NACK this message using the message alternatives given below. The host shall wait for an acknowledge message before sendi the next data block. See Flash-based AssistNow Offline for details.								rnal TA message, the a. The payload 's internal nessage			
	ŀ	Чеас	der	Class	ID	Length ((Bytes)		Payload	Checksum	
Message Structure 0xB5 0x62 0x13 0x21 6 + 1*size set						see below	CK_A CK_B				
Payload Content	ts:					•			•		
Byte Offset	Numbe Format		Scaling	Name			Unit	Description			

byte Offset	Number	Scalling	Name	Unit	Description
	Format				
0	U1	-	type	-	Message type. Set to 1 for this message.
1	U1	-	version	-	FLASH-DATA message version (this is version 0).



MGA-FLASH continued

Byte Offset	Number	Scaling	Name	Unit	Description					
	Format									
2	U2 -		sequence	-	Message sequence number, starting at 0 and					
					increamenting by 1 for each MGA-FLASH-DATA					
					message sent.					
4	U2	-	size	-	Payload size in bytes.					
Start of repeated	block (size	times)								
6 + 1*N	U1	-	data	-	Payload data.					
End of repeated l	End of repeated block									

21.14.4.2 UBX-MGA-FLASH-STOP

Message		UB	X-MGA-	FLASH	-STOP						
Description		Fin	ish flash	ing M	GA-AN	IO data	a				
Firmware			ported o								
		• l	a-plox M8	3 from	firmwa	ire versi	on 2.00	up to versio	on 2.30		
Туре		Inp	ut								
CommentThis message is used to tell the receiver that there messages coming, and that it can do any final inte data to flash as a background activity. A UBX-MG, this process. Note that there may be a delay of sev for this message is sent because of the time taken AssistNow Offline for details.						final interna UBX-MGA-A lay of severa	al operations ACK message al seconds be	needed to will be se fore the L	o commit the ent at the end of JBX-MGA-ACK		
Message Struct	uro	Hea	35 0x62	Class 0x13	1D 0x21	Length 2	(bytes)			see below	
Payload Conten			55 07.02	0.15	0,72,1	2					
Byte Offset	Numi	ber	Scaling	Name			Unit	Description			
	Form	at									
0	U1		-	type	5		-	Message	type. Set to 2	2 for this n	nessage.
1	U1		-	vers	sion		-	FLASH-ST	OP message	version (th	nis is version 0).

21.14.4.3 UBX-MGA-FLASH-ACK

Message		UB	X-MGA-I	LASH	-ACK			BX-MGA-FLASH-ACK										
Description		Ac	knowled	ge las	t FLAS	H-DAT	A or -S	ТОР										
Firmware			oported o															
 u-blox M8 from firmware version 2.00 up to version 2.30 																		
Type Output																		
Comment	Comment			This message reports an ACK/NACK to the host for the last MGA-FLASH type 1 or type 2														
		me	message message received. See Flash-based AssistNow Offline for details.															
		Hea	der	Class	ID	Length	Length (Bytes)			Payload	Checksum							
Message Struct	ure	OxE	35 0x62	0x13	0x21	6				see below	СК_АСК_В							
Payload Conter	nts:			•		•												
Byte Offset	Nun	nber	Scaling	Name			Unit	Description	Description									
	Format																	
0	U1		-	type - Message type. Set to 3 for this message.				nessage.										



MGA-FLASH continued

Byte Offset	Number Format	Scaling	Name	Unit	Description
1	U1	-	version	-	FLASH-ACK message version (this is version 0).
2	U1	-	ack	-	Acknowledgement type. 0 - ACK: Message received and written to flash. 1 - NACK: Problem with last message, re-transmission required (this only happens while acknowledging a UBX-MGA_FLASH_DATA message). 2 - NACK: problem with last message, give up.
3	U1	-	reserved1	-	Reserved
4	U2	-	sequence	-	If acknowledging a UBX-MGA-FLASH-DATA message this is the Message sequence number being ack'ed. If acknowledging a UBX-MGA-FLASH-STOP message it will be set to 0xffff.

21.14.5 UBX-MGA-GLO (0x13 0x06)

21.14.5.1 UBX-MGA-GLO-EPH

Message		UB	X-MGA-	GLO-E	PH						
Description		GL	ONASS I	Ephem	eris As	sistan	ce				
Firmware			ported c								
		• L	u-blox M8	8 from	firmwa	ire versi	on 2.00 ι	up to version 2.30			
Туре		Inp	out								
Comment			-				of GLONA for details	ASS ephemeris assistance.	ce to a rec	eiver. See the	
		Hea	der .	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struct	Message Structure 0			0x13	0x06	48			see below	CK_A CK_B	
Payload Conter	nts:								•		
Byte Offset	Numb	Number Scaling		Name	Name		Unit	Description			
	Forma	ət									
0	U1		-	type	5		-	Message type. Set to 7	1 for this n	nessage (1 =	
								Ephemeris).			
1	U1		-	rese	erved	1	-	Reserved			
2	U1		-	svId	svId		-	GLONASS Satellite identifier (see Satellite			
								Numbering)			
3	U1		-	rese	erved	2	-	Reserved			
4	U1		-	FT			-	User range accuracy			
5	U1		-	В			-	Health flag from string	g 2		
6	U1		-	М			-	Type of GLONASS sate	ellite (1 inc	licates	
								GLONASS-M)			
7	1		-	Н	Н		-	Carrier frequency number of navigation RF			
								signal, Range=(-7 6)	, -128 for	unknown	
8	14		2^-11	x			kilomet	X component of the S	V position	in PZ-90.02	
							ers	coordinate System			





MGA-GLO continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
12	14	2^-11	У	kilomet	Y component of the SV position in PZ-90.02
				ers	coordinate System
16	14	2^-11	Z	kilomet	Z component of the SV position in PZ-90.02
				ers	coordinate System
20	14	2^-20	dx	kilomet	X component of the SV velocity in PZ-90.02
				ers/sec	coordinate System
24	14	2^-20	dy	kilomet	Y component of the SV velocity in PZ-90.02
				ers/sec	coordinate System
28	14	2^-20	dz	kilomet	Z component of the SV velocity in PZ-90.02
				ers/sec	coordinate System
32	1	2^-30	ddx	kilomet	X component of the SV acceleration in PZ-90.02
				ers/sec	coordinate System
				^2	
33	1	2^-30	ddy	kilomet	Y component of the SV acceleration in PZ-90.02
				ers/sec	coordinate System
				^2	
34	1	2^-30	ddz	kilomet	Z component of the SV acceleration in PZ-90.02
				ers/sec	coordinate System
				^2	
35	U1	15	tb	minutes	Index of a time interval within current day
					according to UTC(SU)
36	12	2^-40	gamma	-	Relative carrier frequency deviation
38	U1	-	E	days	Ephemeris data age indicator
39	1	2^-30	deltaTau	seconds	Time difference between L2 and L1 band
40	14	2^-30	tau	seconds	SV clock bias
44	U1[4]	-	reserved3	-	Reserved

21.14.5.2 UBX-MGA-GLO-ALM

Message		UB	X-MGA-0	GLO-A	LM						
Description		GL	ONASS A	Imana	ac Assi	istance					
Firmware		Sup	oported o	n:							
u-blox M8 from firmware version 2.00 up to version 2.30											
Type Input											
Comment			This message allows the delivery of GLONASS almanac assistance to a receiver. See the description of AssistNow Online for details.								
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struct	ture	OxE	35 0x62	0x13	0x06	36			see below	CK_A CK_B	
Payload Conter	nts:	•		•		•					
Byte Offset	Numi Form		Scaling	Name			Unit	Description			
0 U1 -		type	type		-	Message type. Set to 2 for this message (2 = Almanac).					
1	U1	- reserved1			1	-	Reserved				




MGA-GLO continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
2	U1	-	svId	-	GLONASS Satellite identifier (see Satellite
					Numbering)
3	U1	-	reserved2	-	Reserved
4	U2	-	N	days	Reference calender day number of almanac
					within the four-year period (from string 5)
6	U1	-	М	-	Type of GLONASS satellite (1 indicates
					GLONASS-M)
7	U1	-	С	-	Unhealthy flag at instant of almanac upload (1
					indicates operability of satellite)
8	12	2^-18	tau	seconds	Coarse time correction to GLONASS time
10	U2	2^-20	epsilon	-	Eccentricity
12	14	2^-20	lambda	semi-cir	Longitude of the first (within the N-day)
				cles	ascending node of satellite orbit in PC-90.02
					coordinate system
16	14	2^-20	deltaI	semi-cir	Correction to the mean value of inclination
				cles	
20	U4	2^-5	tLambda	seconds	Time of the first ascending node passage
24	14	2^-9	deltaT	seconds	Correction to the mean value of Draconian
				/orbital-	period
				period	
28	1	2^-14	deltaDT		Rate of change of Draconian perion
				/orbital-	
				period^	
				2	
29	1	-	Н	-	Carrier frequency number of navigation RF
					signal, Range=(-7 6)
30	12	-	omega	-	Argument of perigee
32	U1[4]	-	reserved3	-	Reserved

21.14.5.3 UBX-MGA-GLO-TIMEOFFSET

Message		UB	X-MGA-0	GLO-TI	MEOF	FSET						
Description		GL	ONASS A	uxilia	ry Tim	e Offs	et Assist	ance				
Firmware		Sup	ported o	n:								
		 u-blox M8 from firmware version 2.00 up to version 2.30 										
Type Input												
Comment		This	This message allows the delivery of auxiliary GLONASS assistance (including the GLONASS									
		tim	time offsets to other GNSS systems) to a receiver. See the description of AssistNow Online									
		for	details.									
		Hea	der	Class	ID	Length	'Bytes)			Payload	Checksum	
Message Struct	ure	0xB	35 0x62	0x13	0x06	20				see below	СК_АСК_В	
Payload Conten	ts:	•			•					•	•	
Byte Offset	Numb	ber	Scaling	Name			Unit	Description				
	Form	at										





MGA-GLO continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
0	U1	-	type	-	Message type. Set to 3 for this message $(3 =$
					time offsets).
1	U1	-	reserved1	-	Reserved
2	U2	-	N	days	Reference calender day number within the
					four-year period of almanac (from string 5)
4	14	2^-27	tauC	seconds	Time scale correction to UTC(SU) time
8	14	2^-31	tauGps	seconds	Correction to GPS time relative to GLONASS
					time
12	12	2^-10	B1	seconds	Coefficient to determine delta UT1
14	12	2^-16	В2	seconds	Rate of change of delta UT1
				/msd	
16	U1[4]	-	reserved2	-	Reserved

21.14.6 UBX-MGA-GPS (0x13 0x00)

21.14.6.1 UBX-MGA-GPS-EPH

Message		UB	X-MGA-	GPS-EF	ΡΗ							
Description		GP	S Ephem	eris A	ssistar	nce						
Firmware		Sup	oported o	n:								
		•ι	u-blox M8	3 from	firmwa	are versi	on 2.00 เ	p to version 2.30				
Туре		Inp	Input									
Comment		This message allows the delivery of GPS ephemeris assistance to a receiver. See the										
		des	description of AssistNow Online for details.									
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum		
Message Struct	ture	0xB	35 0x62	0x13	0x00	68			see below	CK_A CK_B		
Payload Conter	nts:			•		•						
Byte Offset	Numl	ber	Scaling	Name			Unit	Description				
	Forma	at										
0	U1		-	type		-	Message type. Set to 1	I for this n	nessage (1 =			
								Ephemeris).				
1	U1		-	rese	erved	1	-	Reserved				
2	U1		-	svId	1		-	GPS Satellite identifier (see Satellite Numbering				
3	U1		-	rese	erved	2	-	Reserved				
4	U1		-	fitI	Inter	val	-	Fit interval flag				
5	U1		-	ural	Index		-	URA index				
6	U1		-		ealth		-	SV health				
7	11		2^-31	tgd			seconds	Group delay differenti	al			
8	U2		-	iodo	2		-	IODC				
10	U2		2^4	toc			seconds	Clock data reference t	ime			
12	U1 - reserved3		3	-	Reserved							
13	11 2^-55 af 2			sec/sec	Time polynomial coeff	icient 2						
							squared					
14	12		2^-43	af1			sec/sec	Time polynomial coefficient 1				
16	14		2^-31	af0			seconds	Time polynomial coeff	icient 0			





MGA-GPS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
20	12	2^-5	crs	meters	Crs
22	12	2^-43	deltaN	semi-cir	Mean motion difference from computed value
				cles/sec	
24	14	2^-31	m0	semi-cir	Mean anomaly at reference time
				cles	
28	12	2^-29	cuc	radians	Amplitude of cosine harmonic correction term
					to argument of latitude
30	12	2^-29	cus	radians	Amplitude of sine harmonic correction term to
					argument of latitude
32	U4	2^-33	е	-	Eccentricity
36	U4	2^-19	sqrtA	sqrt	Square root of the semi-major axis
				meters	
40	U2	2^4	toe	seconds	Reference time of ephemeris
42	12	2^-29	cic	radians	Amplitude of cos harmonic correction term to
					angle of inclination
44	14	2^-31	omega0	semi-cir	Longitude of ascending node of orbit plane at
				cles	weekly epoch
48	12	2^-29	cis	radians	Amplitude of sine harmonic correction term to
					angle of inclination
50	12	2^-5	crc	meters	Amplitude of cosine harmonic correction term
					to orbit radius
52	14	2^-31	iO	semi-cir	Inclination angle at reference time
				cles	
56	14	2^-31	omega	semi-cir	Argument of perigee
				cles	
60	14	2^-43	omegaDot		Rate of right ascension
				cles/sec	
64	12	2^-43	idot	semi-cir	Rate of inclination angle
				cles/sec	
66	U1[2]	-	reserved4	-	Reserved



21.14.6.2 UBX-MGA-GPS-ALM

Message		UBX-MGA-	GPS-AI	LM								
Description		GPS Alman	GPS Almanac Assistance									
Firmware		Supported c • u-blox M8		firmwa	are vers	ion 2.00 ι	ip to version 2.30					
Туре		Input										
Comment		This messag description			-		manac assistance to a l	receiver. Se	ee the			
		Header	Class					Payload	Checksum			
Message Struc	ture	0xB5 0x62	0x13	0x00	36			see below	СК_АСК_В			
Payload Conte	nts:											
Byte Offset	Numb Forma		Name			Unit	Description					
0	U1	-	type	2		-	Message type. Set to Almanac).	2 for this r	nessage (2 =			
1	U1	-	rese	erved	1	-	Reserved					
2	U1	-	svId	svId			GPS Satellite identifie	entifier (see Satellite Numbering				
3	U1	-	svHe	ealth		-	SV health informatior	۱				
4	U2	2^-21	е			-	Eccentricity					
6	U1	-	almW	almWNa		week	Reference week numl WNa field)	per of alma	anac (the 8 bit			
7	U1	2^12	toa			seconds	Reference time of alm	nanac				
8	12	2^-19	delt	aI		semi-cir cles	Delta inclination angle	e at referer	nce time			
10	12	2^-38	omeg	gaDot		semi-cir cles/sec	Rate of right ascensio	n				
12	U4	2^-11	sqrt	A		sqrt meters	Square root of the se	mi-major a	xis			
16	14	2^-23	omeg	ja0		semi-cir cles	Longitude of ascendir	ng node of	orbit plane			
20	14	2^-23	omeg	ja		semi-cir cles	emi-cir Argument of perigee					
24	14	2^-23	mO				-cir Mean anomaly at reference time					
28	12	2^-20	af0				Time polynomial coef	ficient 0 (8	MSBs)			
30	12	2^-38	af1			sec/sec	Time polynomial coef	ficient 1				
32	U1[4	.] -	rese	erved	2	-	Reserved					



21.14.6.3 UBX-MGA-GPS-HEALTH

Message		UB	BX-MGA-GPS-HEALTH									
Description		GP	S Health	Assist	ance							
Firmware			Supported on:									
		• L	u-blox M8 from firmware version 2.00 up to version 2.30									
Туре		Inp	put									
Comment		Thi	his message allows the delivery of GPS health assistance to a receiver. See the descriptic									
		of /	AssistNov	v Onlin	e for d	etails.						
		Неа	Header Class ID Length (Bytes) Payload Checksum									
Message Structu	ıre	OxE	35 0x62	0x13	0x00	40			see below	CK_A CK_B		
Payload Conten	ts:	-			•							
Byte Offset	Numb	ber	Scaling	Name			Unit	Description				
	Forma	ət										
0	U1		-	type	5		-	Message type. Set to 4 for this message (4 =				
								health flags).				
1	U1[3]	-	rese	ervedl	1	-	Reserved				
4 U1[32] - healthCode - Each byte represents a GPS SV (1-32). The							1-32). The 6					
								LSBs of each byte cont	tains the 6	bit health code		
								from subframes 4/5 page 25.				
36	U1[4	.]	-	rese	erved2	2	-	Reserved				

21.14.6.4 UBX-MGA-GPS-UTC

Message		UB	UBX-MGA-GPS-UTC										
Description		GP	S UTC As	sistan	ce								
Firmware		Sup	Supported on:										
		• L	u-blox M8	⁸ from ⁻	firmwa	ire versi	on 2.00 u	p to version 2.30					
Туре		Inp	nput										
Comment		Thi	This message allows the delivery of GPS UTC assistance to a receiver. See the descriptio										
		Ass	sistNow O	nline f	or deta	ails.							
		Hea	Header Class ID Length (Bytes) Payload Checksum										
Message Struc	ture	0xB5 0x62 0x13 0x00 20 see below CK_4					CK_A CK_B						
Payload Conte	nts:			•	•	•			•				
Byte Offset	Num	ber	Scaling	Name			Unit	Description					
	Form	ət											
0	U1		-	type	2		-	Message type. Set to 5 for this message (5 =					
								Time parameters).					
1	U1[3	3]	-	rese	erved	1	-	Reserved					
4	14		2^-30	utcA	40		seconds	First parameter of UTC	polynom	al			
8	14		2^-50	utcA	1		sec/sec	Second parameter of l	JTC polyn	omial			
12	1		-	utcI	DtLS		seconds	Delta time due to curr	ent leap se	econds			
13	U1	2^12 utcTot					seconds	UTC parameters refere	ence time o	of week (GPS			
								time)					
14	U1		-	utcW	INt		weeks	UTC parameters refere	ence week	number (the 8			
								bit WNt field)					



MGA-GPS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
15	U1	-	utcWNlsf	weeks	Week number at the end of which the future
					leap second becomes effective (the 8 bit WNLSF
					field)
16	U1	-	utcDn	days	Day number at the end of which the future leap
					second becomes effective
17	1	-	utcDtLSF	seconds	Delta time due to future leap seconds
18	U1[2]	-	reserved2	-	Reserved

21.14.6.5 UBX-MGA-GPS-IONO

Message		UBX-MGA	UBX-MGA-GPS-IONO									
Description		GPS lono	sphere A	Assista	ance							
Firmware		Supported u-blox N 		firmwa	are vers	ion 2.00 ι	p to version 2.30					
Туре		Input					-					
Comment			This message allows the delivery of GPS ionospheric assistance to a receiver. See the description of AssistNow Online for details.									
		Header	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struct	essage Structure 0xB5 0x62				16			see below	CK_A CK_B			
Payload Conter	nts:							1	I			
Byte Offset	Numb Forma	J	Name			Unit	Description					
0	U1	-	type	5		-	Message type. Set to 6 for this message (6 = ionosphere parameters).					
1	U1[3	3] -	rese	erved	1	-	Reserved					
4	1	2^-30	iono	Alph	.a0	seconds	lonospheric parameter	r alpha0 [s]			
5	1	2^-27	iond	ionoAlpha1		sec/sem i-circle	Ionospheric parameter	r alpha1 [s	/semi-circle]			
6	11	2^-24	iono	ionoAlpha2		sec/(se mi-circl e^2)	lonospheric parameter	r alpha2 [s	/semi-circle^2]			
7	11	2^-24	iono	DAlph	a3	sec/(se mi-circl e^3)	Ionospheric parameter	r alpha3 [s	/semi-circle^3]			
8	1	2^11	iono	Beta	0	seconds	lonospheric parameter	r beta0 [s]				
9	1	2^14	iond	oBeta	1	sec/sem i-circle	lonospheric parameter	r beta1 [s/s	semi-circle]			
10	11	2^16 ionoBeta2				sec/(se mi-circl e^2)	Ionospheric parameter beta2 [s/semi-circle^2]					
11	I II 2^16 ionoBeta3 sec/(se Ionospheric parameter beta3 [s/semi-cire mi-circl e^3)					emi-circle^3]						
12	U1[4	l] -	rese	erved	2	-	Reserved					



21.14.7 UBX-MGA-INI (0x13 0x40)

21.14.7.1 UBX-MGA-INI-POS_XYZ

Message		UB	IBX-MGA-INI-POS_XYZ										
Description		Ini	Initial Position Assistance										
Firmware		Su	Supported on:										
		• (u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Inp	out										
Comment		Supplying position assistance that is inaccurate by more than the specified								ecified			
		position accuracy, may lead to substantially degraded receiver performance.											
		Thi	s message	e allow	s the d	elivery	of initia	position assistance ⁻	to a receiver in	cartesian ECEF			
		cod	ordinates.	This m	nessage	is equ	ivalent t	o the UBX-MGA-IN	I-POS_LLH m	nessage, except			
		for	the coord	dinate	system	. See th	ne descri	ption of AssistNow (Online for deta	ils.			
		Hea	nder	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	0x8	35 0x62	0x13	0x40	20			see below	СК_АСК_В			
Payload Conte	nts:				•								
Byte Offset	Num	ber	Scaling	Name			Unit	Description					
	Form	at											
0	U1		-	type	5		-	Message type. Set	t to 0x00 for th	nis message			
								(0x00 = Position -	ECEF - XYZ).				
1	U1[3	1[3] - reserved1 - Reserved											
4	14		-	ecef	X		cm WGS84 ECEF X coordinate						
8	14		-	ecef	Y		cm	WGS84 ECEF Y co	oordinate				
12	14		-	ecef	Z		cm	WGS84 ECEF Z coordinate					
16	U4		-	posA	Acc		cm	Position accuracy	(stddev)				

21.14.7.2 UBX-MGA-INI-POS_LLH

Message		UB	UBX-MGA-INI-POS_LLH									
Description		Init	Initial Position Assistance									
Firmware		Supported on:u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Input										
Comment Message Struc	ture	pos This lat/ me det <i>Hea</i>	sition acc s message long/alt c ssage, exe ails.	curacy e allow oordin	, may s the c ates. T	lead to lelivery his mes oordina	of initia sage is e te syste	inaccurate by mo antially degraded position assistance equivalent to the to m. See the descrip	d receiver perfo te to a receiver in JBX-MGA-INI-	WGS84 POS_XYZ W Online for Checksum		
Payload Conte	nts:			•		•			•			
Byte Offset	Num! Forma		Scaling	Name			Unit	t Description				
0	U1		-	type	2		-	Message type. S (0x01 = Position	Set to 0x01 for t n - ECEF - LLA).	his message		
1	U1[3] - reserved1 - Reserved											



MGA-INI continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
4	14	1e-7	lat	deg	WGS84 Latitude
8	14	1e-7	lon	deg	WGS84 Longitude
12	14	-	alt	cm	WGS84 Altitude
16	U4	-	posAcc	cm	Position accuracy (stddev)


21.14.7.3 UBX-MGA-INI-TIME_UTC

Message		UBX	-MGA-I	NI-TIN	1E_UT	С								
Description		Initia	nitial Time Assistance											
Firmware		Supp	orted o	n:										
		• u-ł	blox M8	3 from	firmwa	are vers	ion 2.00) up to version 2.30						
Туре		Input	t											
Comment		Supp	olying t	lying time assistance that is inaccurate by more than the specified time										
				ay lead to substantially degraded receiver performance.										
			0		e allows the delivery of UTC time assistance to a receiver. This message is									
			quivalent to the UBX-MGA-INI-TIME_GNSS message, except for the time base. See the lescription of AssistNow Online for details.											
			•			1		ils.	1	1				
		Heade		Class	ID	Length	(Bytes)		Payload	Checksum				
Message Struc	essage Structure 0xB5 0x62			0x13	0x40	24			see below	CK_A CK_B				
Payload Conte	ents:													
Byte Offset	Numb	ber S	icaling	Name			Unit	Description						
	Forma	at												
0	U1	-		type	9		-	Message type. Set to	0x10 for th	nis message				
								(0x10 = Time).						
1	U1	-		rese	reserved1		-	Reserved						
2	X1	-		ref	ref		-		Reference to be used to set time (see graphic					
2				-				below) Number of leap seconds since 1980 (or 0x80						
3	1	-		lear	leapSecs		S		ids since 19	980 (or 0x80 =				
4	U2							-128 if unknown)						
4	U1	-		year			-	Year Month, starting at 1						
o 7	U1			mont	n		-	Day, starting at 1						
8	U1			day hour	~		-	Hour, from 0 to 23						
9	U1			minu			-	Minute, from 0 to 59						
10	U1			seco			s	Seconds, from 0 to 59)					
10	U1	-			erved	2	-	Reserved	•					
12	U4						9.999							
16	U2						- ,							
18	U1[2													
20	U4	-		tAcc			ns	Nanoseconds part of	time accura	acy, from 0 to				
								999,999,999		-				



Bitfield ref

This Graphic explains the bits of ref



■ signed value ■ unsigned value ■ reserved

Name	Description
source	0: none, i.e. on receipt of message (will be inaccurate!)
	1: relative to pulse sent to EXTINTO
	2: relative to pulse sent to EXTINT1
	3-15: reserved
fall	use falling edge of EXTINT pulse (default rising) - only if source is EXTINT
last	use last EXTINT pulse (default next pulse) - only if source is EXTINT

21.14.7.4 UBX-MGA-INI-TIME_GNSS

Message	UBX-MGA-	INI-TIN	1E_GN	SS		
Description	Initial Time	Assist	ance			
Firmware	Supported c	n:				
	• u-blox M8	3 from ⁻	firmwa	re version 2.00 up to version 2.30		
Туре	Input					
Comment	Supplying	time as	ssistan	ce that is inaccurate by more that	an the specifi	ed time
	accuracy, m	nay lea	d to s	ubstantially degraded receiver p	erformance.	
	This messag	e allow	s the d	elivery of time assistance to a receiv	er in a chosen	GNSS
	timebase. Th	nis mes	sage is	equivalent to the UBX-MGA-INI-T	TIME_UTC me	essage, except
	for the time	base. S	See the	description of AssistNow Online for	details.	
	Header	Class	ID	Length (Bytes)	Payload	Checksum
Message Structure	0xB5 0x62	0x13	0x40	24	see below	CK_A CK_B
Payload Contents:	÷					

Payload Contents:

Tayload Conte	1113.				
Byte Offset	Number Format	Scaling	Name	Unit	Description
0	U1	-	type	-	Message type. Set to $0x11$ for this message ($0x11 = Time GNSS$).
1	U1	-	reserved1	-	Reserved
2	X1	-	ref	-	Reference to be used to set time (see graphic below)
3	U1	-	gnssId	-	Source of time information. Currently supported: 0: GPS time 2: Galileo time 3: BeiDou time 6: GLONASS time: week = 834 + ((N4-1)*1461 + Nt)/7, tow = (((N4-1)*1461 + Nt) % 7) * 86400 + tod
4	U1[2]	-	reserved2	-	Reserved
6	U2	-	week	-	GNSS week number




MGA-INI continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
8	U4	-	tow	-	GNSS time of week
12	U4	-	ns	ns - GNSS time of week, nanosecond	
					999,999,999
16	U2	-	tAccS	S	Seconds part of time accuracy
18	U1[2]	-	reserved3	-	Reserved
20	U4	-	tAccNs	ns	Nanoseconds part of time accuracy, from 0 to
					999,999,999

Bitfield ref

This Graphic explains the bits of ${\tt ref}$



■ signed value ■ unsigned value ■ reserved

Description						
0: none, i.e. on receipt of message (will be inaccurate!)						
: relative to pulse sent to EXTINTO						
2: relative to pulse sent to EXTINT1						
3-15: reserved						
use falling edge of EXTINT pulse (default rising) - only if source is EXTINT						
use last EXTINT pulse (default next pulse) - only if source is EXTINT						

21.14.7.5 UBX-MGA-INI-CLKD

Message		UBX-MGA-INI-CLKD									
Description	Initial Clock Drift Assistance										
Firmware		Supported on:									
		• u-blox M8 from firmware version 2.00 up to version 2.30									
Туре		Inp	ut								
Comment		Supplying clock drift assistance that is inaccurate by more than the specified accuracy, may lead to substantially degraded receiver performance. This message allows the delivery of clock drift assistance to a receiver. See the description of AssistNow Online for details.									
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	OxB	35 0x62	0x13	0x40	12			see below	CK_A CK_B	
Payload Contents:											
Byte Offset	Number Format		Scaling	Name		Unit	Description				
0) U1		-	type		-	Message type. Set to $(0x20 = Clock Drift)$.	lessage type. Set to 0x20 for this message lx20 = Clock Drift).			
1	1 U1[3]		-	reserved1		-	Reserved	Reserved			
4 14			-	clkI	clkD		ns/s	Clock drift			



MGA-INI continued


Byte Offset	Number Format	Scaling	Name	Unit	Description
8	U4	-	clkDAcc	ns/s	Clock drift accuracy

21.14.7.6 UBX-MGA-INI-FREQ

Message		UB	X-MGA-I	NI-FRE	Q							
Description	Initial Frequency Assistance											
Firmware		Supported on:										
		 u-blox M8 from firmware version 2.00 up to version 2.30 										
Туре		Inp	out									
Comment		Supplying external frequency assistance that is inaccurate by more than the										
		spe	specified accuracy, may lead to substantially degraded receiver performance.									
		Thi	This message allows the delivery of external frequency assistance to a receiver. See the									
		des	description of AssistNow Online for details.									
		Hea	ıder	Class ID Length ((Bytes)		Payload Checksum			
Message Struc	ture	OxE	35 0x62	0x13	0x13 0x40 12				see below CK_A CI		CK_A CK_B	
Payload Conte	nts:	•		•					·	•		
Byte Offset	Numi	ber	Scaling	Name		Unit	Description	Description				
Form		at										
0	D U1		-	type	type		-	Message type. Set to 0x21 for this message			is message	
								(0x21 = Frequence	(0x21 = Frequency).			
1	U1[2	2]	-	reservedl		-	Reserved					
3	X1		-	flag	flags		-	Frequency refere	Frequency reference (see graphic below)			
4	14		1e-2	freq	freq		Hz	Frequency	Frequency			
8	3 U4		-	freq	freqAcc		ppb	Frequency accuracy				

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description					
source): frequency available on EXTINTO					
	1: frequency available on EXTINT1					
	2-15: reserved					
fall	use falling edge of EXTINT pulse (default rising)					



21.14.7.7 UBX-MGA-INI-EOP

Message		UBX-MGA	-INI-EO	Р						
Description		Earth Orie	ntation	Parar	neters	Assistan	ice			
Firmware		Supported • u-blox M		firmwa	are vers	ion 2.00	up to version 2.30			
Туре		Input								
Comment		This messag improve As			-		arth Orientation Paramon.	eters (EOP)	to a receiver to	
		Header	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	0xB5 0x62	0x13	0x13 0x40		72			CK_A CK_B	
Payload Conte	nts:							•	•	
Byte Offset	Numb Forma		Name	Name		Unit	Description			
0	U1	-	type	type		-	Message type. Set to $0x30$ for this message ($0x30 = EOP$).			
1	U1[3] -	rese	erved	1	-	Reserved	eserved		
4	U2	-	d2kI	d2kRef		d	reference time (days since 1.1.2000 12.00h UTC)			
6	U2	-	d2kN	d2kMax		d	expiration time (days s UTC)	expiration time (days since 1.1.2000 12.00h		
8	14	2^-30	xpP()		arcsec	x_p t^0 polynomial te	rm (offset)		
12	14	2^-30	xpPl	L		arcsec/ d	x_p t^1 polynomial te	x_p t^1 polynomial term (drift)		
16	14	2^-30	ypP()		arcsec	y_p t^0 polynomial te	rm (offset)		
20	14	2^-30	ypP]	ypP1		arcsec/ d	y_p t^1 polynomial te	y_p t^1 polynomial term (drift)		
24	14	2^-25	dUTI	L		S	dUT1 t^0 polynomial	term (offse	et)	
28	14	2^-30	ddUT	Г1		s/d	dUT1 t^1 polynomial	dUT1 t^1 polynomial term (drift)		
32	U1[4	0] -	rese	erved	2	-	Reserved			

21.14.8 UBX-MGA-QZSS (0x13 0x05)

21.14.8.1 UBX-MGA-QZSS-EPH

Message		UB	BX-MGA-QZSS-EPH								
Description		QZ:	ZSS Ephemeris Assistance								
Firmware			upported on: u-blox M8 from firmware version 2.00 up to version 2.30								
Type Input											
Comment		This message allows the delivery of QZSS ephemeris assistance to a receiver. See the description of AssistNow Online for details.									
		Head	der	Class	ID	Length (Bytes) Payload Checksum			Checksum		
Message Structur	re	0xB	5 0x62	0x13	0x05	68			see below	CK_A CK_B	
Payload Contents	5.									•	
Byte Offset	Numbe Format		Scaling	Name		Unit Description					



MGA-QZSS continued

Byte Offset	Number Format	Scaling	Name	Unit	Description
0	U1	_	type		Message type. Set to 1 for this message (1 =
0			0120		Ephemeris).
1	U1	-	reserved1	-	Reserved
2	U1	-	svId	-	QZSS Satellite identifier (see Satellite Numbering
), Range 1-5
3	U1	-	reserved2	-	Reserved
4	U1	-	fitInterval	-	Fit interval flag
5	U1	-	uraIndex	-	URA index
6	U1	-	svHealth	-	SV health
7	11	2^-31	tgd	seconds	Group delay differential
8	U2	-	iodc	-	IODC
10	U2	2^4	toc	seconds	Clock data reference time
12	U1	-	reserved3	-	Reserved
13	11	2^-55	af2	sec/sec	Time polynomial coefficient 2
				squared	
14	12	2^-43	af1	sec/sec	Time polynomial coefficient 1
16	14	2^-31	af0		Time polynomial coefficient 0
20	12	2^-5	crs	meters	Crs
22	12	2^-43	deltaN		Mean motion difference from computed value
				cles/sec	······
24	14	2^-31	mO		Mean anomaly at reference time
				cles	
28	12	2^-29	cuc	radians	Amp of cosine harmonic corr term to arg of lat
30	12	2^-29	cus	radians	Amp of sine harmonic corr term to arg of lat
32	U4	2^-33	e	-	eccentricity
36	U4	2^-19	sqrtA	sqrt	Square root of the semi-major axis A
			-	meters	
40	U2	2^4	toe		Reference time of ephemeris
42	12	2^-29	cic	radians	Amp of cos harmonic corr term to angle of
					inclination
44	14	2^-31	omega0	semi-cir	Long of asc node of orbit plane at weekly epoch
				cles	
48	12	2^-29	cis	radians	Amp of sine harmonic corr term to angle of
					inclination
50	12	2^-5	crc	meters	Amp of cosine harmonic corr term to orbit
					radius
52	14	2^-31	iO	semi-cir	Inclination angle at reference time
52			10	cles	
56	14	2^-31	omega		Argument of perigee
20				cles	
60	14	2^-43	omegaDot		Rate of right ascension
			Janegabot	cles/sec	
64	12	2^-43	idot		Rate of inclination angle
04	<u> </u>	12 -45	TUOL	12CHIL-CI	



MGA-QZSS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
66	U1[2]	-	reserved4	-	Reserved

21.14.8.2 UBX-MGA-QZSS-ALM

Message		UBX-MG	iA-Q	ZSS-A	٩LM							
Description		QZSS Almanac Assistance										
Firmware		Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30										
Туре												
Comment			This message allows the delivery of QZSS almanac assistance to a receiver. See the description of AssistNow Online for details.									
		Header	(Class ID Length			(Bytes)		Payload	Checksum		
Message Struc	ture	0xB5 0x6	52 (0x13	0x05	36			see below	CK_A CK_B		
Payload Conte	nts:											
Byte Offset	Numb Forma	-	g	Name			Unit	Description				
0	U1	-		type	2		-	Message type. Set to 2 for this message (2 = Almanac).				
1	U1	-		reserved1		-	Reserved					
2	U1	-		svId		-	QZSS Satellite identifier (see Satellite Numbering), Range 1-5					
3	U1	-		svHe	ealth		-	Almanac SV health inf	ormation			
4	U2	2^-2	1	е			-	Almanac eccentricity				
6	U1	-		almWNa		week	Reference week number of almanac (the 8 bit WNa field)					
7	U1	2^12	2	toa		seconds	Reference time of almanac					
8	12	2^-1	9	deltaI		semi-cir cles	Delta inclination angle at reference time					
10	12	2^-3	8	omeg	JaDot		semi-cir cles/sec	Almanac rate of right ascension				
12	U4	2^-1	1	sqrt	A		sqrt meters	Almanac square root	uare root of the semi-major axis A			
16	14	2^-2	3	omeg	ja0		semi-cir cles	Almanac long of asc r weekly	ode of ork	bit plane at		
20	14	2^-2	3	omega		semi-cir cles	Almanac argument of	perigee				
24	14 2^-23		3	m0			semi-cir cles	Almanac mean anoma	aly at refer	ence time		
28	12	2^-2	0	af0			seconds	Almanac time polynor	ne polynomial coefficient 0 (8 MSBs)			
30	12	2^-3	8	af1			sec/sec	Almanac time polynor	nial coeffic	cient 1		
32	U1[4	- [rese	erved	2	-	Reserved				



21.14.8.3 UBX-MGA-QZSS-HEALTH

Message		UB	X-MGA-	QZSS-H	IEALT	Н					
Description		QZ	SS Healt	h Assi	stance						
Firmware Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30											
Туре	Input										
<i>Comment</i> This message allows the delivery of QZSS health as: of AssistNow Online for details.						health assistance to a re	ceiver. See	e the description			
Header			der	Class	ID	Length	ength (Bytes) Payload Check			Checksum	
Message Structure		OxE	35 0x62	0x13	0x05	12			see below	CK_A CK_B	
Payload Conte	nts:			•							
Byte Offset	Num Form		Scaling	Name		Unit	Description	Description			
0	U1		-	type	type		-	Message type. Set to 4 health flags).	Message type. Set to 4 for this message (4 = health flags).		
1	U1[3	3]	-	rese	rved	1	-	Reserved			
4	U1[5] -		heal	thCoo	de	-	LSBs of each byte cont	Each byte represents a QZSS SV (1-5). The 6 LSBs of each byte contains the 6 bit health code from subframes 4/5, data ID = 3, SV ID = 51			
9	U1[3	3]	-	rese	erved	2	-	Reserved			



21.15 UBX-MON (0x0A)

Monitoring Messages: i.e. Comunication Status, CPU Load, Stack Usage, Task Status. Messages in this class are sent to report GPS receiver status, such as CPU load, stack usage, I/O subsystem statistics etc.


21.15.1 UBX-MON-GNSS (0x0A 0x28)

21.15.1.1 Information message GNSS selection

Message		М	ON-GNSS									
Description		Inf	Information message GNSS selection									
Firmware		Sup	Supported on:									
		• u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Ou	tput									
Comment		Thi	s message	e repor	ts GNS	S syste	m select	ion. It does this be mean	s of bit ma	asks in U1 fields.		
		Each bit in a bit mask corresponds to one GNSS system. Systems such as SBAS and QZSS										
	are	are not reported. If systems such as SBAS/QZSS are related to one GNSS system (GPS is										
		these cases), then they will be disabled when the related system is disabled.										
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum		
Message Structure		OxE	35 0x62	0x0A	0x28	8			see below CK_ACK			
Payload Conte	ents:			1	1	1				I		
Byte Offset Nun		ber Scaling		Name			Unit	Description				
	Form	at										
0	U1		-	vers	sion		-	Type of the message,	age, 1 for this type			
1	X1		-	Supported		d	-	A bit mask, saying wh	A bit mask, saying which GNSS systems can be			
								supported by this receiver (see graphic below)				
2	X1		-	Defa	ult		-	A bit mask, saying wh	A bit mask, saying which GNSS systems are			
								enabled in the current	efuse def	ault		
								configuration for this	receiver (se	e graphic		
								below)				
3	X1		-	Enab	oled		-	A bit mask, saying wh		,		
								currently enabled for t	this receive	er (see graphic		
								below)				
4	U1		-	Simu	ltan	eous	-		Maximum number of concurrent GNSS systems			
								which can be supported	ed by this i	receiver		
5	U1[3	3]	-	rese	erved	1	-	Reserved				

Bitfield Supported

This Graphic explains the bits of Supported



Name	Description
GPSSup	GPS is supported




Bitfield Supported Description continued

Name	Description
GlonassSup	GLONASS is supported
BeidouSup	BeiDou is supported

Bitfield Default

This Graphic explains the bits of Default




■ signed value ■ unsigned value ■ reserved

Name	Description
GPSDef	GPS is default-enabled
GlonassDef	GLONASS is default-enabled
BeidouDef	BeiDou is default-enabled

Bitfield Enabled

This Graphic explains the bits of Enabled



■ signed value ■ unsigned value ■ reserved

Name	Description
GPSEna	GPS is enabled
GlonassEna	GLONASS is enabled
BeidouEna	BeiDou is enabled



21.15.2 UBX-MON-HW2 (0x0A 0x0B)

21.15.2.1 Extended Hardware Status

Message		MON-HW2										
Description		Ext	tended H	lardwa	are Sta	atus						
Firmware		Sup	ported c	n:								
		• l	u-blox M8 from firmware version 2.00 up to version 2.30									
Туре		Peri	iodic/Poll	ed								
Comment		Sta	tus of dif	ferent	aspects	s of the	hardwa	are such as Imbalance, Low-Level Confi	guration			
		and POST Results.										
		The first four parameters of this message represent the complex signal from the RF front										
		end. The following rules of thumb apply:										
		 The smaller the absolute value of the variable ofsI and ofsQ, the better. 										
		• Ideally, the magnitude of the I-part (magI) and the Q-part (magQ) of the complex signal										
		S	hould be	1								
		Head		Class	ID	Length	(Bytes)	,	ecksum			
Message Struc	ture	0xB	35 0x62	0x0A	0x0B	28		see below CK	(_A CK_B			
Payload Conte	nts:											
Byte Offset	Numb Forma		Scaling	Name			Unit	Description				
0	1		-	ofsl	[-	Imbalance of I-part of complex signa	al. scaled			
Ŭ								(-128 = max. negative imbalance, 127 = max.				
								positive imbalance)				
1	U1		-	magl	[-	Magnitude of I-part of complex sign	al, scaled (0			
								= no signal, 255 = max. magnitude)	ıl, 255 = max. magnitude)			
2	1		-	ofsÇ	2	-		Imbalance of Q-part of complex signal, scaled				
								(-128 = max. negative imbalance, 127 = max.				
								positive imbalance)				
3	U1		-	magÇ	2		-	Magnitude of Q-part of complex signal, scaled				
								(0 = no signal, 255 = max. magnitude)				
4	U1		-	cfgS	Source	е	-	5	Source of low-level configuration			
								(114 = ROM, 111 = OTP, 112 = con	tig pins, 102			
-		1						= flash image)				
5	U1[3]	-		erved		-	Reserved	1 11			
8	U4		-	IwoL	levCf	g	-	Low-level configuration (obsolete, only use this				
								field if the message MON-LLC is not	avaliable in			
12	111[0	1		2000		<u></u>		your receiver) Reserved				
20	U1[8	1	-		erved: Stati		-	POST status word				
20		1	-	-	erved		-	Reserved				
24	U1[4	.1	-	rese	erved	3	-	NESEIVEU				



21.15.3 UBX-MON-HW (0x0A 0x09)


21.15.3.1 Hardware Status

Message		MON-HW										
Description		Hardware	Status									
Firmware		Supported	on:									
		• u-blox N	8 from	firmwa	are vers	ion 2.00) up to version 2.30					
Туре		Periodic/Po	lled									
Comment		Status of di	fferent	aspect	of the	hardwa	re, such as Antenna, Pl	O/Peripheral	Pins, Noise			
		Level, Auto	matic G	ain Co	ntrol (A							
		Header	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	0xB5 0x62	0x0A	0x09	60			see below	CK_A CK_B			
Payload Conte	nts:		1									
Byte Offset	Numbe Format		Name			Unit	Description					
0	X4	-	pins	Sel		-	Mask of Pins Set as	Peripheral/PI	0			
4	X4	-	-	Bank		-	Mask of Pins Set as		0			
8	X4	-	pinI			-	Mask of Pins Set as		t			
12	X4	-	 pin\			-	Mask of Pins Value					
16	U2	-	nois	sePer	MS	-	Noise Level as meas	sured by the	GPS Core			
18	U2	-	agc	Int		-	AGC Monitor (coun	nts SIGHI xor	SIGLO, range 0			
							to 8191)					
20	U1	-	aSta	atus		-	Status of the Anten	na Superviso	r State Machine			
							(0=INIT, 1=DONTKN	NOW, 2=0K,	3=SHORT,			
							4=OPEN)					
21	U1	-	aPov	ver		-	Current PowerStatu	is of Antenna	a (0=OFF, 1=ON,			
							2=DONTKNOW)					
22	X1	-	flag	-		-	Flags (see graphic b	elow)				
23	U1	-		erved	1	-	Reserved		-) (internal Dire			
24	X4	-	used	lMask		-	Mask of Pins that a	re used by th	e virtual Pin			
28	U1[1]	71 -	VP				Manager Array of Pin Mappir	ar for oach	of the 17			
20		/] -	VP			-	Physical Pins	igs for each	Ji the T7			
45	U1	-	jam]	Ind		-	CW Jamming indica	ator scaled (() = no CW			
	Jami				jamming, 255 = stro							
46	U1[2]	-	rese	erved	2	-	Reserved	j				
48	X4	-	pin			-	Mask of Pins Value	using the PIC) Irq			
52	X4	-	pull			-	Mask of Pins Value					
							Resistor					
56	X4	-	pull	pullL			Mask of Pins Value using the PIO Pull Low					
							Resistor					



Bitfield flags

This Graphic explains the bits of flags



signed value unsigned value

reserved

Description
RTC is calibrated
safeBoot mode (0 = inactive, 1 = active)
output from Jamming/Interference Monitor (0 = unknown or feature disabled, 1 = ok - no significant jamming, 2
= warning - interference visible but fix OK, 3 = critical - interference visible and no fix)
RTC xtal has been determined to be absent. (not supported in protocol versions less than 18)

21.15.4 UBX-MON-IO (0x0A 0x02)

21.15.4.1 I/O Subsystem Status

Message		м	ON-IO	N-IO										
Description		I/O	Subsyst	tem St	atus									
Firmware		Sup	oported c	n:										
		u-blox M8 from firmware version 2.00 up to version 2.30												
Туре		Periodic/Polled												
Comment		The	e size of t	he mes	sage is	deterr	nined by	the number of port	ts 'N' the receiv	ver supports, i.e.				
		on u-blox 5 the number of ports is 6.												
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum				
Message Structu	ıre	OxE	35 0x62	0x0A	0x02	0 + 20)*N	see below	СК_АСК_В					
Payload Content	ts:			•		•								
Byte Offset	Numb	ber	Scaling	Name			Unit	Description						
	Forma	ət												
Start of repeated	d block	(N tin	nes)											
N*20	U4		-	rxBy	rtes		bytes	Number of bytes	ever received					
4 + 20*N	U4		-	txBy	rtes		bytes	Number of bytes ever sent						
8 + 20*N	U2		-	pari	tyEr	rs	-	Number of 100m	s timeslots with	n parity errors				
10 + 20*N	U2		-	fram	ningE	rrs	-	Number of 100m	s timeslots with	n framing errors				
12 + 20*N	U2		-	over	runE	rrs	-	Number of 100m						
14 + 20*N	U2		-	brea	akCono	d	-	Number of 100m	s timeslots with	n break				
								conditions						
16 + 20*N	U1		-	rxBu	ısy		-	Flag is receiver is						
17 + 20*N	U1		-	txBu	-		-	Flag is transmitter	r is busy					
18 + 20*N	U1[2	2]	-	rese	erved	1	-	Reserved						
End of repeated	block													



21.15.5 UBX-MON-MSGPP (0x0A 0x06)

21.15.5.1 Message Parse and Process Status

Message		МС	ON-MSGPP										
Description		Me	essage P	arse ar	nd Pro	cess St	atus						
Firmware			upported on:										
		• l	u-blox M	8 from	up to version 2.30								
Туре		Per	iodic/Pol	ed									
Comment		-			-				-				
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	0xE	35 0x62	0x0A	0x06	120			see below	СК_А СК_В			
Payload Conte	nts:												
Byte Offset	Numb	er	Scaling	Name			Unit	Description					
	Forma	nt											
0	U2[8]	-	msg1	L		msgs	Number of successfull	y parsed m	nessages for			
								each protocol on port	0				
16	U2[8]	-	msg2	2		msgs	Number of successfull		nessages for			
								each protocol on port	1				
32	U2[8]	-	msg3	3		msgs	Number of successfull	y parsed m	nessages for			
								each protocol on port	2				
48	U2[8]	-	msg4	ł		msgs	Number of successfull	y parsed m	nessages for			
								each protocol on port	3				
64	U2[8]	-	msg5	5		msgs	Number of successfull	y parsed m	nessages for			
								each protocol on port	4				
80	U2[8]	-	msge	5		msgs	Number of successfull	y parsed m	nessages for			
								each protocol on port	5				
96	U4[6	4[6] - skipped					bytes	Number skipped bytes	s for each	port			

21.15.6 UBX-MON-PATCH (0x0A 0x27)

21.15.6.1 Poll Request for installed patches

Message	MON-PATC	Н				
Description	Poll Reques	st for i	nstalle	ed patches		
Firmware	Supported c	n:				
	• u-blox M8	3 from ⁻	firmwa	are version 2.00 up to version 2.30		
Туре	Poll Request					
Comment	-					
	Header	Class	ID	Length (Bytes)	Payload	Checksum
Message Structure	0xB5 0x62	0x0A	0x27	0	see below	CK_A CK_B
No payload	·	•	•	•	•	



Message		М	ON-PATCH										
Description		Ou	Output information about installed patches.										
Firmware			oported c										
		• (u-blox M8	3 from firmware version 2.00 up to version 2.30									
Туре		Ou	tput Mes	sage									
Comment		-	-										
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struct	ure	OxE	35 0x62	0x0A	0x27	4 + 16	es	see below	СК_АСК_В				
Payload Conten	ts:												
Byte Offset	Numl	ber	Scaling	Name			Unit	Description					
	Form	at											
0	U2		-	version			-	Type of the message.	0x1 for thi	s one.			
2	U2		-	nEnt	ries		-	The number of patches that is output.					
Start of repeate	d block	(nEnt	ries times)										
4 + 16*N	X4		-	pato	chInf	C	-	Additional information	h about the	e patch not			
								stated in the patch he	ader. (see	graphic below)			
8 + 16*N	U4		-	comp	parato	orNum	-	The number of the co	mparator.				
		ber											
12 + 16*N	U4		-	pato	hAdd	Address - The address that the targeted by the patch.							
16 + 16*N	U4		-	pato	chData	a	-	The data that will be i	nserted at	the			
								patchAddress.					
End of repeated	l block												

21.15.6.2 Output information about installed patches.

Bitfield patchInfo

This Graphic explains the bits of patchInfo

														2	1	0
														location		activated

■ signed value ■ unsigned value ■ reserved

_ reserved	
Name	Description

Name	Description	
activated	1: the patch is active. 0: otherwise.	
location	Indicates where the patch is stored. 0: eFuse, 1: ROM, 2: BBR, 3: file system.	



21.15.7 UBX-MON-RXBUF (0x0A 0x07)

21.15.7.1 Receiver Buffer Status

Message		мо	ON-RXBU	F											
Description		Ree	eceiver Buffer Status												
Firmware		Sup	oported o	on:											
		•ι	u-blox M8	from	firmwa	ire versi	on 2.00	up to version 2.30							
Туре		Per	riodic/Polled												
Comment		-													
		Hea	der	Class	ID	Length	Checksum								
Message Struct	35 0x62	0x0A	0x07	24			see below	CK_A CK_B							
Payload Conter	nts:					•			•						
Byte Offset	Numl	ber	Scaling	Name			Unit	Description							
	Forma	ət													
0	U2[6	5]	-	pend	ling		bytes	Number of bytes pend	ling in rece	eiver buffer for					
								each target							
12	U1[6	5]	-	usag	le		%	Maximum usage receiv	ver buffer	during the last					
								sysmon period for eac	h target						
18	U1[6	5]	-	peak	Usage	е	%	Maximum usage receiv	ver buffer	for each target					

21.15.8 UBX-MON-RXR (0x0A 0x21)

21.15.8.1 Receiver Status Information

Message		М	ON-RXR											
Description		Re	ceiver St	atus In	forma	ation								
Firmware		Sup	oported o	n:										
		• (u-blox M8 from firmware version 2.00 up to version 2.30											
Туре	Output													
Comment		The	The receiver ready message is sent when the receiver changes from or to backup mode.											
		Hea	der	Class	Class ID Length					Payload	Checksum			
Message Struct	ture	OxE	35 0x62	0x0A	0x21	1 see below CK_A								
Payload Conter	nts:													
Byte Offset Number Scaling Name Unit Descripti							Description							
	Form	at												
0	X1		-	flag	s		-	Receiver stat	us flags (s	ee graphic	: below)			

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description
awake	not in Backup mode




21.15.9 UBX-MON-SMGR (0x0A 0x2E)

21.15.9.1 Synchronization Manager Status

Message		MON-SMGR										
Description		Synchronization Manager Status										
Firmware		 Supported on: u-blox M8 from firmware version 2.20 up to version 2.30 (only available with FTS product variant) 										
Туре		Output		-,								
Comment		This message reports the status of internal and external oscillators and sources as well as whether GNSS is used for disciplining.										
		Header	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	cture	0xB5 0x62	0x0A	0x2E	16			see below	CK_A CK_B			
Payload Conte	ents:				•			•	•			
Byte Offset	Numb Forma		Name			Unit	Description					
0	U1	-	vers	sion		-	Message version (0 fo) for this version)				
1	U1[3] -	rese	erved	1	-	Reserved					
4	U4	-	iTOV	N		ms	Time of the week					
8	X2	-	int(Dsc		-	A bit mask, indicating oscillator (see graphic	ting the status of the local phic below)				
10	X2	-	ext(Dsc		-	A bit mask, indicating oscillator (see graphic		of the external			
12	U1	-	diso	discSrc		-	Disciplining source ide 0: internal oscillator 1: GNSS 2: EXTINTO 3: EXTINT1 4: internal oscillator m 5: external oscillator n	entifier: neasured b	•			
13	X1	-	gnss	gnss			A bit mask, indicating (see graphic below)	A bit mask, indicating the status of the GNSS (see graphic below)				
14	X1	-	extI	Int0		-	A bit mask, indicating input 0 (see graphic b	elow)				
15	X1	-	extl	Int1		-	A bit mask, indicating input 1 (see graphic b		of the external			

Bitfield intOsc

This Graphic explains the bits of intOsc






Bitfield intOsc Description continued

Name	Description						
Name	Description						
intOscState	State of the oscillator:						
	0: autonomous operation						
	1: calibration ongoing						
	2: oscillator is steered by the host						
	3: idle state						
intOscCalib	1 = oscillator gain is calibrated						
intOscDisc	1 = signal is disciplined						

Bitfield extOsc

This Graphic explains the bits of extOsc




■ signed value ■ unsigned value ■ reserved

Name	Description
ext0scState	State of the oscillator:
	0: autonomous operation
	1: calibration ongoing
	2: oscillator is steered by the host
	3: idle state
ext0scCalib	1 = oscillator gain is calibrated
ext0scDisc	1 = signal is disciplined

Bitfield gnss

This Graphic explains the bits of gnss




Name	Description
gnssAvail	1 = GNSS is present



Bitfield extInt0

This Graphic explains the bits of extInt0



■ signed value ■ unsigned value ■ reserved

Name	Description
extInt0Avail	1 = signal present at this input
extInt0Type	Source type:
	0: frequency
	1: time
extInt0FeedBa	This source is used as feedback of the external oscillator
ck	

Bitfield extInt1

This Graphic explains the bits of extInt1



■ signed value ■ unsigned value ■ reserved

Name	Description
extInt1Avail	1 = signal present at this input
extInt1Type	Source type:
	0: frequency
	1: time
extInt1FeedBa	This source is used as feedback of the external oscillator
ck	




21.15.10 UBX-MON-TXBUF (0x0A 0x08)

21.15.10.1 Transmitter Buffer Status

Message	age MON-TXBUF										
Description		Tra	nsmitte	r Buffe	er Stat	us					
Firmware	Sup	Supported on:									
u-blox M8 from firmware version 2.00 up to version 2.30											
Туре		Per	iodic/Poll	ed							
Comment		-									
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	OxE	35 0x62	0x0A	0x08	28			see below	СК_АСК_В	
Payload Conte	nts:										
Byte Offset	Numb	ber	Scaling	Name			Unit	Description			
	Forma	ət									
0	U2[6	5]	-	pend	pending		bytes	Number of bytes pending in transmitter buffer for each target			
12	U1[6	5]	-	usage				Maximum usage trans		-	
								last sysmon period for each target			
18	U1[6	5]	-	peak	peakUsage		%	Maximum usage transmitter buffer for each		fer for each	
24	U1			tIlda	tUsage			target Maximum usage of transmitter buffer during			
				0.50	ige		%	-	the last sysmon period for all targets		
25	U1		-	tPea	kusag	ge	%	Maximum usage of tr		-	
								targets			
26	X1		-	erro	ors		-	Error bitmask (see graphic below)			
27	U1		-	rese	erved	1	-	Reserved			

Bitfield errors

This Graphic explains the bits of errors



Name	Description						
limit	Buffer limit of corresponding target reached						
mem	Memory Allocation error						
alloc	Allocation error (TX buffer full)						



21.15.11 UBX-MON-VER (0x0A 0x04)

21.15.11.1 Poll Receiver/Software Version

Message	MON-VER	MON-VER											
Description	Poll Receiv	Poll Receiver/Software Version											
Firmware	Supported of	Supported on:											
	• u-blox M8	 u-blox M8 from firmware version 2.00 up to version 2.30 											
Туре	Poll Request	Poll Request											
Comment	-												
	Header	Class	ID	Length (Bytes)	Payload	Checksum							
Message Structure	0xB5 0x62	0x0A	0x04	0	see below	CK_A CK_B							
No payload	1				•	1							

21.15.11.2 Receiver/Software Version

Message	age MON-VER											
Description		Receiver/Software Version										
Firmware		Sup	Supported on:									
u-blox M8 from firmware version 2.00 up to version 2.30												
Туре		An	Answer to Poll									
Comment		-										
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum		
Message Struct	ure	OxE	35 0x62	0x0A	0x04	40 + 3	30*N		see below	CK_A CK_B		
Payload Conten	ts:					•			•			
Byte Offset	Numb	per	Scaling	Name			Unit	Description				
	Forma	ət										
0	CH[3	30]	-	swVe	ersio	n	-	Zero-terminated Softv	terminated Software Version String.			
30	CH[1	10]	-	hwVe	ersio	n	-	Zero-terminated Hardware Version String				
Start of repeate	d block	(N tin	nes)									
40 + 30*N	CH[3	30]	-	extension			-	Extended receiver/software information.				
								If the receiver's firmw	are is runn	ing from flash,		
								the first extension fiel	d will conta	ain the Software		
								Version String of the u	underlying	ROM.		
								Additional fields may	also indica [.]	te the		
								supported protocol ve	ersion and a	any product		
								variants, capabilities o	r extensior	IS.		
End of repeated	l block											



21.16 UBX-NAV (0x01)

Navigation Results: i.e. Position, Speed, Time, Acceleration, Heading, DOP, SVs used. Messages in the NAV Class output Navigation Data such as position, altitude and velocity in a number of formats. Additionally, status flags and accuracy figures are output.


21.16.1 UBX-NAV-AOPSTATUS (0x01 0x60)

21.16.1.1 AssistNow Autonomous Status

Message		NA	NAV-AOPSTATUS									
Description		Ass	istNow /	Auton	omou	s Statu	S					
Firmware		Sup	ported o	n:								
		• u	-blox M8	from	firmwa	re versi	on 2.00 (up to version 2.30				
Туре		Perio	Periodic/Polled									
Comment This message provides information on the status of the AssistNow Autonomous subsy								<i>ous</i> subsystem				
		on t	he receiv	er. For	examp	ole, a h	ost applic	ation can determine the	e optimal t	time to shut		
		dow	n the rea	ceiver k	oy mor	nitoring	the sta	tus field for a steady 0.	See the c	hapter		
		Assi	stNow A	utonor	nous ir	n the re	ceiver de	scription for details on t	his feature	2.		
	ler	Class	ID	Length	(Bytes)		Checksum					
Message Struc	ture	0xB	5 0x62	0x01	0x01 0x60 16				see below	CK_A CK_B		
Payload Conte	nts:				•							
Byte Offset	Numl	ber	Scaling	Name		Un		Description				
	Forma	at										
0	U4		-	iTOW	itow		ms	GPS time of week of the navigation epoch.				
								See the description of iTOW for details.				
4	U1		-	aopC	fg		-	AssistNow Autonomous configuration (see				
								graphic below)				
5	5 U1 -		stat	status			AssistNow Autonomous subsystem is idle (0) or					
							running (not 0)					
6	U1[1	0]	-	rese	erved	1	-	Reserved				

Bitfield aopCfg

This Graphic explains the bits of aopCfg



Name	Description
useAOP	AOP enabled flag



21.16.2 UBX-NAV-CLOCK (0x01 0x22)

21.16.2.1 Clock Solution

Message		NA	V-CLOCH	(
Description		Clo	Clock Solution								
Firmware		Sup	Supported on:								
	 u-blox M8 from firmware version 2.00 up to version 2.30 										
Туре		Per	Periodic/Polled								
Comment		-									
		Hea	eader Class ID Length (Bytes)				Payload	Checksum			
Message Struc	ture	0xB5 0x62		0x01	0x22	20 see below CK_A CK_			СК_АСК_В		
Payload Conte	nts:			•		•			•		
Byte Offset	Numl		Scaling	Name			Unit	Description	Description		
	Forma	at									
0	U4		-	itow	I		ms	GPS time of week of the navigation epoch.		ion epoch.	
								See the description of	iTOW for	details.	
4	14		-	clkE	3		ns	Clock bias	Clock bias		
8	14		-	clkI	clkD		ns/s	Clock drift			
12	U4		-	tAcc			ns	Time accuracy estimate			
16	U4		-	fAcc	!		ps/s	Frequency accuracy estimate			

21.16.3 UBX-NAV-DGPS (0x01 0x31)

21.16.3.1 DGPS Data Used for NAV

Message		NA	V-DGPS									
Description		DG	iPS Data	Used f	for NA	V						
Firmware		Sup	oported c	n:	1:							
		• (u-blox M8	3 from	firmwa	ire versi	on 2.00	up to version 2.30				
Туре		Per	iodic/Poll	ed								
Comment		Thi	s messag	e outpi	uts the	DGPS	correctio	on data that has been a	pplied to the	e current NAV		
		Sol	ution. Se	e also t	he not	es on th	ne RTCN	1 protocol.				
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum		
Message Struct	ture	OxE	35 0x62	0x01	0x31	16 + 1	2*num	Ch	see below	CK_A CK_B		
Payload Conter	nts:			•	•							
Byte Offset	Num	ber	ber Scaling		Name		Unit	Description	Description			
	Form	at										
0	U4		-	itov	itow		ms	GPS time of week of the navigation epoch.				
								See the description of iTOW for details.				
4	14		-	age			ms	-	Age of newest correction data			
8	12		-	base	eId		-	DGPS base station identifier				
10	12		-	base	Heal	th	-	DGPS base station h	DGPS base station health status			
12	U1		-	numC	lh		-	Number of channels	for which c	orrection data is		
								following				
13	U1		-	stat	us		-	DGPS correction type	e status:			
								0x00: none				
								0x01: PR+PRR corre	ction			
14	U1[2	2]	-	rese	erved	1	-	Reserved				




NAV-DGPS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
Start of repeated	d block (num	nCh times)			
16 + 12*N	U1	-	svid	-	Satellite ID
17 + 12*N	X1	-	flags	-	Channel number and usage (see graphic below)
18 + 12*N	U2	-	ageC	ms	Age of latest correction data
20 + 12*N	R4	-	prc	m	Pseudorange correction
24 + 12*N	R4	-	prrc	m/s	Pseudorange rate correction
End of repeated	block				

Bitfield flags

This Graphic explains the bits of flags



Name	Description
channel	GPS channel number this SV is on
dgpsUsed	1 = DGPS used for this SV

21.16.4 UBX-NAV-DOP (0x01 0x04)

21.16.4.1 Dilution of precision

Message		NA	NAV-DOP								
Description		Dil	Dilution of precision								
Firmware		Sup	oported o	n:							
		• (u-blox M8	from	firmwa	re versi	on 2.00	up to version 2.30			
Туре		Per	Periodic/Polled								
Comment • DOP values are dimensionless.											
		• /	All DOP va	alues a	re scale	ed by a	factor c	of 100. If the unit trans	smits a value	of e.g. 156, the	
		DOP value is 1.56.									
		Hea	der	Class ID Length (Bytes) Payload Checksun						Checksum	
Message Struc	ture	0xB5 0x62 0x01 0x04 18				see below	CK_A CK_B				
Payload Conte	nts:								·		
Byte Offset	Numb	ber	Scaling	Name	Vame		Unit	Description	Description		
	Form	ət									
0	U4		-	iTOW	1		ms	GPS time of week of	GPS time of week of the navigation epoch.		
								See the description	of iTOW for	details.	
4	U2		0.01	gDOE	<u>p</u>		-	Geometric DOP			
6	U2		0.01	pDOE	þ		-	Position DOP			
8	U2		0.01	1 tdop		-	Time DOP	Time DOP			
10	U2		0.01	VDOE	>		-	Vertical DOP	Vertical DOP		
12	U2		0.01	hDOF	>		-	Horizontal DOP			



NAV-DOP continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
14	U2	0.01	nDOP	-	Northing DOP
16	U2	0.01	eDOP	-	Easting DOP

21.16.5 UBX-NAV-ODO (0x01 0x09)

21.16.5.1 Odometer Solution

Message		NA	V-ODO								
Description		Od	Odometer Solution								
Firmware		Sup	Supported on:								
		•ι	u-blox M8	from ⁻	firmwa	re versi	on 2.00	up to version 2.30			
Туре		Per	eriodic/Polled								
Comment		Thi	s message	e outpu	uts the	travele	d distanc	e since last reset (see NA	V-RESET	ODO) together	
with an associated estimated accuracy and the total cumulated ground distance							ance (can only				
		be	be reset by a cold start of the receiver).								
		Header Class ID Length (Bytes) Payload					Checksum				
Message Struct	lessage Structure 0xB5 0x62			0x01	0x09	20 see below CK_A CK_B				CK_A CK_B	
Payload Conter	nts:										
Byte Offset	Numb	ber	Scaling	Name	Name		Unit	Description			
	Forma	ət									
0	U1		-	vers	ion		-	Message version (0 for	Message version (0 for this version)		
1	U1[3	8]	-	rese	erved	L	-	Reserved	Reserved		
4	U4		-	iTOW	I		ms	GPS time of week of t	GPS time of week of the navigation epoch.		
								See the description of	iTOW for	details.	
8	U4		-	dist	ance		m	Ground distance since	Ground distance since last reset		
12	U4		-	tota	lDist	ance	m	Total cumulative grour	Total cumulative ground distance		
16	U4		-	dist	ances	Std	m	Ground distance accur	racy (1-sigi	ma)	

21.16.6 UBX-NAV-ORB (0x01 0x34)

21.16.6.1 GNSS Orbit Database Info

Message		NA	V-ORB								
Description		GN:	GNSS Orbit Database Info								
Firmware	upported on:										
		 u-blox M8 from firmware version 2.00 up to version 2.30 									
Туре		Peri	odic/Poll	ed							
Comment		Stat	tus of the	GNSS	orbit c	latabas	e know	ledge.			
Header			Class	ID	Length (Bytes) Payload Checksul				Checksum		
Message Struc	ture	0xB	5 0x62	0x01	0x34	8 + 6*numSv see below CK_A CH				CK_A CK_B	
Payload Conte	nts:					•			ł		
Byte Offset	Num	ber	Scaling	Name	Name		Unit	Description			
	Form	at									
0	U4		-	iTOW	itow		ms	GPS time of we	GPS time of week of the navigation epoch.		
								See the description of iTOW for details.			
4	U1		-	vers	version			Message version (0, for this version)			




NAV-ORB continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
5	U1	-	numSv	-	Number of SVs in the database
6	U1[2]	-	reserved1	-	Reserved
Start of repeat	ed block (nur	nSv times)		•	
8 + 6*N	U1	-	gnssId	-	GNSS ID
9 + 6*N	U1	-	svId	-	Satellite ID
10 + 6*N	X1	-	svFlag	-	Information Flags (see graphic below)
11 + 6*N	X1	-	eph	-	Ephemeris data (see graphic below)
12 + 6*N	X1	-	alm	-	Almanac data (see graphic below)
13 + 6*N	X1	-	otherOrb	-	Other orbit data available (see graphic below)

Bitfield svFlag

This Graphic explains the bits of svFlag



Name	Description
health	SV health:
	0: unknown
	1: healthy
	2: not healty
visibility	SV health:
	0: unknown
	1: below horizon
	2: above horizon
	3: above elevation mask

Bitfield eph

This Graphic explains the bits of eph






Bitfield eph Description continued

Name	Description							
ephUsability	How long the receiver will be able to use the stored ephemeris data from now on:							
	1: The usability period is unknown							
	30: The usability period is more than 450 minutes							
	30 > n > 0: The usability period is between (n-1)*15 and n*15 minutes							
	0: Ephemeris can no longer be used							
ephSource	0: not available							
	1: GNSS transmission							
	2: external aiding							
	3-7: other							

Bitfield alm

This Graphic explains the bits of alm



Bitfield otherOrb

This Graphic explains the bits of otherOrb





Bitfield otherOrb Description continued

Name	Description
anoAopUsabili	How long the receiver will be able to use the orbit data from now on:
ty	31: The usability period is unknown
	30: The usability period is more than 30 days
	30 > n > 0: The usability period is between n-1 and n days
	0: Data can no longer be used
type	Type of orbit data:
	0: No orbit data available
	1: Assist now offline data
	2: Assist now autonomous data
	3-7: Other orbit data

21.16.7 UBX-NAV-POSECEF (0x01 0x01)

21.16.7.1 Position Solution in ECEF

Message		NAV-POSECEF												
Description		Pos	sition So	lution	in ECE	F								
Firmware		Sup	oported o	n:										
		 ι 	u-blox M8	3 from	firmwa	re versi	on 2.00	up to version 2.30						
Туре		Per	iodic/Polle	z/Polled										
Comment			ee important comments concerning validity of position given in section avigation Output Filters.											
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum				
Message Struc	ture	OxE	35 0x62	0x01	0x01	20			see below	СК_АСК_В				
Payload Conte	nts:			•	•				•					
Byte Offset	Numb Forma		Scaling	Name			Unit	Description						
0	U4		-	itov	1		ms	GPS time of week of See the description o	-					
4	14	- ecefX					cm	ECEF X coordinate						
8	14		-	ecefY				ECEF Y coordinate						
12	14		-	ecefZ			cm	ECEF Z coordinate						
16	U4	l - pAcc cm					cm	Position Accuracy Estimate						



21.16.8 UBX-NAV-POSLLH (0x01 0x02)

21.16.8.1 Geodetic Position Solution

Message		NAV-POSLLH															
Description		Ge	odetic Po	sition	Solut	ion											
Firmware		Su	oported o	n:													
		• 1	u-blox M8	from	firmwa	re versi	on 2.00	up to version 2.30									
Туре		Per	iodic/Polle	ed													
Comment		See important comments concerning validity of position given in section Navigation Output Filters. This message outputs the Geodetic position in the currently selected ellipsoid. The default is the WGS84 Ellipsoid, but can be changed with the message CFG-DAT.															
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum							
Message Struc	ture	0xE	35 0x62	0x01	0x02	28			see below	CK_A CK_B							
Payload Conte	nts:																
Byte Offset	Num Form		Scaling	Name			Unit	Description									
0	U4		-	itov	1		ms	GPS time of week of the navigation epoch.									
								See the description of iT		details.							
4	4		1e-7	lon			deg	Longitude									
8	14	le-7 lat deg Latitude															
12	14		-	heig	ht		mm	Height above ellipsoid	1								
16	14		-	hMSI	1		mm	Height above mean se	ea level								
20	U4		-	hAcc	!		mm	Horizontal accuracy e	stimate								
24	U4		-	vAcc	:		mm	Vertical accuracy estimate									

21.16.9 UBX-NAV-PVT (0x01 0x07)

21.16.9.1 Navigation Position Velocity Time Solution

Message		NAV-PVT												
Description		Na	vigation	Positi	on Vel	ocity T	ime Solı	ıtion						
Firmware		Su	oported o	n:										
		• 1	 u-blox M8 from firmware version 2.00 up to version 2.30 											
Туре		Per	riodic/Poll	ic/Polled										
Comment		No	te that d	luring	a leap	secon	d there r	nay be more (or less)	than 60 s	seconds in a				
		minute; see the description of leap seconds for details.												
		Thi	is message	e comb	oines po	osition,	velocity a	and time solution, includ	ding accur	acy figures				
		Hea	nder	Class	ID	Length	(Bytes)		Payload	Checksum				
Message Struct	ure	0x8	35 0x62	0x01	0x07	92	СК_АСК_В							
Payload Conter	nts:				•	•			•	•				
Byte Offset	Num	ber	Scaling	Name			Unit	Description						
	Form	at												
0	U4		-	iTOW	V		ms	GPS time of week of the navigation epoch						
								See the description of	iTOW for	details.				
4	U2		-	year	2		у	Year (UTC)						
6	U1		-	mont	h		month	Month, range 112 (UTC)						
7	U1		-	day			d	Day of month, range 131 (UTC)						




NAV-PVT continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
8	U1	-	hour	h	Hour of day, range 023 (UTC)
9	U1	-	min	min	Minute of hour, range 059 (UTC)
10	U1	-	sec	S	Seconds of minute, range 060 (UTC)
11	X1	-	valid	-	Validity Flags (see graphic below)
12	U4	-	tAcc	ns	Time accuracy estimate (UTC)
16	14	-	nano	ns	Fraction of second, range -1e9 1e9 (UTC)
20	U1	-	fixType	-	GNSSfix Type, range 05
					0x00 = No Fix
					0x01 = Dead Reckoning only
					0x02 = 2D-Fix
					0x03 = 3D-Fix
					0x04 = GNSS + dead reckoning combined
					0x05 = Time only fix
					0x060xff: reserved
21	X1	-	flags	-	Fix Status Flags (see graphic below)
22	U1	-	reserved1	-	Reserved
23	U1	-	numSV	-	Number of satellites used in Nav Solution
24	14	1e-7	lon	deg	Longitude
28	14	1e-7	lat	deg	Latitude
32	14	-	height	mm	Height above ellipsoid
36	14	-	hMSL	mm	Height above mean sea level
40	U4	-	hAcc	mm	Horizontal accuracy estimate
44	U4	-	vAcc	mm	Vertical accuracy estimate
48	14	-	velN	mm/s	NED north velocity
52	14	-	velE	mm/s	NED east velocity
56	14	-	velD	mm/s	NED down velocity
60	14	-	gSpeed	mm/s	Ground Speed (2-D)
64	14	1e-5	headMot	deg	Heading of motion (2-D)
68	U4	-	sAcc	mm/s	Speed accuracy estimate
72	U4	1e-5	headAcc	deg	Heading accuracy estimate (both motion and vehicle)
76	U2	0.01	pDOP	_	Position DOP
78	U1[6]		reserved2	-	Reserved
84	14	- 1e-5	headVeh	deg	Heading of vehicle (2-D)
88	U1[4]	1	reserved3	uey	Reserved



Bitfield valid

This Graphic explains the bits of valid




■ signed value ■ unsigned value ■ reserved

Name	Description
validDate	1 = Valid UTC Date
validTime	1 = Valid UTC Time of Day
fullyResolved	1 = UTC Time of Day has been fully resolved (no seconds uncertainty)

Bitfield flags

This Graphic explains the bits of flags



signed value unsigned value reserved

Name	Description							
gnssFixOK	A valid fix (i.e within DOP & accuracy masks)							
diffSoln	if differential corrections were applied							
psmState	Power Save Mode state (see Power Management):							
	0 = n/a (i.e no PSM is active)							
	1 = ENABLED (an intermediate state before ACQUISITION state							
	2 = ACQUISITION							
	3 = TRACKING							
	4 = POWER OPTIMIZED TRACKING							
	5 = INACTIVE							
headVehValid	Heading of vehicle is valid							



21.16.10 UBX-NAV-RESETODO (0x01 0x10)

21.16.10.1 Reset odometer

Message	NAV-RESET	ODO								
Description	Reset odon	Reset odometer								
Firmware	Supported o	n:								
	• u-blox M8	B from ⁻	firmwa	re version 2.00 up to version 2.30						
Туре	Command	Command								
Comment	This message	e resets	s the tr	aveled distance computed by the odom	eter (see U	BX-NAV-ODO).				
	UBX-ACK-A	CK or	UBX-A	CK-NAK are returned to indicate succes	s or failure	2.				
	Header	Class	ID	Length (Bytes)	Payload	Checksum				
Message Structure	0xB5 0x62	0x01	0x10	0	see below	CK_A CK_B				
No payload	·	•			•					

21.16.11 UBX-NAV-SAT (0x01 0x35)

21.16.11.1 Satellite Information

Message		NAV-SAT												
Description		Sat	tellite In	format	ion									
Firmware			ported c u-blox M8		firmwa	are versi	on 2.00	up to version 2.30						
Туре		Per	iodic/Poll	ed										
Comment			s messag rently tra	•	•		n about	SVs which are either kn	own to be	visible or				
		Hea	der	Class	ID	Length ((Bytes)		Payload	Checksum				
Message Struct	ure	OxE	35 0x62	0x01	0x35	8 + 12	*numSv	′S	see below	СК_АСК_В				
Payload Conter	Payload Contents:													
Byte Offset	Numb Forma		Scaling	Name			Unit	Description						
0	U4	J4 -		itov	itow			GPS time of week of the See the description of	-					
4	U1		-	vers	version			Message version (1 fo	or this version	on)				
5	U1		-	numSvs			-	Number of satellites						
6	U1[2]]	-	rese	erved	1	-	Reserved						
Start of repeate	ed block (i	num	Svs times)											
8 + 12*N	U1		-	gnss	sId		-	GNSS identifier (see S assignment	GNSS identifier (see Satellite numbering) for assignment					
9 + 12*N	U1		-	svić	1		-	Satellite identifier (see assignment	e Satellite n	umbering) for				
10 + 12*N	U1		-	cno			dBHz	Carrier to noise ratio	(signal stre	ngth)				
11 + 12*N	11		-	elev	7		deg	Elevation (range: +/-9 range	0), unknov	vn if out of				
12 + 12*N	12		-	azin	n		deg	Azimuth (range +/-18 out of range	0), unknov	vn if elevation is				
14 + 12*N	12		0.1	prRes			m	Pseudo range residua						
16 + 12*N	N X4 -			flag	js		-	Bitmask (see graphic below)						



NAV-SAT continued

,	Number Format	Scaling	Name	Unit	Description
End of repeated b	olock				

Bitfield flags

This Graphic explains the bits of flags

								14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
								aopĤvail	anoĤvail	almĤvail	ephĤvail	orbitSource			smoothed	diffCorr	health		svUsed	qualityInd		

■ signed value ■ unsigned value ■ reserved

Name	Description
qualityInd	Signal quality indicator:
	0: no signal
	1: searching signal
	2: signal aquired
	3: signal detected but unusable
	4: code locked and time synchronized
	5, 6, 7: code and carrier locked and time synchronized
	Note: Since IMES signals are not time synchronized, a channel tracking an IMES signal can never reach a quality
	indicator value of higher than 3.
svUsed	1 = SV is currently being used for navigation
health	SV health flag:
	0: unknown
	1: healthy
	2: unhealthy
diffCorr	1 = differential correction data is available for this SV
smoothed	1 = carrier smoothed pseudorange used
orbitSource	Orbit source:
	0: no orbit information is available for this SV
	1: ephemeris is used
	2: almanac is used
	3: AssistNow Offline orbit is used
	4: AssistNow Autonomous orbit is used
	5, 6, 7: other orbit information is used
ephAvail	1 = ephemeris is available for this SV
almAvail	1 = almanac is available for this SV
anoAvail	1 = AssistNow Offline data is available for this SV
aopAvail	1 = AssistNow Autonomous data is available for this SV



21.16.12 UBX-NAV-SBAS (0x01 0x32)


21.16.12.1 SBAS Status Data

Message		NAV-SBAS										
Description		SBAS Status Data										
Firmware		Supported on:										
		• u-blox M	8 from	firmwa	ire vers	ion 2.00) up to version 2.30					
Туре		Periodic/Pol	led									
Comment		This messag	ge outp	uts the	status	of the S	BAS sub system					
		Header	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struct	ure	0xB5 0x62	0x01	0x32	12 + 1	2*cnt		see below	CK_A CK_B			
Payload Conten	ts:				•							
Byte Offset	Numbe	er Scaling	Name			Unit	Description					
	Format	-										
0	U4	-	iTOV	N		ms	GPS time of week o	of the navigat	tion epoch.			
							See the description	-				
4	U1	-	geo			-	PRN Number of the					
							integrity data is use	d from				
5	U1	-	mode	e		-	SBAS Mode					
							0 Disabled					
							1 Enabled Integrity					
							3 Enabled Testmode					
6	11	-	sys	sys		-	SBAS System (WAA	S/EGNOS/)				
			_				-1 Unknown	,				
							0 WAAS					
							1 EGNOS					
							2 MSAS					
							16 GPS					
7	X1	-	serv	vice		-	SBAS Services available (see graphic below)					
8	U1	-	cnt			-	Number of SV data following					
9	U1[3]	-	rese	erved	1	-	Reserved					
Start of repeate	d block (d	nt times)										
12 + 12*N	U1	-	svio	đ		-	SV ID					
13 + 12*N	U1	-	flag	gs		-	Flags for this SV					
14 + 12*N	U1	-	udre	-		-	Monitoring status					
15 + 12*N	U1	-	svSy			-	System (WAAS/EGN	IOS/)				
							same as SYS					
16 + 12*N	U1	-	svSe	ervic	e	-	Services available					
							same as SERVICE					
17 + 12*N	U1	-	rese	erved	2	-	Reserved					
18 + 12*N	12	-	prc			cm	Pseudo Range corre	ection in [cm]				
20 + 12*N	U1[2]	-	rese	erved	3	-	Reserved					
22 + 12*N	12	-	ic			cm	lonosphere correcti					



Bitfield service

This Graphic explains the bits of service



21.16.13 UBX-NAV-SOL (0x01 0x06)

21.16.13.1 Navigation Solution Information

Message		NAV-SOL										
Description		Navigation Solution Information										
Firmware			Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30									
Туре		Periodic/Po	lled									
Comment		This message combines position, velocity and time solution in ECEF, including accuracy figures. This message has only been retained for backwards compatibility; users are recommended to use the UBX-NAV-PVT message in preference.										
		Header	Class	ID	Length	(Bytes)		Payload	Checksum			
Message Struc	ture	0xB5 0x62	0x01	0x06	52			see below	СК_АСК_В			
Payload Conte	nts:				1			4	I			
Byte Offset	Numb Forma		Name			Unit	Description					
0	U4	-	itov	V		ms	GPS time of week of the navigation epoch. See the description of iTOW for details.					
4	4 -		ftow	ftow		ns	Fractional part of iTOW (range: +/-500000). The precise GPS time of week in seconds is: (iTOW * 1e-3) + (fTOW * 1e-9)					
8	12	-	week	week		weeks	GPS week number of the navigation epoch					
10	U1	- week		-	GPSfix Type, range 0 0x00 = No Fix 0x01 = Dead Reckonir 0x02 = 2D-Fix 0x03 = 3D-Fix 0x04 = GPS + dead re 0x05 = Time only fix 0x060xff: reserved	ng only ckoning co						
11	X1	-	flag	js		-	Fix Status Flags (see gr	raphic belc	w)			
12	14	-	ecef	ecefX		cm	ECEF X coordinate					
16	14	-	ecef	ecefY		cm	ECEF Y coordinate					
20	14	-	ecef	ΞZ		cm		ECEF Z coordinate				
24	U4	-	pAcc	2		cm	3D Position Accuracy	Estimate				
28	14	-	ecef	TVX		cm/s	ECEF X velocity					
32	14	-	ecef	ĪΥΥ		cm/s	ECEF Y velocity					




NAV-SOL continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
36	14	-	ecefVZ	cm/s	ECEF Z velocity
40	U4	-	sAcc	cm/s	Speed Accuracy Estimate
44	U2	0.01	pDOP	-	Position DOP
46	U1	-	reserved1	-	Reserved
47	U1	-	numSV	-	Number of SVs used in Nav Solution
48	U1[4]	-	reserved2	-	Reserved

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description
GPSfixOK	1 = Fix within limits (e.g. DOP & accuracy)
DiffSoln	1 = DGPS used
WKNSET	1 = Valid GPS week number
TOWSET	1 = Valid GPS time of week (iTOW & fTOW)

21.16.14 UBX-NAV-STATUS (0x01 0x03)

21.16.14.1 Receiver Navigation Status

Message		NA	NAV-STATUS										
Description		Re	Receiver Navigation Status										
Firmware			ported o										
		• (a-plox M8	3 from	firmwa	ire versi	ion 2.00	up to	version 2.30				
Туре		Per	iodic/Polle	ed									
Comment		See	e importa	ant co	mmen	ts conc	erning	validit	ty of position a	and velocity	/ given in		
		sec	section Navigation Output Filters.										
		-	-										
		Hea	der	Class	ID	Length (Bytes)				Payload	Checksum		
Message Struc	ture	OxE	35 0x62	0x01	0x03	16				see below	CK_A CK_B		
Payload Conte	nts:	-											
Byte Offset	Num	ber	Scaling	Name			Unit	Descr	iption				
	Form	nat											
0	U4		-	itow	itow		ms	GPS	time of week o	f the navigat	tion epoch.		
								Seet	See the description of iTOW for details.				




NAV-STATUS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
4	U1	-	gpsFix	-	GPSfix Type, this value does not qualify a fix as valid and within the limits. See note on flag gpsFixOk below. 0x00 = no fix 0x01 = dead reckoning only
					0x02 = 2D-fix 0x03 = 3D-fix 0x04 = GPS + dead reckoning combined 0x05 = Time only fix 0x060xff = reserved
5	X1	-	flags	-	Navigation Status Flags (see graphic below)
6	X1	-	fixStat	-	Fix Status Information (see graphic below)
7	X1	-	flags2	-	further information about navigation output (see graphic below)
8	U4	-	ttff	-	Time to first fix (millisecond time tag)
12	U4	-	msss	-	Milliseconds since Startup / Reset

Bitfield flags

This Graphic explains the bits of flags




■ signed value ■ unsigned value ■ reserved

Name	Description
gpsFixOk	position and velocity valid and within DOP and ACC Masks, see also important comments in section Navigation
	Output Filters.
diffSoln	1 if DGPS used
wknSet	1 if Week Number valid
towSet	1 if Time of Week valid

Bitfield fixStat

This Graphic explains the bits of fixStat






Bitfield fixStat Description continued

Name	Description
dgpsIStat	DGPS Input Status
	0: none
	1: PR+PRR Correction
mapMatching	map matching status:
	00: none
	01: valid but not used, i.e. map matching data was received, but was too old
	10: valid and used, map matching data was applied
	11: valid and used, map matching data was applied. In case of sensor unavailability map matching data enables
	dead reckoning. This requires map matched latitude/longitude or heading data.

Bitfield flags2

This Graphic explains the bits of flags2



■ signed value ■ unsigned value ■ reserved

Name	Description					
psmState	power save mode state					
	0: ACQUISITION [or when psm disabled]					
	1: TRACKING					
	2: POWER OPTIMIZED TRACKING					
	3: INACTIVE					

21.16.15 UBX-NAV-SVINFO (0x01 0x30)

21.16.15.1 Space Vehicle Information

Message		NA	NAV-SVINFO									
Description		Spa	Space Vehicle Information									
Firmware		Sup	oported o	n:								
		• L	u-blox M8	3 from	firmwa	re versi	on 2.00 ι	p to version 2.30				
Туре		Per	iodic/Polle	ed								
Comment		Info	ormation	about	satellite	es used	or visible					
		Thi	This message has only been retained for backwards compatibility; users are recommended									
		to ı	use the 🖽	BX-NA	V-SAT	messa	ge in pret	ference.				
		Hea	der	Class	ID	Length (Bytes)			Payload	Checksum		
Message Struct	ure	OxE	35 0x62	0x01	0x30	8 + 12*numCh			see below	CK_A CK_B		
Payload Conten	ts:					•						
Byte Offset	Numl	ber	Scaling	Name			Unit	Description				
	Form	ət										
0	U4		-	itow		ms	GPS time of week of the navigation epoch.		ion epoch.			
							See the description of iTOW for details.		details.			
4	U1	-		numC	numCh		-	Number of channels				
5	X1		-	glok	balFla	ags	-	Bitmask (see graphic below)				



NAV-SVINFO continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
6	U1[2]	-	reserved1	-	Reserved
Start of repeate	d block (nun	nCh times)			
8 + 12*N	U1	-	chn	-	Channel number, 255 for SVs not assigned to a
					channel
9 + 12*N	U1	-	svid	-	Satellite ID, see Satellite numbering for
					assignment
10 + 12*N	X1	-	flags	-	Bitmask (see graphic below)
11 + 12*N	X1	-	quality	-	Bitfield (see graphic below)
12 + 12*N	U1	-	cno	dBHz	Carrier to Noise Ratio (Signal Strength)
13 + 12*N	1	-	elev	deg	Elevation in integer degrees
14 + 12*N	12	-	azim	deg	Azimuth in integer degrees
16 + 12*N	14	-	prRes	cm	Pseudo range residual in centimeters
End of repeated	l block				

Bitfield globalFlags

This Graphic explains the bits of globalFlags



unsigned value

Name	Description
chipGen	Chip hardware generation
	0: Antaris, Antaris 4
	1: u-blox 5
	2: u-blox 6
	3: u-blox 7
	4: u-blox M8

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description					
svUsed	SV is used for navigation					
diffCorr	Differential correction data is available for this SV					
orbitAvail	OrbitAvail Orbit information is available for this SV (Ephemeris or Almanac)					




Bitfield flags Description continued

Name	Description					
orbitEph	Orbit information is Ephemeris					
unhealthy	SV is unhealthy / shall not be used					
orbitAlm	Orbit information is Almanac Plus					
orbitAop	Orbit information is AssistNow Autonomous					
smoothed	Carrier smoothed pseudorange used					

Bitfield quality

This Graphic explains the bits of quality



signed value unsigned value reserved

Name	Description					
qualityInd	Signal Quality indicator (range 07). The following list shows the meaning of the different QI values:					
	0: no signal					
	1: searching signal					
	2: signal aquired					
	3: signal detected but unusable					
	4: code locked and time synchronized					
	5, 6, 7: code and carrier locked and time synchronized					
	Note: Since IMES signals are not time synchronized, a channel tracking an IMES signal can never reach a quality					
	indicator value of higher than 3.					

21.16.16 UBX-NAV-TIMEBDS (0x01 0x24)

21.16.16.1 BDS Time Solution

Message		NAV-TIMEBDS									
Description			BDS Time Solution								
Firmware		Supported on:									
• u-blox M8 firmware version 2.30					30						
Type Periodic/Polled											
Comment		This message reports the precise BDS time of the most recent navigation solution including validity flags and an accuracy estimate.									
		Hea	der	Class	ID	Length (Bytes)			Payload	Checksum	
Message Structure		OxE	35 0x62	0x01	0x24	20			see below	CK_A CK_B	
Payload Contents:											
Byte Offset	Num Form		Scaling	Name		Unit	Description				
0	U4		-	itow		ms		me of week of the navigation epoch. e description of iTOW for details.			
4	U4	-		SOW	SOW		S	BDS time of week (rounded to seconds)			




NAV-TIMEBDS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
8	14	-	fSOW	ns	Fractional part of SOW (range: +/-500000000).
					The precise BDS time of week in seconds is:
					SOW + fSOW * 1e-9
12	12	-	week	-	BDS week number of the navigation epoch
14	11	-	leapS	S	BDS leap seconds (BDS-UTC)
15	X1	-	valid	-	Validity Flags (see graphic below)
16	U4	-	tAcc	ns	Time Accuracy Estimate

Bitfield valid

This Graphic explains the bits of valid



■ signed value ■ unsigned value ■ reserved

Name	Description
sowValid	1 = Valid SOW and fSOW
weekValid	1 = Valid week
leapSValid	1 = Valid leapS

21.16.17 UBX-NAV-TIMEGLO (0x01 0x23)

21.16.17.1 GLO Time Solution

Message		NAV-TIMEGLO								
Description		GL	GLO Time Solution							
<i>Firmware</i> Supported on: • u-blox M8 firmware version 2.30										
Туре		Per	iodic/Polle	ed						
Comment			s message dity flags					e of the most recent nav	rigation so	lution including
		Hea	der	Class	ID	Length (Bytes)			Payload	Checksum
Message Struc	ture	0xB5 0x62 0x01 0x23 20					see below	CK_A CK_B		
Payload Contents:										
Byte Offset	Num! Forma			Name	Name		Unit	Description		
0	U4	-		itov	1		ms	GPS time of week of the See the description of	5	
4	U4	4 -		TOD		S	GLONASS time of day (rounded to integer seconds)		to integer	
8	14	14 -		ftoi)		ns	Fractional part of TOD (range: \pm /-500000000). The precise GLONASS time of day in seconds is TOD + fTOD * 1e-9		



NAV-TIMEGLO continued

Byte Offset	Number Format	Scaling	Name	Unit	Description
12	U2	-	Nt	days	Current date (range: 1-1461), starting at 1 from the 1st Jan of the year indicated by N4 and ending at 1461 at the 31st Dec of the third year after that indicated by N4
14	U1	-	N4	-	Four-year interval number starting from 1996 (1=1996, 2=2000, 3=2004)
15	X1	-	valid	-	Validity flags (see graphic below)
16	U4	-	tAcc	ns	Time Accuracy Estimate

Bitfield valid

This Graphic explains the bits of valid



signed value unsigned value

reserved	

Name	Description
todValid	1 = Valid TOD and fTOD
dateValid	1 = Valid N4 and Nt

21.16.18 UBX-NAV-TIMEGPS (0x01 0x20)

21.16.18.1 GPS Time Solution

Message		NA	IAV-TIMEGPS									
Description		GP	GPS Time Solution									
Firmware		Sup	oported o	n:								
		• (u-blox M8	from firmware version 2.00 up to version 2.30								
Туре		Per	iodic/Polle	ed								
Comment			s message idity flags	•				e of the most recent n	avigation so	lution including		
		Hea	, ,	Class	ID	Length (Bytes)			Payload	Checksum		
Message Struc	ture	0xB5 0x62 0x			0x20	16 see below CK_A CK_I			CK_A CK_B			
Payload Conte	nts:								·	•		
Byte Offset	Num Form			Name	Name		Unit	Description				
0	U4	U4 -		itov	iTOW		ms	GPS time of week o	f the navigat	ion epoch.		
							See the description of	See the description of iTOW for details.				
4	4 -		ftow		ns	Fractional part of iTOW (range: +/-500000).						
								The precise GPS time	e of week in	seconds is:		
							(iTOW * 1e-3) + (fTOW * 1e-9)					
8	12		-	week	2		-	GPS week number o	of the naviga	tion epoch		
10	11		-	leap	S		S	GPS leap seconds (G	iPS-UTC)			




NAV-TIMEGPS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
11	X1	-	valid	-	Validity Flags (see graphic below)
12	U4	-	tAcc	ns	Time Accuracy Estimate

Bitfield valid

This Graphic explains the bits of valid



■ signed value ■ unsigned value ■ reserved

Name	Description
towValid	1 = Valid GPS time of week (iTOW & fTOW)
weekValid	1 = Valid GPS week number
leapSValid	1 = Valid GPS leap seconds

21.16.19 UBX-NAV-TIMEUTC (0x01 0x21)

21.16.19.1 UTC Time Solution

Message		NAV-TIMEUTC								
Description		UTC Time Solution								
Firmware		Sup	ported c	on:						
		• u	-blox M8	8 from	firmwa	are versi	on 2.00 เ	up to version 2.30		
Туре		Peri	odic/Poll	ed						
Comment		Not	te that o	during	a leap	secon	d there r	nay be more or less t	han 60 se	conds in a
		min	nute; see	e the d	lescrip	tion of	leap see	onds for details.		
		-								
		Head	der	Class	ID	Length	(Bytes)		Payload	Checksum
Message Struc	ture	0xB	5 0x62	0x01	0x21	20			see below	СК_АСК_В
Payload Conte	nts:			•		•			•	
Byte Offset	Numi	ber	Scaling	Name	Name		Unit	Description		
	Form	at								
0	U4		-	iTOV	itow		ms	GPS time of week of the navigation epoch.		
								See the description of	iTOW for	details.
4	U4		-	tAco	2		ns	Time accuracy estimate (UTC)		
8	14		-	nano	nano		ns	Fraction of second, range -1e9 1e9 (UTC)		
12	U2	-		year	year		у	Year, range 19992099 (UTC)		
14	U1	- month			month	Month, range 112 (UTC)				
15	U1	- day		d	Day of month, range 131 (UTC)					
16	U1		-	houi	hour		h	Hour of day, range 023 (UTC)		
17	U1		-	min			min	Minute of hour, range		
18	U1		-	sec			S	Seconds of minute, ra	-	
19	X1		-	val	id		-	Validity Flags (see grap	hic below)



Bitfield valid

This Graphic explains the bits of valid

utcStandard validUTC validWKN validTOW	utcStandard validUTC validUTC validUTC	7 6 5 4	2 1 0
utcStanc valic valic valic	signed value	Aand	AUTC AWKN ATOW
nto,	signed value	Stano	/alic /alic /alic
		nto	

reserved

Name	Description						
validTOW	1 = Valid Time of Week						
validWKN	1 = Valid Week Number						
validUTC	= Valid UTC Time						
utcStandard	UTC standard identifier.						
	0: Information not available						
	1: Communications Research Labratory (CRL)						
	2: National Institute of Standards and Technology (NIST)						
	3: U.S. Naval Observatory (USNO)						
	4: International Bureau of Weights and Measures (BIPM)						
	5: European Laboratory (tbd)						
	6: Former Soviet Union (SU)						
	7: National Time Service Center, China (NTSC)						
	15: Unknown						

21.16.20 UBX-NAV-VELECEF (0x01 0x11)

21.16.20.1 Velocity Solution in ECEF

Message		NA	V-VELEC	EF						
Description		Ve	locity So	lution	in ECE	F				
Firmware		Sup	oported o	n:						
		• (u-blox M8 from firmware version 2.00 up to version 2.30 							
Туре		Periodic/Polled								
Comment		See	e import	ant co	mmen	ts cond	erning	validity of velocity give	ven in sec	tion
Navigation				Outpu	ut Filte	ers.				
Header		der	Class	ID	Length (Bytes)			Payload	Checksum	
Message Structure		OxE	35 0x62	0x01	0x11	20			see below	СК_АСК_В
Payload Conten	its:				•					•
Byte Offset	Num	ber	Scaling	Name	Name		Unit	Description		
	Form	at								
0	U4		-	itow	iTOW		ms	GPS time of week of the navigation epoch.		
								See the description of iTOW for details.		
4	14	-		ecef	ecefVX		cm/s	ECEF X velocity		
8	14	-		ecef	ecefVY		cm/s	ECEF Y velocity		
12	14		-	ecef	ecefVZ		cm/s	ECEF Z velocity		
16	U4		-	sAcc	2		cm/s	Speed accuracy estimate		



21.16.21 UBX-NAV-VELNED (0x01 0x12)

21.16.21.1 Velocity Solution in NED

Message		NAV-VELNED								
Description		Vel	Velocity Solution in NED							
Firmware		Sup	oported o	n:						
		• L	u-blox M8	⁸ from ⁻	firmwa	ire versi	on 2.00	up to version 2.30		
Туре		Per	iodic/Polle	ed						
Comment		See	e importa	ant co	mmen	ts cond	erning	validity of velocity giv	en in sec	tion
		Na	vigation	Outpu	ut Filte	ers.				
		-								
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum
Message Struc	ture	0xB	35 0x62	0x01	0x12	36			see below	CK_A CK_B
Payload Conte	nts:									
Byte Offset	Numb	ber	Scaling	Name			Unit	Description		
	Forma	ət								
0	U4		-	iTOW	I		ms	GPS time of week of t	he navigat	ion epoch.
								See the description of		details.
4	14		-	velN			cm/s	North velocity component		
8	14		-	velE			cm/s	East velocity component		
12	14		-	velD			cm/s	Down velocity component		
16	U4 -		speed			cm/s	Speed (3-D)			
20	U4	-		gSpeed			cm/s	Ground speed (2-D)		
24	14	1e-5		heading			deg	Heading of motion 2-D		
28	U4		-	sAcc	sAcc		cm/s	Speed accuracy Estimate		
32	U4		1e-5	cAcc	:		deg	Course / Heading accuracy estimate		



21.17 UBX-RXM (0x02)

Receiver Manager Messages: i.e. Satellite Status, RTC Status.

Messages in Class RXM output status and result data from the Receiver Manager.

21.17.1 UBX-RXM-PMREQ (0x02 0x41)

21.17.1.1 Requests a Power Management task

Message		RX	KM-PMREQ							
Description		Rec	quests a	Powe	' Mana	ageme	nt task			
Firmware		Sup	ported o	n:						
 u-blox M8 from firmware version 2.00 up to version 2.30 										
Type Command										
Comment Request of a Po			Power	ower Management related task of the receiver.						
		Head	der	Class	ID	Length (Bytes)			Payload	Checksum
Message Structure		0xB	5 0x62	0x02	0x41	8			see below	CK_A CK_B
Payload Conte	nts:									
Byte Offset	Numl	ber	Scaling	Name			Unit	Description		
	Forma	at								
0 U4		- duratio		tion		ms	Duration of the requested task, set to zero for			
								infinite duration		
4	X4		-	flag	flags		-	task flags (see graphic below)		

Bitfield flags

This Graphic explains the bits of flags

Name	Description
backup	The receiver goes into backup mode for a time period defined by duration

21.17.2 UBX-RXM-RAWX (0x02 0x15)

21.17.2.1 Multi-GNSS Raw Measurement Data

Message	RXM-RAWX	RXM-RAWX							
Description	Multi-GNSS	Multi-GNSS Raw Measurement Data							
Firmware	Supported o	Supported on:							
	• u-blox M8	firmw	are ver	rsion 2.30 (only available with Raw D	ata produ	uct variant)			
Туре	Periodic/Polle	Periodic/Polled							
Comment	This message	This message contains the information needed to be able to generate a RINEX 3							
	multi-GNSS (multi-GNSS observation file.							
	This message contains pseudorange, Doppler, carrier phase, phase lock and signal quality								
	information for GNSS satellites once signals have been synchronized. This message supports								
	all active GNSS.								
	Header	Class	ID	Length (Bytes)	Payload	Checksum			
Message Structure	0xB5 0x62	0x02	0x15	16 + 32*numMeas	see below	CK_A CK_B			





Payload Conten	ts:				
Byte Offset	Number Format	Scaling	Name	Unit	Description
0	R8	-	rcvTow	S	Measurement time of week in receiver local time approximately aligned to the GPS time system. The receiver local time of week, week number and leap second information can be used to translate the time to other time systems. More information about the difference in time systems can be found in RINEX 3 documentation. For a receiver operating in GLONASS only mode, UTC time can be determined by subtracting the leapS field from GPS time regardless of whether the GPS leap seconds are valid.
8	U2	-	week	weeks	GPS week number in receiver local time.
10	1	-	leapS	S	GPS leap seconds (GPS-UTC). This field represents the receiver's best knowledge of the leap seconds offset. A flag is given in the recStat bitfield to indicate if the leap seconds are known.
11	U1	-	numMeas	-	Number of measurements to follow
12	X1	-	recStat	-	Receiver tracking status bitfield (see graphic below)
13	U1[3]	-	reserved1	-	Reserved
Start of repeate	d block (nun	nMeas times	5)		
16 + 32*N	R8	-	prMes	m	Pseudorange measurement [m]. GLONASS inter frequency channel delays are compensated with an internal calibration table.
24 + 32*N	R8	-	cpMes	cycles	Carrier phase measurement [cycles]. The carrier phase initial ambiguity is initialized using an approximate value to make the magnitude of the phase close to the pseudorange measurement. Clock resets are applied to both phase and code measurements in accordance with the RINEX specification.
32 + 32*N	R4	-	doMes	Hz	Doppler measurement (positive sign for approaching satellites) [Hz]
36 + 32*N	U1	-	gnssId	-	GNSS identifier (see Satellite Numbering for a list of identifiers)
37 + 32*N	U1	-	svId	-	Satellite identifier (see Satellite Numbering)
38 + 32*N	U1	-	reserved2	-	Reserved
39 + 32*N	U1	-	freqId	-	Only used for GLONASS: This is the frequency slot + 7 (range from 0 to 13)
40 + 32*N	U2	-	locktime	ms	Carrier phase locktime counter (maximum 64500ms)




RXM-RAWX continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
42 + 32*N	U1	-	cno	dBHz	Carrier-to-noise density ratio (signal strength)
					[dB-Hz]
43 + 32*N	X1	0.	prStdev	m	Estimated pseudorange measurement standard
		01*2^n			deviation (see graphic below)
44 + 32*N	X1	0.004	cpStdev	cycles	Estimated carrier phase measurement standard
					deviation (note a raw value of 0x0F indicates the
					value is invalid) (see graphic below)
45 + 32*N	X1	0.	doStdev	Hz	Estimated Doppler measurement standard
		002*2^			deviation. (see graphic below)
		n			
46 + 32*N	X1	-	trkStat	-	Tracking status bitfield (see graphic below)
47 + 32*N	U1	-	reserved3	-	Reserved
End of repeated	block				

Bitfield recStat

This Graphic explains the bits of recStat




■ signed value ■ unsigned value

reserved	

Name	Description
leapSec	Leap seconds have been determined
clkReset	Clock reset applied. Typically the receiver clock is changed in increments of integer milliseconds.

Bitfield prStdev

This Graphic explains the bits of prStdev




Name	Description
prStd	Estimated pseudorange standard deviation



Bitfield cpStdev


This Graphic explains the bits of cpStdev



Name	Description
cpStd	Estimated carrier phase standard deviation


Bitfield doStdev

This Graphic explains the bits of doStdev



Bitfield trkStat

This Graphic explains the bits of trkStat



unsigned value

Name	Description
prValid	Pseudorange valid
cpValid	Carrier phase valid
halfCyc	Half cycle valid
subHalfCyc	Half cycle subtracted from phase



21.17.3 UBX-RXM-SFRBX (0x02 0x13)

21.17.3.1 Raw Subframe Data

Message		RXM-S	RXM-SFRBX											
Description		Raw Su	ubfra	me Da	ata									
Firmware		Support	Supported on:											
		• u-blo	• u-blox M8 firmware version 2.30 (only available with Raw Data product variant)											
Туре		Aperiod	lic											
Comment This is			nis is an extended, more flexible version of RXM-SFRB.											
		This message sends the raw data received from a certain satellite system (including IMES).												
		Thus the message contains preamble, parity bits and all protocol specific overhead and is												
		sent out when new data is received from the transmitter.												
		Note th	at for	r IMES	transm	nitters t	he dwrd	l can contain data of on	ly one IME	S frame but also				
		data of multiple frames. For example, it could contain a single 1-word long short ID frame												
		only, in this case numWords is 1, but it could also contain a 1-word long short ID frame												
		and a 3	and a 3-word long position 1 frame, then numWords would be 4. For details on the data											
		format,	ormat, please check IS-QZSS Version 1.5.											
		Header	leader Class ID Length (Bytes)					Payload	Checksum					
Message Structure 0xB5 0x62		(62	0x02	0x13	8 + 4*	'numWc	ords	see below	СК_А СК_В					
Payload Conte	ents:	•												
Byte Offset	Numb	per Scali	ng	Name			Unit	Description						
	Forma	at												
0	U1	-		gnss	Id		-	GNSS identifier (see S	atellite Nur	mbering)				
1	U1	-		svId	l		-	Satellite identifier (see	Satellite N	lumbering)				
2	U1	-		rese	erved	1	-	Reserved						
3	U1	-		freq	[Id		-	Only used for GLONA	SS: This is	the frequency				
								slot + 7 (range from 0						
4	U1	-		numW	lords		-	The number of data v	vords conta	ained in this				
								message (016)						
5	U1	-		rese	erved	2	-	Reserved						
6	U1	-		vers			-	Message version, (=1	for this ver	rsion)				
7	U1	-		rese	rved	3	-	Reserved						
Start of repeat	ted block	(numWord	s times	s)										
8 + 4*N	U4	-		dwrd	l		-	The data words						
End of repeate	ed block													




21.17.4 UBX-RXM-SVSI (0x02 0x20)

21.17.4.1 SV Status Info

Message		RX	RXM-SVSI											
Description		sv	Status I	nfo										
Firmware		Sup	oported c	n:										
		• (u-blox M8	3 from	firmwa	are versi	on 2.00	up to version 2.30						
Туре		Per	iodic/Poll	ed	b									
Comment		Sta	Status of the receiver manager knowledge about GPS Orbit Validity											
			This message has only been retained for backwards compatibility; users are recommended											
		to	use the U	BX-NA	V-ORE	a messa	ge in pre	eference.	-					
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum				
Message Struct	ture	0xB5 0x62 0x02 0x20 8 + 6*numSV			see below	CK_A CK_B								
Payload Conter	nts:			4		1								
Byte Offset	Num	ber	Scaling	Name			Unit	Description						
	Form	at												
0	U4		-	itow			ms	GPS time of week of the navigation epoch						
								See the description of iTOW for details.						
4	12		-	week	2		weeks	GPS week number of the navigation epoch						
6	U1		-	num∖	/is		-	Number of visible satellites						
7	U1		-	numS	numSV		-	Number of per-SV data blocks following						
Start of repeate	ed block	(num	SV times)											
8 + 6*N	U1		-	svid	1		-	Satellite ID						
9 + 6*N	X1		-	svF]	ag		-	Information Flags	(see graphic b	elow)				
10 + 6*N	12		-	azin	azim		-	Azimuth						
12 + 6*N	1		-	elev	7		-	Elevation						
13 + 6*N X1		-		age			-	Age of Almanac a	and Enhemeris	(see graphic				
13 + 6*N	X1		1-	age				, ige of , annunde e	ind Ephemens.	(see graphic				

Bitfield svFlag

This Graphic explains the bits of svFlag



Name	Description
ura	Figure of Merit (URA) range 015
healthy	SV healthy flag
ephVal	Ephemeris valid
almVal	Almanac valid
notAvail	SV not available



Bitfield age

This Graphic explains the bits of age

7	6	5	4	3	2	1	0			
Ĥĝe				Ĥĝe						
eph	ephAge al mAge									
Ū 4	igne Insig eser	ned	lue valu	e						

Name	Description							
almAge	Age of ALM in days offset by 4							
	the reference time may be in the future:							
	ageOfAlm = (age & 0x0f) - 4							
ephAge	Age of EPH in hours offset by 4.							
	i.e. the reference time may be in the future:							
	ageOfEph = ((age & 0xf0) >> 4) - 4							



21.18 UBX-TIM (0x0D)

Timing Messages: i.e. Time Pulse Output, Timemark Results.

Messages in this class are output by the receiver, giving information on Timepulse and Timemark measurements.

21.18.1 UBX-TIM-DOSC (0x0D 0x11)

21.18.1.1 Disciplined oscillator control

Message		TIN	TIM-DOSC								
Description		Dis	Disciplined oscillator control								
Firmware		Sup	oported o	n:							
		• ı	u-blox M8	s from ⁻	firmwa	ire versi	on 2.20	up to version 2.30 (only	y availabl	e with FTS	
		1	product variant)								
Туре		Ou	Dutput								
Comment		The	The receiver sends this message when it is disciplining an external oscillator and the							and the	
		ext	ernal osci	llator is	set up	o to be	controlle	ed via the host.			
		Hea	ıder	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struc	ture	re 0xB5 0x62			0x11	8			see below	CK_A CK_B	
Payload Conte	nts:			1					•	•	
Byte Offset	Num	ber	Scaling	Name			Unit	Description	Description		
	Form	at									
0	U1		-	vers	ion		-	Message version (0 fo	Message version (0 for this version)		
1	U1[3	3]	-	rese	rved	1	-	Reserved			
4	U4		-	valu	le		-	The raw value to be a	pplied to t	he DAC	
								controlling the external oscillator. The least			
								significant bits should	be writter	to the DAC,	
								with the higher bits be	with the higher bits being ignored.		

21.18.2 UBX-TIM-FCHG (0x0D 0x16)

21.18.2.1 Oscillator frequency changed notification

Message		TIN	FIM-FCHG										
Description		Os	Oscillator frequency changed notification										
Firmware		• (upported on: u-blox M8 from firmware version 2.20 up to version 2.30 (only available with FTS product variant)										
Туре		No	Notification										
Comment		This message reports frequency changes commanded by the sync manager for th and external oscillator. It is output at the configured rate even if the sync manage not to command a frequency change.											
		Hea	der	Class	ID	Length (Bytes)				Payload	Checksum		
Message Structu	ıre	OxE	35 0x62	0x0D	0x16	32				see below	CK_A CK_B		
Payload Conten	ts:												
Byte Offset	Numi Form					Unit	Description						
0	U1		-	vers	sion		-	Message ve	essage version (0 for this version)				
1	U1[3	3]	-	rese	erved	1	-	Reserved					



TIM-FCHG continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
4	U4	-	itow	ms	GPS time of week of the navigation epoch from which the sync manager obtains the GNSS specific data. Like for the NAV message, the iTOW can be used to group messages of a single sync manager run together (See the description of iTOW for details)
8	14	2^-8	intDeltaFreq	ppb	Frequency increment of the internal oscillator
12	U4	2^-8	intDeltaFreqU nc	ppb	Uncertainty of the internal oscillator frequency increment
16	U4	-	intRaw	-	Current raw DAC setting commanded to the internal oscillator
20	14	2^-8	extDeltaFreq	ppb	Frequency increment of the external oscillator
24	U4	2^-8	extDeltaFreqU nc	ppb	Uncertainty of the external oscillator frequency increment
28	U4	-	extRaw	-	Current raw DAC setting commanded to the external oscillator

21.18.3 UBX-TIM-HOC (0x0D 0x17)

21.18.3.1 Host oscillator control

Message		ΤIN	1-HOC								
Description		Host oscillator control									
Firmware		Sup	ported o	n:							
		•ι	i-blox M8	3 from t	firmwa	re versi	on 2.20	up to version 2.	30 (only	available	e with FTS
		F	oroduct	variant	t)						
Туре		Inp	nput								
Comment		This message can be sent by the host to force the receiver to bypass the disciplining algorithms in the SMGR and carry out the instructed changes to internal or external oscillator frequency. No checks are carried out on the size of the frequency change requested, so normal limits imposed by the SMGR are ignored. It is recommended that the disciplining of that oscillator is disabled before this messares sent (i.e. by clearing the enableInternal or enableExternal flag in the CFG-SMGR messor otherwise the autonomous disciplining processes may cancel the effect of the direct command. Note that the GNSS subsystem may temporarily lose track of some/all satellite signals large change of the internal oscillator is made.								external change his message is MGR message), ne direct	
		Hea	der	Class	ID	Length	(Bytes)			Payload	Checksum
Message Struct	ture	OxB	5 0x62	0x0D	0x17	8				see below	CK_A CK_B
Payload Conter	nts:										
Byte Offset	Num	ber	Scaling	Name			Unit	Description			

Byte OffsetNumberScalingNameUnitDescription0U1-version-Message version (0 for this version)






TIM-HOC continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
1	U1	-	oscId	-	ld of oscillator:
					0: internal oscillator
					1: external oscillator
2	U1	-	flags	-	Flags (see graphic below)
3	U1	-	reserved1	-	Reserved
4	14	2^-8	value	ppb/-	Required frequency offset or raw output,
					depending on the flags

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description						
raw	ype of value:						
	0: frequency offset						
	1: raw digital output						
difference	Nature of value:						
	0: absolute (i.e. relative to 0)						
	1: relative to current setting						

21.18.4 UBX-TIM-SMEAS (0x0D 0x13)

21.18.4.1 Source measurement

Message	TIM-SMEAS	TIM-SMEAS									
Description	Source mea	Source measurement									
Firmware	Supported o	Supported on:									
	• u-blox M8	from t	irmwa	are version 2.20 up to version 2.30 (onl	y availabl	e with FTS					
	product v	/ariant	:)								
Туре	Input/Outpu	t									
Comment	Frequency ar	nd/or p	hase n	neasurement of syncronization sources.	The measu	urements are					
	relative to th	e nomi	nal fre	equency and nominal phase.							
	The receiver	reports	the m	neasurements on its sync sources using	this messag	ge. Which					
	measuremen	nts are i	reporte	ed can be configured using UBX-CFG-S	MGR.						
	The host ma	y repor	t offse	t of the receiver's outputs with this me	ssage as w	ell. The receiver					
	has to be co	nfigure	d usin	g UBX-CFG-SMGR to enable the use of	the extern	al measurement					
	messages. O	therwis	se the	receiver will ignore them.							
	Header	Class	ID	Length (Bytes) Payload Checksum							
Message Structure	0xB5 0x62 0x0D 0x13 12 + 24*numMeas see below CK_A CK_B										
Payload Contents:	•	•		•							





TIM-SMEAS continued

	linuea				
Byte Offset	Number Format	Scaling	Name	Unit	Description
Byte Offset	Number Format	Scaling	Name	Unit	Description
0	U1	-	version	-	Message version (0 for this version)
1	U1	-	numMeas	-	Number of measurements in repeated block
2	U1[2]	-	reserved1	-	Reserved
4	U4	-	iTOW	ms	Time of the week
8	U1[4]	-	reserved2	-	Reserved
Start of repeated		- Meas times			
12 + 24*N	U1		sourceId		Index of source. SMEAS can provide six measurement sources. The first four sourceld values represent measurements made by the receiver and sent to the host. The first of these with a sourceld value of 0 is a measurement of the internal oscillator against the current receiver time-and-frequency estimate. The internal oscillator is being disciplined against that estimate and this result represents the current offset between the actual and desired internal oscillator states. The next three sourceld values represent frequency and time measurements made by the receiver against the internal oscillator. sourceld 1 represents the GNSS-derived frequency and time compared with the internal oscillator frequency and time. sourceld2 give measurements of a signal coming in on EXTINTO. sourceld 3 corresponds to a similar measurement on EXTINT1. The remaining two of these measurements (sourceld 4 and 5) are made by the host and sent to the receiver. A measurement with sourceld 4 is a measurement by the host of the internal oscillator and sourceld 5 indicates a host measurement of the external oscillator.
13 + 24*N	X1	-	flags	-	Flags (see graphic below)
14 + 24*N	1	2^-8	phaseOffsetFr ac	ns	Sub-nanosecond phase offset; the total offset is the sum of phaseOffset and phaseOffsetFrac
15 + 24*N	U1	2^-8	phaseUncFrac	ns	Sub-nanosecond phase uncertainty
16 + 24*N	14	-	phaseOffset	ns	Phase offset, positive if the source lags accurate phase and negative if the source is early
20 + 24*N	U4	-	phaseUnc	ns	Phase uncertainty (one standard deviation)
24 + 24*N	U1[4]	-	reserved3	-	Reserved
28 + 24*N	14	2^-8	freqOffset	ppb	Frequency offset, positive if the source frequency is too high, negative if the frequency is too low.



TIM-SMEAS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
32 + 24*N	U4	2^-8	freqUnc	ppb	Frequency uncertainty (one standard deviation)
End of repeated l	olock				

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

Name	Description
freqValid	1 = frequency measurement is valid
phaseValid	1 = phase measurement is valid

21.18.5 UBX-TIM-SVIN (0x0D 0x04)

21.18.5.1 Survey-in data

Message		TIN	TIM-SVIN							
Description		Su	Survey-in data							
Firmware			oported c							
			 u-blox M8 from firmware version 2.00 up to version 2.30 (only available with or FTS product variants) 							e with Timing
		-			variar	ITS)				
Туре			iodic/Poll							
Comment			-					survey-in parameters. Fo	or details a	bout the Time
		Мс	ode see se	ection T	ime M	ode Co	onfiguratio	on.	1	
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum
Message Struct	ture	OxE	35 0x62	0x0D	0x04	28			see below	CK_A CK_B
Payload Conter	nts:			•		•				
Byte Offset	Num	ber	Scaling	Name			Unit	Description		
	Form	at								
0	U4		-	dur			S	Passed survey-in observation time		
4	14		-	meanX			cm	Current survey-in mean position ECEF X		ECEF X
								coordinate		
8	14		-	meanY			cm	Current survey-in mean position ECEF Y		ECEF Y
								coordinate		
12	4		-	mear	meanZ		cm	Current survey-in mean position ECEF Z		ECEF Z
								coordinate		
16	U4		-	mear	meanV		mm^2	Current survey-in mea	n position	3D variance
20	U4	-		obs	obs		-	Number of position ob	oservations	s used during
								survey-in		
24	U1		-	vali	d		-	Survey-in position valid	dity flag, 1	= valid,
								otherwise 0		



TIM-SVIN continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
25	U1	-	active	-	Survey-in in progress flag, 1 = in-progress, otherwise 0
26	U1[2]	-	reserved1	-	Reserved


21.18.6 UBX-TIM-TM2 (0x0D 0x03)

21.18.6.1 Time mark data

Message		TIM-TM2									
Description		Tin	Time mark data								
Firmware			Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30								
Туре		Per	iodic/Polle	ed							
Comment		This message contains information for high precision time stamping / pulse contains for high precision time stamping / pulse contains delay figures and timebase given in CFG-TP5 are also applied to the time output in this message.							-		
		Hea	der	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Structu	ıre	OxE	35 0x62	0x0D	0x03	28			see below	CK_A CK_B	
Payload Conten	ts:			1	1				1		
Byte Offset	Numt Forma		Scaling	Name			Unit	Description			
0	U1		-	ch			-	Channel (i.e. EXTINT) measured	Channel (i.e. EXTINT) upon which the pulse wa measured		
1	X1		-	flags			-	Bitmask (see graphic below)			
2	U2		-	cour	count		-	rising edge counter.			
4	U2		-	wnR			-	week number of last rising edge			
6	U2		-	wnF			-	week number of last f	week number of last falling edge		
8	U4		-	tow№	IsR		ms	tow of rising edge			
12	U4		-	tows	towSubMsR		ns	millisecond fraction of nanoseconds	tow of ris	ing edge in	
16	U4		-	towM	towMsF		ms	tow of falling edge			
20	U4	-		tows	towSubMsF		ns	millisecond fraction of nanoseconds	millisecond fraction of tow of falling edge in		
24	U4		-	accE	lst		ns	Accuracy estimate			

Bitfield flags

This Graphic explains the bits of flags





Bitfield flags Description continued

Name	Description
Name	Description
mode	0=single
	1=running
run	0=armed
	1=stopped
newFallingEdg	new falling edge detected
e	
timeBase	0=Time base is Receiver Time
	1=Time base is GNSS Time (the system according to the configuration in CFG-TP5 for tpldx=0)
	2=Time base is UTC (the variant according to the configuration in CFG-NAV5)
utc	0=UTC not available
	1=UTC available
time	0=Time is not valid
	1=Time is valid (Valid GNSS fix)
newRisingEdge	new rising edge detected

21.18.7 UBX-TIM-TOS (0x0D 0x12)

21.18.7.1 Time Pulse Time and Frequency Data

Message		TIN	TIM-TOS								
Description		Tin	Fime Pulse Time and Frequency Data								
Firmware		Sup	Supported on:								
		• 1	• u-blox M8 from firmware version 2.20 up to version 2.30 (only available with								
			product v	variant	:)						
Туре		Per	riodic								
Comment		Thi	s message	e conta	ins inf	ormatic	n about [.]	the time pulse that has	just happe	ned and the	
		sta	te of the o	disciplii	ned os	cillators	(s) at the	time of the pulse. It giv	es the UT(and GNSS	
							•	gether with frequency a		ncy uncertainty	
		of	the discip	lined o				es leap second informati	ion.		
		Hea	nder	Class	ID	Length	(Bytes)		Payload	Checksum	
Message Struct	ture	OxE	35 0x62	0x0D	0x12	56			see below	CK_A CK_B	
Payload Conter	nts:										
Byte Offset	Num	ber	Scaling	Name			Unit	Description			
	Form	at									
0	U1		-	vers	ion		-	Message version (0 for this version)			
1	U1		-	gnss	gnssId		-	GNSS system used for reporting GNSS time (see			
								Satellite Numbering)			
2	U1[2	2]	-	rese	erved	1	-	Reserved	Reserved		
4	X4		-	flag	IS		-	Flags (see graphic belo	w)		
8	U2		-	year	•		у	Year of UTC time			
10	U1		-	mont	month		month	Month of UTC time			
11	U1		-	day	day		d	Day of UTC time			
12	U1		-	hour			h	Hour of UTC time			
13	U1		-	minu	ite		min	Minute of UTC time			
14	U1		-	seco	ond		S	Second of UTC time			



TIM-TOS continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
15	U1	-	utcStandard	-	UTC standard identifier:
					0: unknown
					3: UTC as operated by the U.S. Naval
					Observatory (USNO)
					6: UTC as operated by the former Soviet Union
					7: UTC as operated by the National Time Service
					Center, China
16	14	-	utcOffset	ns	Time offset between the preceding pulse and
					UTC top of second
20	U4	-	utcUncertaint	ns	Uncertainty of utcOffset
			У		
24	U4	-	week	-	GNSS week number
28	U4	-	TOW	S	GNSS time of week
32	14	-	gnssOffset	ns	Time offset between the preceding pulse and
					GNSS top of second
36	U4	-	gnssUncertain	ns	Uncertainty of gnssOffset
			ty		
40	14	2^-8	intOscOffset	ppb	Internal oscillator frequency offset
44	U4	2^-8	intOscUncerta	ppb	Internal oscillator frequency uncertainty
			inty		
48	14	2^-8	ext0sc0ffset	ppb	External oscillator frequency offset
52	U4	2^-8	ext0scUncerta	ppb	External oscillator frequency uncertainty
			inty		

Bitfield flags

This Graphic explains the bits of flags

	13 12 11 10 9 8	7 6 5 4 3 2 1 0
	lockedPulse cohPulse raim DiscSrc	UTCTimeValid gnssTimeValid extOscInLimit intOscInLimit timeInLimit leapPositive leapNow

■ signed value ■ unsigned value ■ reserved

Name	Description
leapNow	1 = currently in a leap second
leapSoon	1 = leap second scheduled in current minute
leapPositive	1 = positive leap second
timeInLimit	1 = time pulse is within tolerance limit (CFG-SMGR timeTolerance field)
intOscInLimit	1 = internal oscillator is within tolerance limit (CFG-SMGR freqTolerance field)
extOscInLimit	1 = external oscillator is within tolerance limit (CFG-SMGR freqTolerance field)
gnssTimeValid	1 = GNSS time is valid
UTCTimeValid	1 = UTC time is valid



Bitfield flags Description continued

Name	Description
DiscSrc	Disciplining source identifier:
	0: internal oscillator
	1: GNSS
	2: EXTINTO
	3: EXTINT1
	4: internal oscillator measured by the host
	5: external oscillator measured by the host
raim	1 = (T)RAIM system is currently active. Note this flag only reports the current state of the GNSS solution; it is not
	affected by whether or not the GNSS solution is being used to discipline the oscillator.
cohPulse	1 = coherent pulse generation is currently in operation
lockedPulse	1 = time pulse is locked

21.18.8 UBX-TIM-TP (0x0D 0x01)


21.18.8.1 Time Pulse Timedata

Message		TIN	И-ТР								
Description		Tin	ne Pulse	Timed	ata						
Firmware		Sup	oported o	n:							
		• (u-blox M8	⁸ from ⁻	firmwa	re versi	on 2.00	up to version 2.30			
Туре		Per	iodic/Polle	ed							
Comment		This message contains information for high precision timing. The recommended configuration when using this message is to set both the measurement rate (CFG-RZ and the timepulse frequency (CFG-TP5) to 1Hz. For more information see section Timpulse.								(CFG-RATE)	
Header Class ID Length (Bytes)							Payload	Checksum			
Message Struc	ture	0xE	35 0x62	0x0D	0x01	16			see below	CK_A CK_B	
Payload Conte	nts:					1			•		
Byte Offset	Num! Forma		Scaling	Name	Name		Unit	Description			
0	U4		-	tow№	IS		ms	Time pulse time of we	Time pulse time of week according to time bas		
4	U4		2^-32	tows	SubMS		ms	Submillisecond part of	Submillisecond part of TOWMS		
8	14		-	qErr			ps	Quantization error of	time pulse	(not supported	
								for the FTS product va	riant).		
12	U2	-		week			weeks	Time pulse week number according to time			
						base					
14	X1	- flags			-	bitmask (see graphic b	hic below)				
15	X1		-	refI	nfo		-	Time reference inform	ation (see	graphic below)	



Bitfield flags

This Graphic explains the bits of flags




■ signed value ■ unsigned value ■ reserved

Name	Description
timeBase	0=Time base is GNSS
	1=Time base is UTC
utc	0=UTC not available
	1=UTC available
raim	(T)RAIM information
	0=information not available
	1=not active
	2=active

Bitfield refInfo

This Graphic explains the bits of refInfo



Name	Description								
timeRefGnss	GNSS reference information (only active if time base is GNSS -> timeBase=0)								
	0: GPS								
	1: GLONASS								
	2: BeiDou								
	15: Unknown								
utcStandard	UTC standard identifier (only active if time base is UTC -> timeBase=1)								
	0: Information not available								
	1: Communications Research Laboratory (CRL)								
	2: National Institute of Standards and Technology (NIST)								
	3: U.S. Naval Observatory (USNO)								
	4: International Bureau of Weights and Measures (BIPM)								
	5: European Laboratory (tbd)								
	6: Former Soviet Union (SU)								
	15: Unknown								



21.18.9 UBX-TIM-VCOCAL (0x0D 0x15)

21.18.9.1 VCO calibration extended command

Message		TIM-VCOC	AL										
Description		VCO calibr	ation e	xtend	ed com	mand							
Firmware		Supported of • u-blox M product	8 from ⁻		are versi	on 2.20	up to version 2.30 (or	ly availabl	e with FTS				
Туре		Command											
Comment		Calibrate (m varying the maxStepSize "raw values VCTCXO is dRelativeFre as follows: Starting from in steps of s is changed frequency is measured re maxStepSize Care must b case the cha signal track system will will then fai It is also imp process and	raw osc e is the s" are ei connect equency m the c size at m towards s again i e sult. No e then t be taker anges a ing, esp lose its lose its bortant t that it easuren	illator largest ther P ted to Chang urrent nost m raw1, measur ormal of he tran pplied ecially fix and s case i that or remain	control step ch WM du the syst pe/dRaw raw ou axStepS , again i red and operation nation va calibra to the o when s be una maxStep nly the o ns stable will be n	values be hange that ty cycle v em. The (not dFr tput the of ize. Ther n steps of the mes on then re vill happe ting the oscillator ignals are ble to me osize mus chosen fr e through hade and iver.	ntrolled oscillator. The etween the limits spec- at can be used during alues or DAC values d measured gain is the equency/dVoltage). The control value is chang the frequency is mea- f maxStepSize. When sage version DATA0 is esumes. If the control en in one step - this w nternal oscillator agai frequency could be se e weak. If too many si easure the oscillator fre- st be reasonably small equency source is ena- out the calibration pe- this will lead to misca	ified in raw(the calibrati epending or transfer func- ne calibration ed in the dir sured and the raw1 is read output con- value mover fill give fast of nst the GNS evere enough gnals are los requency - the bled during eriod; otherv	D amd raw1. on process. The h how the ction n process works ection of raw0 he control value ched, the taining the ment is less than calibration. S source. In that h to lose satellite st, the GNSS he calibration the calibration				
Message Struc	ture	0xB5 0x62	0x0D	0x15	12			see below	CK_A CK_B				
Payload Conte	nts:	1	1	1	1			I	1				
Byte Offset	Numb Forma		Name			Unit	Description						
0	U1	-	type	2		-	Message type (2 for	this messag	e)				
1	U1	-	vers	sion		-	Message version (0 f		on)				
2	U1	-	oscI	oscId			Oscillator to be calib 0: internal oscillator 1: external oscillator	ated:					



TIM-VCOCAL continued

Byte Offset	Number	Scaling	Name	Unit	Description
	Format				
3	U1	-	srcId	-	Reference source:
					0: internal oscillator
					1: GNSS
					2: EXTINTO
					3: EXTINT1
					Option 0 should be used when calibrating the
					external oscillator. Options 1-3 should be used
					when calibrating the internal oscillator.
4	U1[2]	-	reservedl	-	Reserved
6	U2	-	raw0	-	First value used for calibration
8	U2	-	rawl	-	Second value used for calibration
10	U2	-	maxStepSize	raw	Maximum step size to be used
				value/s	

21.18.9.2 Results of the calibration

Message		TIN	/I-VCOCA	L									
Description		Res	sults of t	he cali	ibratic	n							
Firmware		Sup	ported o	n:									
		• L	u-blox M8	from firmware version 2.20 up to version 2.30 (only available with FTS									
		F	oroduct v	/ariant	t)								
Туре		Not	Notification										
Comment		Thi	s message	e is sen	t wher	n the os	cillator ga	ain calibration process is	s finished (successful or			
			unsuccessful). It notifies the user of the calibrated oscillator gain. If the oscillator gain										
		cali	calibration process was successful, this message will contain the measured gain (field										
		gai	ainVco) and its uncertainty (field gainUncertainty). The calibration process can however										
		fail	. In that c	ase the	se the two fields gainVco and gainUncertainty are set to zero.								
Header				Class	ID	Length ((Bytes)		Payload	Checksum			
Message Structure 0xB5 0x62		35 0x62	0x0D	0x15	12			see below	CK_A CK_B				
Payload Conte	nts:					!							
Byte Offset	Numl	ber	Scaling	Name			Unit	Description					
	Forma	ət											
0	U1		-	type	5		-	Message type (3 for this message)					
1	U1		-	vers	sion		-	Message version (0 for this version)					
2	U1		-	oscI	d		-	Id of oscillator:					
								0: internal oscillator					
								1: external oscillator					
3	U1[3	3]	-	rese	erved	1	-	Reserved					
6	U2		2^-16	gair	gainUncertain			Relative gain uncertair	nty after ca	alibration, 0 if			
				ty				calibration failed					
8	14		2^-16	gair	Vco		ppb/ra	Calibrated gain or 0 if	calibration	n failed			
							w LSB						



21.18.10 UBX-TIM-VRFY (0x0D 0x06)

21.18.10.1 Sourced Time Verification

Message		TIN	TIM-VRFY										
Description		So	Sourced Time Verification										
Firmware		Sup	oported o	n:									
		• (u-blox M8	8 from t	firmwa	ire versi	on 2.00	up to version 2.30					
Туре		Pol	led/Once										
Comment		Thi	s message	e conta	ins ver	ificatior	n informa	ation about previous tim	e received	via AID-INI or			
		fro	m RTC										
	Header					Length	(Bytes)		Payload	Checksum			
Message Structure 0xB5 0x62			35 0x62	0x0D	0x06	20 see below CK_				CK_A CK_B			
Payload Conte	nts:			•		•			•				
Byte Offset	Numl	ber	Scaling	Name	Name			Description					
	Form	ət											
0	14		-	itow	7		ms	integer millisecond tow received by source					
4	14		-	frac	!		ns	sub-millisecond part o	f tow				
8	14		-	delt	aMs		ms	integer milliseconds of	f delta time	e (current time			
								minus sourced time)					
12	14		-	delt	aNs		ns	sub-millisecond part o	sub-millisecond part of delta time				
16	U2		-	wno	wno			week number					
18	X1		-	flag	flags			information flags (see graphic below)					
19	U1		-	rese	rved	1	-	Reserved					

Bitfield flags

This Graphic explains the bits of flags



■ signed value ■ unsigned value ■ reserved

- Hesenved	
Name	Description
src	aiding time source
	0: no time aiding done
	2: source was RTC
	3: source was AID-INI



21.19 UBX-UPD (0x09)

Firmware Update Messages: i.e. Memory/Flash erase/write, Reboot, Flash identification, etc.. Messages in this class are used to update the firmware.

21.19.1 UBX-UPD-SOS (0x09 0x14)

21.19.1.1 Poll Backup File Restore Status

Message	UPD-SOS	JPD-SOS										
Description	Poll Backup	Poll Backup File Restore Status										
Firmware	Supported o	upported on:										
	• u-blox M8	u-blox M8 from firmware version 2.00 up to version 2.30										
Туре	Poll Request	Poll Request										
Comment	Sending this	(empty	/ / no-p	payload) message to the receiver results	in the rece	eiver returning a						
	System Resto	ored fro	om Bac	<i>kup</i> message as defined below.								
	Header	Class	ID	Length (Bytes)	Payload	Checksum						
Message Structure	0xB5 0x62	0xB5 0x62 0x09 0x14 0 see below CK_A CK_B										
No payload	-				3							

21.19.1.2 Create Backup File in Flash

Message		UP	D-SOS										
Description		Cre	eate Back	up Fil	e in Fla	ash							
Firmware			Supported on:										
		• l	u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Inp	ut										
Comment Message Structur		The host can send this message in order to save part of the BBR memory in a file in flash file system. The feature is designed in order to emulate the presence of the backup battery even if it is not present; the host can issue the save on shutdown command before switching off the device supply. It is recommended to issue a GNSS stop command before, 								backup battery before nmand before,			
			35 0x62	0x09	0x14	4				see below			
Payload Contents							1	1					
Byte Offset	Numbe	er	Scaling	Name			Unit	Description					
	Forma	t											
0	U1		-	cmd	cmd			Command (mu	Command (must be 0)				
1	U1[3]]	-	rese	erved	L	-	Reserved					



21.19.1.3 Clear Backup in Flash

Message		UP	D-SOS										
Description		Cle	lear Backup in Flash										
Firmware			Supported on: • u-blox M8 from firmware version 2.00 up to version 2.30										
Туре		Inp	iput										
Comment Message Structu		The host can send this message in order to erase the backup file present in flash. It isrecommended that the clear operation is issued after the host has received the notificationthat the memory has been restored after a reset. Alternatively the host can parse thestartup string 'Restored data saved on shutdown' or poll the UBX-UPD-SOS message forgetting the status.HeaderClassIDLength (Bytes)PayloadChecksum0xB5 0x620x090x144see belowCK A CK B									the notification parse the message for		
Payload Contents	5:									I	I		
Byte Offset	Numbe Forma	5				Unit	Description						
0	U1		-	cmd	cmd			Command (mu	nust be 1)				
1	U1[3]]	-	rese	rved	1	-	Reserved					

21.19.1.4 Backup File Creation Acknowledge

Message UPD-SOS											
Description Backup File				Creat	Creation Acknowledge						
Firmware		Sup	oported o	n:							
		• (u-blox M8	from	firmwa	re versi	on 2.00 เ	up to version 2.30			
Type		Ou	tput								
Comment		The	e message	e is sen	t from	the dev	ice as co	nfirmation of creation o	f a backup	o file in flash.	
			e host can	safely shut down the device after received this messag					age.		
		Hea	nder	Class	ID	Length (Bytes)		Payload	Checksum		
Message Structu	re	OxE	35 0x62	0x09	0x14	8			see below	CK_A CK_B	
Payload Contents	5:										
Byte Offset	Numb	ber	Scaling	Name		Unit	Description				
	Forma	ət									
0	U1		-	cmd		-	Command (must be 2)				
1 U1[3] -		reservedl		-	Reserved						
4 U1 -		-	response		-	0: Not acknowledged					
				1: Acknowledged							
5	U1[3	8]	-	rese	erved2	2	-	Reserved			



21.19.1.5 System Restored from Backup

Message		UP	UPD-SOS							
Description Syst			System Restored from Backup							
Firmware		Sup	Supported on:							
• u-blox M				from	firmwa	re versi	on 2.00) up to version 2.30		
Type Output										
Comment		The	e message	e is sen	t from	the dev	/ice to r	otify the host the BBR h	as been res	stored from a
		bad	ckup file ir	n flash	. The h	ost sho	uld clea	r the backup file after re	eceiving this	s message. If the
		UB	X-UPD-SC	S mes	sage is	polled,	this me	essage will be resent.		
Header			der	Class	ID	Length (Bytes) Payload Check			Checksum	
Message Structure		OxE	35 0x62	0x09	0x14	4 8			see below	CK_A CK_B
Payload Conte	nts:				•					
Byte Offset	Numb	ber	Scaling	Name			Unit	Description	Description	
	Form	ət								
0	U1		-	cmd			-	Command (must be 3)		
1	U1[3	3]	-	reserved1		1	-	Reserved		
4	U1		-	resp	onse		-	0: Unknown		
								1: Failed restoring fr	om backup	file
							2: Restored from ba	ckup file		
								3: Not restored (no l	backup)	
5	U1[3	3]	-	rese	erved2	2	-	Reserved	Reserved	



22 RTCM Protocol

22.1 Introduction

The RTCM (Radio Technical Commission for Maritime Services) protocol is a unidirectional protocol (input to the receiver) that is used to supply the GPS receiver with real-time differential correction data (DGPS). The RTCM protocol specification is available from <u>http://www.rtcm.org</u>.



i

This feature is only applicable to GPS operation.

For effective differential positioning accuracy, it is necessary that the reference station antenna is situated in a low multipath environment with an unobstructed view of the sky. It is recommended that reference receiver applies phase smoothing to the broadcast corrections.

22.2 Supported Messages

The following RTCM 2.3 messages are supported:

••	5 71
Message Type	Description
1	Differential GPS Corrections
2	Delta Differential GPS Corrections
3	GPS Reference Station Parameters
9	GPS Partial Correction Set

Supported RTCM 2.3 Message Types

22.3 Configuration

The DGPS feature does not need any configuration to work properly. When an RTCM stream is input on any of the communication interfaces, the data will be parsed and applied if possible, which will put the receiver into DGPS mode.

The only configurable parameter of DGPS mode is the timeout that can be specified using UBX-CFG-NAV5. This value defines the time after which old RTCM data will be discarded.

The RTCM protocol can be disabled/enabled on communication interfaces by means of the UBX-CFG-PRT message. By default, RTCM is enabled.

22.4 Output

DGPS mode will result in following modified output:

- NMEA-GGA: The quality field will be 2 (see NMEA Positon Fix Flags). The age of DGPS corrections and Reference station ID will be set.
- NMEA-GLL, NMEA-RMC, NMEA-VTG, NMEA-GNS: The posMode indicator will be D (see NMEA Positon Fix Flags).
- NMEA-PUBX-POSITION: The status will be D2/D3; The age of DGPS corrections will be set.
- UBX-NAV-SOL: The DGPS will be set.
- UBX-NAV-PVT: The DGPS will be set.
- UBX-NAV-STATUS: The DGPS will be set; The DGPS input will be set to "PR+PRR".
- UBX-NAV-SVINFO: The DGPS flag will be set for channels with valid DGPS correction data.
- UBX-NAV-DGPS: This message will contain all valid DGPS data



• If the base line exceeds 100km and a message type 3 is received, a UBX-INF-WARNING will be output, e.g. "WARNING: DGPS baseline big: 330.3km"

22.5 Restrictions

The following restrictions apply to DGPS mode:

- The DGPS solution will only include measurements from satellites for which DGPS corrections were provided. This is because the navigation algorithms cannot mix corrected with uncorrected measurements.
- SBAS corrections will not be applied when using RTCM correction data.
- Precise Point Positioning will be deactivated when using RTCM correction data.
- RTCM correction data cannot be applied when using AssistNow Offline or AssistNow Autonomous.

22.6 Reference

The RTCM support is implemented according to RTCM 10402.3 ("RECOMMENDED STANDARDS FOR DIFFERENTIAL GNSS").



Appendix

A Protocol Versions

The Protocol Version defines a set of messages that are applicable across various u-blox products. Each firmware used by a u-blox receiver supports a specific Protocol Version, which is not configurable.

Each receiver reports its supported Protocol Version in the following ways:

- On start-up in the 'boot screen'
- In the UBX-MON-VER message

The following tables show the supported Protocol Versions for a number of common firmware versions and platforms.

A.1 Supported Protocol Versions

u-blox 5

Firmware Version	Supported Protocol Version
4.00	10.00
4.01	10.01
5.00	11.00
6.00	12.00
6.02	12.02

u-blox 6

Firmware Version	Supported Protocol Version
6.00	12.00
6.02	12.02
7.01	13.01
7.03	13.03

u-blox 6 GPS/GLONASS/QZSS

Firmware Version	Supported Protocol Version
1.00	14.00

u-blox 7

Firmware Version	Supported Protocol Version
1.00	14.00
1.01	14.01

u-blox M8

Firmware Version	Supported Protocol Version
2.00	15.00
2.01	15.01
2.20	16.00
2.30	17.00



B Satellite Numbering

A summary of all the SV numbering schemes is provided in the following table.

	-						
GNSS Type	SV range	UBX gnssld:svld	UBX svld	NMEA 2.X-4.	NMEA 2.X-4.0	NMEA 4.1+	NMEA 4.1+
				0 (strict)	(extended)	(strict)	(extended)
GPS	G1-G32	0:1-32	1-32	1-32	1-32	1-32	1-32
SBAS	S120-S158	1:120-158	120-158	33-64	33-64,152-158	33-64	33-64,152-158
Galileo	E1-E36	2:1-36	211-246	-	301-336	1-36	1-36
BeiDou	B1-B37	3:1-37	159-163,33-64	-	401-437	1-37	1-37
IMES	1- 10	4:1-10	173-182	-	173-182	-	173-182
QZSS	Q1-Q5	5:1-5	193-197	-	193-197	-	193-197
GLONASS	R1-R32, R?	6:1-32, 6:255	65-96, 255	65-96, null	65-96, null	65-96, null	65-96, null

Satellite numbering

C u-blox M8 Default Settings

The default settings listed in this section apply from u-blox M8 ROM-based receivers with ROM version 2.00 and above. These values assume that the default levels of the configuration pins have been left unchanged and no setting that affects the default configuration was written to the eFuse. Default settings are dependent on the configuration pin and eFuse settings, for information regarding these settings, consult the applicable Data Sheet.

C.1 Antenna Supervisor Settings (UBX-CFG-ANT)

For parameter and protocol description see section UBX-CFG-ANT.

Antenna Settings

_			
Parameter	Description	Default Setting	Unit
flags-svcs	Enable Control Signal	Enabled	
flags-scd	Enable Short Circuit Detection	Enabled	
flags-pdwnOnSCD	Enable Short Circuit Power Down logic	Enabled	
flags-recovery	Enable Automatic Short Circuit Recovery logic	Enabled	
flags-ocd	Enable Open Circuit Detection	Disabled	
pins-pinSwitch	PIO-Pin used for switching antenna supply	16	
pins-pinSCD	PIO-Pin used for detecting a short in the antenna supply	15	
pins-pinOCD	PIO-Pin used for detecting open/not connected antenna	14	

C.2 Datum Settings (UBX-CFG-DAT)

For parameter and protocol description see section UBX-CFG-DAT.

Datum Default Settings

Parameter	Description	Default Setting	Unit
datumNum	Datum number	0	
datumName	Datum name	WGS84	
majA	Semi-major Axis	6378137	m
flat	1.0 / Flattening	298.257223563	
dX	X Axis shift at the origin	0	m
dY	Y Axis shift at the origin	0	m
dZ	Z Axis shift at the origin	0	m



Parameter	Description	Default Setting	Unit
rotX	Rotation about the X Axis	0	S
rotY	Rotation about the Y Axis	0	S
rotZ	Rotation about the Z Axis	0	S
scale	Scale change	0	ppm

Datum Default Settings continued

C.3 Navigation Settings (UBX-CFG-NAV5)

For parameter and protocol description see section UBX-CFG-NAV5.

Navigation Default Settings

U			
Parameter	Description	Default Setting	Unit
dynModel	Dynamic Platform Model	0 - Portable	
fixMode	Fix Mode	3 - Auto 2D/3D	
fixedAlt	Fixed Altitude	N/A (fixMode=3)	m
fixedAltVar	Fixed Altitude Variance	N/A (fixMode=3)	m^2
minElev	Min SV Elevation	5	deg
рDop	PDOP Mask	25	-
tDop	TDOP Mask	25	-
pAcc	P Accuracy	100	m
tAcc	T Accuracy	300	m
staticHoldThresh	Static Hold Threshold	0.00	cm/s
dgpsTimeOut	DGPS timeout	60	S
cnoThreshNumSVs	Number of SVs required to have C/N0	0	
	above cnoThresh for a valid fix		
cnoThresh	C/N0 threshold for a valid fix	0	dBHz
staticHoldMaxDist	Static hold distance threshold	0	m/s



The Dynamic Platform Model default setting is different for certain product variants.

C.4 Navigation Settings (UBX-CFG-NAVX5)

For parameter and protocol description see section UBX-CFG-NAVX5.

Navigation Default Settings

-	-		
Parameter	Description	Default Setting	Unit
minSVs	Minimum number of SV	3	
maxSVs	Maximum number of SV	20	
minCNO	Minimum C/N0 for navigation	6	dBHz
iniFix3D	Initial Fix must be 3D	Disabled	
wknRollover	Weeknumber rollover	1756	
usePPP	Use PPP	disabled	
aopCfg-useAOP	Use AssistNow Autonomous	Disabled	
aopOrbMaxErr	AssistNow Autonomous max. acceptable orbit error	100	m



The minimun number of SV default setting is different for certain product variants.



C.5 Output Rates (UBX-CFG-RATE)

For parameter and protocol description see section UBX-CFG-RATE.

Output Rate Default Settings

Parameter	Description	Default Setting	Unit
timeRef	Time Source	1 - GPS time	
measRate	Measurement Period	1000	ms
navRate	Measurement Rate	1	cycles

C.6 Power Management 2 Configuration (UBX-CFG-PM2)

For parameter and protocol description see section UBX-CFG-PM2.

Power Management 2 Configuration Default Settings

Parameter	Description	Default Setting	Unit
version	Version	1	
flags-extintSelect	EXTINT pin selection	EXTINT0	
flags-extintWake	EXTINT pin control - keep awake	Disabled	
flags-extintBackup	EXTINT pin control - force sleep/backup	Disabled	
flags-limitPeakCurr	Limit peak current	Disabled	
flags-waitTimeFix	Wait for time fix	Disabled	
flags-updateRTC	Update Real Time Clock	Disabled	
flags-updateEPH	Update ephemeris	Enabled	
flags-doNotEnterOff	Do not enter 'Inactive for Search' state when no fix	Disabled	
flags-mode	Mode of operation	Cyclic tracking	
updatePeriod	Update period	1000	ms
searchPeriod	Search period	10000	ms
gridOffset	Grid offset	0	ms
onTime	On time	0	S
minAcqTime	Minimum acquisition time	0	S

C.7 Receiver Manager Configuration (UBX-CFG-RXM)

For parameter and protocol description see section UBX-CFG-RXM.

Power Management Default Settings

Parameter	Description	Default Setting	Unit
lpMode	Low power mode	0 - Continuous Mode	

C.8 GNSS system configuration (UBX-CFG-GNSS)

For parameter and protocol description see section UBX-CFG-GNSS.

UBX-CFG-GNSS Default Settings

Parameter	Description	Default Setting	Unit
numTrkChHw	Number of available tracking channels	32	
numTrkChUse	Number of tracking channels to use	32	
numConfigBlocks	Number of configuration blocks following	5	
gnssld	GNSS identifier (see Satellite Numbering)	0, 1, 3, 5, 6	
flags-enable	Enable this GNSS system (see Satellite Numbering)	0, 1, 5, 6	



UBX-CFG-GNSS Default Settings continued

Parameter	Description	Default Setting	Unit
resTrkCh	Minimum number of tracking channels per GNSS	8, 1, 0, 8	
maxTrkCh	Maximum number of tracking channels per GNSS	16, 3, 3, 14	

C.9 SBAS Configuration (UBX-CFG-SBAS)

For parameter and protocol description see section UBX-CFG-SBAS.

SBAS Configuration Default Settings

Parameter	Description	Default Setting	Unit
mode-enabled	SBAS Subsystem	Enabled	
mode-test	Allow test mode usage	Disabled	
usage-range	Ranging (Use SBAS for navigation)	Enabled	
usage-diffCorr	Apply SBAS Correction Data	Enabled	
usage-integrity	Apply integrity information	Disabled	
maxSBAS	Maximum number of SBAS tracking	3	
	channels		
scanmode1	PRN Codes 120-151	120, 124, 126, 129, 133, 135, 137, 138	
scanmode2	PRN Codes 152-158	None	

C.10 Port Configuration (UBX-CFG-PRT)

For parameter and protocol description see section UBX-CFG-PRT.

C.10.1 UART Port Configuration

For parameter and protocol description see section UBX-CFG-PRT-UART.

UART 1 Default Settings

Parameter	Description	Default Setting	Unit
portID	Port ID	1 (UART 1)	
txReady-en	TX-ready feature	0 (disabled)	
mode-charLen	Character Length	3 (8 bit)	
mode-parity	Parity	4 (No parity)	
mode-nStopBits	Number of Stop Bits	0 (1 stop bit)	
baudRate	Baud rate	9600	baud
inProtoMask	Protocol in	inUBX, inNMEA, inRTCM	
outProtoMask	Protocol out	outUBX, outNMEA	
flags-extendedTxTimeout	Extended TX timeout	0 - disabled	

C.10.2 USB Port Configuration

For parameter and protocol description see section UBX-CFG-PRT-USB.

USB Default Settings

Parameter	Description	Default Setting	Unit
portID	Port ID	3 (USB)	
txReady-en	TX-ready feature	0 (disabled)	
inProtoMask	Protocol in	inUBX, inNMEA, inRTCM	
outProtoMask	Protocol out	outUBX, outNMEA	



C.10.3 SPI Port Configuration

For parameter and protocol description see section UBX-CFG-PRT-SPI.

SPI Default Settings

Parameter	Description	Default Setting	Unit
portID	Port ID	4 (SPI)	
txReady-en	TX-ready feature	0 (disabled)	
mode-spiMode	SPI mode	0 (CPOL=0, CPHA=0)	
mode-ffCnt	0xFF count	50	
inProtoMask	Protocol in	inUBX, inNMEA, inRTCM	
outProtoMask	Protocol out	outUBX, outNMEA	
flags-extendedTxTimeout	Extended TX timeout	0 - disabled	

C.10.4 DDC Port Configuration

For parameter and protocol description see section UBX-CFG-PRT-DDC.

DDC Default Settings

Parameter	Description	Default Setting	Unit
portID	Port ID	0 (DDC)	
txReady-en	TX-ready feature	0 (disabled)	
mode-slaveAddr	Slave address	0x42	
inProtoMask	Protocol in	inUBX, inNMEA, inRTCM	
outProtoMask	Protocol out	outUBX, outNMEA	
flags-extendedTxTimeout	Extended TX timeout	0 - disabled	

C.11 USB Settings (UBX-CFG-USB)

For parameter and protocol description see section UBX-CFG-USB.

USB default settings

Parameter	Description	Default Setting	Unit
vendorID	Vendor ID	0x1546	
productID	Product ID	0x01A8	
powerConsumption	Bus Current required	100	mΑ
flags-powerMode	Power Mode	1 (self-powered)	
vendorString	Vendor string	u-blox AG - www.	
		u-blox.com	
productString	Product string	u-blox GNSS	
		receiver	
serialNumber	Serial number		

C.12 Message Settings (UBX-CFG-MSG)

For parameter and protocol description see section UBX-CFG-MSG.

Enabled output messages

Message	Туре	All Ports
NMEA-Standard-GGA	Out	1
NMEA-Standard-GLL	Out	1
NMEA-Standard-GSA	Out	1



Enabled output messages continued

Message	Туре	All Ports
NMEA-Standard-GSV	Out	1
NMEA-Standard-RMC	Out	1
NMEA-Standard-VTG	Out	1

C.13 NMEA Protocol Settings (UBX-CFG-NMEA)

For parameter and protocol description see section UBX-CFG-NMEA.

NMEA Protocol Default Settings

Parameter	Description	Default Setting	Unit
filter-posFilt	Enable position output even for failed or invalid	Disabled	
	fixes		
filter-mskPosFilt	Enable position even for invalid fixes	Disabled	
filter-timeFilt	Enable time output even for invalid times	Disabled	
filter-dateFilt	Enable time output even for invalid dates	Disabled	
filter-gpsOnlyFilter	Restrict output to GPS satellites only	Disabled	
filter-trackFilt	Enable COG output even if COG is frozen	Disabled	
nmeaVersion	NMEA version	4.0	
numSV	Number of SVs to report	Unlimited	
flags-compat	Compatibility Mode	Disabled	
flags-consider	Consideration Mode	Enabled	
gnssToFilter-gps	Disable GPS satellites	False	
gnssToFilter-sbas	Disable SBAS satellites	False	
gnssToFilter-qzss	Disable QZSS satellites	False	
gnssToFilter-glonass	Disable GLONASS satellites	False	
gnssToFilter-beidou	Disable BeiDou satellites	False	
svNumbering	Output of SV's with no NMEA defined value	0 (not output)	
mainTalkerId	Override main Talker ID	0 (not overridden)	
gsvTalkerId	Override GSV Talker ID	0 (not overridden)	
bdsTalkerId	Set BeiDou Talker ID (two characters)	0 (not overridden)	

C.14 Logging Configuration (UBX-CFG-LOGFILTER)

For parameter and protocol description see section UBX-CFG-LOGFILTER.

UBX-CFG-LOGFILTER Default Settings

Parameter	Description	Default	Unit
		Setting	
flags-recordEnabled	Recording enabled	0	
flags-applyAllFilterSettings	Apply all filter settings	0	
flags-psmOncePerWakupEnabled	Recording of single position per PSM wake up enabled	0	
minInterval	Minimum time interval	0	S
timeThreshold	Time threshold	0	S
speedThreshold	Speed threshold	0	m/s
positionThreshold	Position threshold	0	m



C.15 Remote Inventory (UBX-CFG-RINV)

For parameter and protocol description see section UBX-CFG-RINV.

UBX-CFG-RINV Default Settings

Parameter	Description	Default Setting	Unit
flags-dump	Dump data at startup	0	
flags-binary	Data is binary	0	
data	Data stored in Remote Inventory	Notice: no data saved!	

C.16 INF Messages Settings (UBX-CFG-INF)

For parameter and protocol description see section UBX-CFG-INF.

INF messages default settings

Parameter	Туре	All Ports	Range/Remark
infMsgMask-ERROR	Out	1	In NMEA Protocol only (GPTXT)
infMsgMask-WARNING	Out	1	In NMEA Protocol only (GPTXT)
infMsgMask-NOTICE	Out	1	In NMEA Protocol only (GPTXT)
infMsgMask-TEST	Out		
infMsgMask-DEBUG	Out		

C.17 Timepulse Settings (UBX-CFG-TP5)

For parameter and protocol description see section UBX-CFG-TP5.

TIMEPULSE default settings

Parameter	Description	Default Setting	Unit
tpldx	Time pulse selection	0	
antCableDelay	Cable Delay	50	ns
rfGroupDelay	RF Groupdelay	0	ns
freqPeriod	Period	100000	us
freqPeriodLock	Period Locked	100000	us
pulseLenRatio	Pulse Length	0	us
pulseLenRatioLock	Pulse Length Locked	100000	us
userConfigDelay	User Delay	0	ns
flags-gridUtcGps	Timegrid	0 (UTC Time)	
flags-polarity	Polarity	1 (rising edge at top of second)	
flags-alignToTow	Align to TOW	1	
flags-isLength	IsLength	1	
flags-isFreq	IsFreq	0	
flags-lockedOtherSet	Locked other setting	1	
flags-lockGnssFreq	Lock to GNSS freq	1	
flags-Active	Active	1	

TIMEPULSE2 default settings

Parameter	Description	Default Setting	Unit
tpldx	Time pulse selection	1	
antCableDelay	Cable Delay	50	ns
rfGroupDelay	RF Groupdelay	0	ns
freqPeriod	Frequency	4	Hz



TIMEPULSE2 default settings continued

Parameter	Description	Default Setting	Unit
freqPeriodLock	Frequency Locked	1	Hz
pulseLenRatio	Pulse Length	125000	us
pulseLenRatioLock	Pulse Length Locked	100000	us
userConfigDelay	User Delay	0	ns
flags-gridUtcGps	Timegrid	0 (UTC Time)	
flags-polarity	Polarity	1 (rising edge at top of second)	
flags-alignToTow	Align to TOW	1	
flags-isLength	IsLength	1	
flags-isFreq	IsFreq	1	
flags-lockedOtherSet	Locked other setting	1	
flags-lockGnssFreq	Lock to GNSS freq	1	
flags-Active	Active	0	

C.18 Jammer/Interference Monitor (UBX-CFG-ITFM)

For parameter and protocol description see section UBX-CFG-ITFM.

Jamming/Interference monitor default settings

Parameter	Description	Default Setting	Unit
config-enable	Enable	Disabled	
config-bbThreshold	Broadband interference detection threshold	3	dB
config-cwThreshold	CW interference detection threshold	15	dB
config-antSetting	Antenna setting	0	

D u-blox M8 Standard firmware versions

Standard FW version strings

Generation	Version	String	ROM BASE
u-blox M8	FW 2.00	EXT CORE 2.00 (74182) Sep 26 2013 14:42:35	ROM 0.22
u-blox M8	FW 2.01	ROM CORE 2.01 (75331) Oct 29 2013 13:28:17	-
u-blox M8	FW 2.01	EXT CORE 2.01 (75350) Oct 29 2013 16:15:41	ROM 0.22, ROM 2.01



Related Documents

Overview

As part of our commitment to customer support, u-blox maintains an extensive volume of technical documentation for our products. In addition to product-specific data sheets and integration manuals, general documents are also available. These include:

- GPS Compendium, Docu. No <u>GPS-X-02007</u>
- GPS Antennas RF Design Considerations for u-blox GPS Receivers, Docu. No GPS-X-08014

Our website <u>www.u-blox.com</u> is a valuable resource for general and product specific documentation.

For design and integration projects the Receiver Description Including Protocol Specification should be used together with the Data Sheet and Hardware Integration Manual of the GNSS receiver.



Revision History

Revision	Date	Name	Status / Comments
R01	30 Sep 2013	efav	Added u-blox M8 firmware 2.00
R02	01 Nov 2013	efav	Added u-blox M8 firmware 2.01
R03	15 Dec 2013	efav	Added u-blox M8 ADR product variant
R04	10 Feb 2014	efav	Added u-blox M8 FTS product variant
R05	27 Jun 2014	efav	Added u-blox M8 Timing product variant
R06	09 Sep 2014	maba	Minor corrections
R07	09 Sep 2014	maba	Added u-blox M8 firmware 2.30
R08	04 Dec 2014	maba	Minor corrections



Contact

For complete contact information visit us at www.u-blox.com

u-blox Offices

North, Central and South America

u-blox America, Inc.

Phone: +1 703 483 3180 E-mail: info_us@u-blox.com

Regional Office West Coast:

Phone: +1 408 573 3640 E-mail: info_us@u-blox.com

Technical Support:

Phone:	+1 703 483 3185
E-mail:	support_us@u-blox.com

Headquarters Europe, Middle East, Africa

 u-blox AG

 Phone:
 +41 44 722 74 44

 E-mail:
 info@u-blox.com

 Support:
 support@u-blox.com

Asia, Australia, Pacific

u-blox Singapore Pte. Ltd.

Phone:	+65 6734 3811
E-mail:	info_ap@u-blox.com
Support:	support_ap@u-blox.com

Regional Office Australia:

Phone: +61 2 8448 2016 E-mail: info_anz@u-blox.com Support: support_ap@u-blox.com

Regional Office China (Beijing):

 Phone:
 +86 10 68 133 545

 E-mail:
 info_cn@u-blox.com

 Support:
 support_cn@u-blox.com

Regional Office China (Shenzhen):

Phone:	+86 755 8627 1083
E-mail:	info_cn@u-blox.com
Support:	support_cn@u-blox.com

Regional Office India:

Phone:	+91 959 1302 450
E-mail:	info_in@u-blox.com
Support:	support_in@u-blox.com

Regional Office Japan:

Phone:+81 3 5775 3850E-mail:info_jp@u-blox.comSupport:support_jp@u-blox.com

Regional Office Korea:

Phone:	+82 2 542 0861
E-mail:	info_kr@u-blox.com
Support:	support_kr@u-blox.com

Regional Office Taiwan:

-	
Phone:	+886 2 2657 1090
E-mail:	info_tw@u-blox.com
Support:	support_tw@u-blox.com